

Communication manual



DISCLAIMER OF WARRANTIES AND LIMITATION OF LIABILITY

The information, recommendations, descriptions, and safety notations in this document are based on manufacturer's experience and judgment and may not cover all contingencies. If further information is required, a sales representative should be consulted. Sale of the product shown in this literature is subject to the terms and conditions outlined in appropriate manufacturer selling policies or other contractual agreement between manufacturer and the purchaser.

THERE ARE NO UNDERSTANDINGS, AGREEMENTS, WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE OR MERCHANTABILITY, OTHER THAN THOSE SPECIFICALLY SET OUT IN ANY EXISTING CONTRACT BETWEEN THE PARTIES. ANY SUCH CONTRACT STATES THE ENTIRE OBLIGATION OF THE MANUFACTURER. THE CONTENTS OF THIS DOCUMENT SHALL NOT BECOME PART OF OR MODIFY ANY CONTRACT BETWEEN THE PARTIES.

In no event will the manufacturer be responsible to the purchaser or user in contract, in tort (including negligence), strict liability, or otherwise for any special, indirect, incidental, or consequential damage or loss whatsoever, including but not limited to damage or loss of use of equipment, plant or power system, cost of capital, loss of power, additional expenses in the use of existing power facilities, or claims against the purchaser or user by its customers resulting from the use of the information, recommendations, and descriptions contained herein. The information contained in this manual is subject to change without notice.

Cover Photo: Johnson Controls Variable Speed Drive Series III

Support services

Support

The goal of Johnson Controls is to ensure your greatest possible satisfaction with the operation of our products. We are dedicated to providing fast, friendly, and accurate assistance. That is why we offer you so many ways to get the support you need. Whether it is by phone, fax, or email, you can access Johnson Controls' support information 24 hours a day, seven days a week.

Our wide range of services is listed below.

You should contact your local distributor for product pricing, availability, ordering, expediting, and repairs.

Website

Use the Johnson Controls website to find product information.

Website address

www.johnsoncontrols.com → HVAC Controls → Variable Speed Drives

Johnson Controls product sales operation/ technical support

Call Local Service Center Representative.

If Representative is unknown, call 1-800-482-2778 and ask for a local service representative for programming support.

Contents

SAFETY

Before commencing the installation viii

Definitions and symbols ix

Warnings and cautions ix

Motor and equipment safety. xii

VARIABLE SPEED DRIVE SERIES III OVERVIEW

How to use this manual 1

Receiving and inspection. 1

Real time clock battery activation 1

Rating label 2

General information. 2

OPTION CARD SLOTS

Installing Variable Speed Drive Series III option board 4

Control wiring 4

EMC directive 5

Control cable grounding 5

MODBUS RTU ON-BOARD COMMUNICATIONS

Modbus RTU specifications 6

Commissioning 7

Modbus communication standards. 9

MODBUS TCP ON-BOARD COMMUNICATIONS

Modbus/TCP specifications. 16

Hardware specifications 16

Commissioning 18

Modbus communication standards. 25

BACNET MS/TP—ON-BOARD COMMUNICATION

BACnet MS/TP connections 31

Commissioning 34

BACnet MS/TP parameters 35

BACnet overview. 35

PROFIBUS-DP EXTERNAL COMMUNICATION CARDS

Hardware specifications 43

PROFIBUS cable 44

Commissioning 45

PROFIBUS overview 50

Contents, continued

**BACNET/IP ON-BOARD COMMUNICATION—
VARIABLE SPEED DRIVE SERIES III**
 Prepare to use BACnet/IP through RJ45 port57

APPENDIX A—PARAMETER ID LIST
 Parameter descriptions76

APPENDIX B—PROCESS DATA VALUES
Process data OUT (subordinate → master).93
Process data IN (master →subordinate)93

APPENDIX C—FAULT CODES
 Fault codes95

**APPENDIX D—VARIABLE SPEED DRIVE SERIES III RECOMMENDED
SECURE HARDENING GUIDELINES**
 Introduction97
 References99

List of Figures

Figure 1. RTC battery connection1

Figure 2. Rating label (VS3).2

Figure 3. Variable Speed Drive Series III control board3

Figure 4. Variable Speed Drive Series III control board location.3

Figure 5. Control cable grounding5

Figure 6. Connection diagram.6

Figure 7. Terminal wiring7

Figure 8. Termination resistor and shielding7

Figure 9. VS3 keypad navigation to RS-485 menu8

Figure 10. The basic structure of a modbus frame.9

Figure 11. Module and network status17

Figure 12. CAT-5e cable18

Figure 13. VS3 keypad navigation to ethernet comm settings.18

Figure 14. VS3 Static IP mode20

Figure 15. VS3 Static IP address.21

Figure 16. Principal example diagram.27

Figure 17. Stripping the cable28

Figure 18. RS-485 Cable strip (Aluminum Shield).28

Figure 19. Drive terminals (BACnet)28

Figure 20. Serial ground28

Figure 21. RS-485 Bus termination setup.29

Figure 22. BACnet bus termination29

Figure 23. VS3 BACnet MSTP parameter navigation30

Figure 24. Fault tracing37

Figure 25. Com1 PROFIBUS card layout39

Figure 26. Com1 PROFIBUS DB9 adapter40

Figure 27. PROFIBUS parameter menu41

Figure 28. PROFIdrive.46

Figure 29. Application class47

Figure 30. General state diagram52

Figure 31. Principle example diagram of BACnet57

Figure 32. CAT-5e cable58

Figure 33. VS3 keypad navigation to ethernet comm settings.59

Figure 34. VS3 Static IP mode61

Figure 35. VS3 Static IP address62

Figure 36. Fault tracing70

Figure 37. VS3 BACnet MSTP parameter navigation.71

Figure 38. Wiring diagram.72

Figure 39. Terminal wiring.72

Figure 40. Termination resistor and shielding73

List of Tables

Table 1. Common abbreviations	1
Table 2. Wire sizes	4
Table 3. Control wiring requirements	5
Table 4. Variable Speed Drive Series III—option boards	5
Table 5. Variable Speed Drive Series III protocols	5
Table 6. Connections	6
Table 7. Communications	6
Table 8. Modbus RTU	8
Table 9. Functions	10
Table 10. Request to read coils	10
Table 11. Request to read discrete inputs	10
Table 12. Request to read holding registers	10
Table 13. Request to read input registers	10
Table 14. Request to read exception status	11
Table 15. Read diagnostics	11
Table 16. Request to write single coil	11
Table 17. Request to write single register	11
Table 18. Write coils 19–28	11
Table 19. Request to write holding registers	11
Table 20. Index table	12
Table 21. Process data subordinate → master (max. 22 bytes)	12
Table 22. Process data master → subordinate (max. 22 bytes)	12
Table 23. Fieldbus basic input table	13
Table 24. FB control word	13
Table 25. Fieldbus basic output table	14
Table 26. FB Status Word Bit Descriptions	14
Table 27. FB general status word	14
Table 28. Process data OUT	15
Table 29. Process data IN	15
Table 30. Modbus/TCP technical data	16
Table 31. Ethernet LED description	16
Table 32. Module status LED description	17
Table 33. Network status LED description	17
Table 34. EtherNet/IP / Modbus TCP	19
Table 35. Request to read coils	22
Table 36. Request to read discrete inputs	22
Table 37. Request to read holding registers	22
Table 38. Request to read input registers	22
Table 39. Request to read exception status	22
Table 40. Read diagnostics	22

List of Tables, continued

Table 41. Request to write single coil	23
Table 42. Request to write single register	23
Table 43. Write coils 19–28	23
Table 44. Write holding registers	23
Table 45. Index table	23
Table 46. Process data subordinate → master (max. 22 bytes)	24
Table 47. Process data master → subordinate (max. 22 bytes)	24
Table 48. Fieldbus basic input table	24
Table 49. FB control word	25
Table 50. Fieldbus basic output table	25
Table 51. FB status word bit descriptions	25
Table 52. FB general status word	26
Table 53. Process data OUT	26
Table 54. Process data IN	27
Table 55. BACnet MS/TP technical data	27
Table 56. BACnet MS/TP Parameter Table	30
Table 57. Supported object types and properties summary	32
Table 58. Binary value object instance summary	35
Table 59. Analog value object instance summary	36
Table 60. Analog Input object instance summary	36
Table 61. Multi state object instance summary	37
Table 62. PROFIBUS technical data	38
Table 63. Line length	38
Table 64. PROFIBUS LEDs	39
Table 65. Connector and pin assignment	40
Table 66. PROFIBUS cable connections	40
Table 67. Recommended cable	40
Table 68. PROFIBUS parameters	42
Table 69. Binary bits and corresponding outputs	44
Table 70. Bypass mode process data modules	45
Table 71. Fieldbus basic output table	45
Table 72. Status word bit descriptions	45
Table 73. Application class	47
Table 74. PROFIdrive control word 1—STW1 message examples	48
Table 75. Control word (STW1) message examples	50
Table 76. Application status word PROFIdrive	50
Table 77. References	51
Table 78. PROFIBUS option Card	53
Table 79. Standard telegram 1	53
Table 80. Words and Double Words	54

List of Tables, continued

Table 81. Base mode parameter request	54
Table 82. Base model response	54
Table 83. Field coding	55
Table 84. BACnet/IP Protocol	57
Table 85. EtherNet/IP	59
Table 86. BACnet/IP	63
Table 87. BACnet/IP parameter descriptions.	64
Table 88. Supported object types and properties summary.	65
Table 89. Binary value object instance summary	67
Table 90. Analog value object instance summary	68
Table 91. Analog input object instance summary	69
Table 92. Multi state object instance summary	69
Table 93. SA Bus Protocol	71
Table 94. SA bus menu parameters	73
Table 95. SA Bus parameter descriptions.	73
Table 96. Object instance summary.	74
Table 97. VS3 Parameter ID list.	76
Table 98. Process data OUT (subordinate → master)	93
Table 99. Process data IN (master → subordinate for all applications . . .	93
Table 100. Fault code list	95
Table 101. Variable Speed Drive Series III—secure configuration guidelines	97

Safety



WARNING! DANGEROUS ELECTRICAL VOLTAGE!

Before commencing the installation

- Disconnect the power supply of the device
- Ensure that devices cannot be accidentally restarted
- Verify isolation from the supply
- Earth and short circuit the device
- Cover or enclose any adjacent live components
- Only suitably qualified personnel in accordance with EN 50110-1/-2 (VDE 0105 Part 100) may work on this device/system
- Before installation and before touching the device ensure that you are free of electrostatic charge
- The functional earth (FE, PES) must be connected to the protective earth (PE) or the potential equalization. The system installer is responsible for implementing this connection
- Connecting cables and signal lines should be installed so that inductive or capacitive interference does not impair the automation functions
- Install automation devices and related operating elements in such a way that they are well protected against unintentional operation
- Suitable safety hardware and software measures should be implemented for the I/O interface so that an open circuit on the signal side does not result in undefined states in the automation devices
- Ensure a reliable electrical isolation of the extra-low voltage of the 24V supply. Only use power supply units complying with IEC 60364-4-41 (VDE 0100 Part 410) or HD384.4.41 S2
- Deviations of the input voltage from the rated value must not exceed the tolerance limits given in the specifications, otherwise this may cause malfunction and dangerous operation
- Emergency stop devices complying with IEC/EN 60204-1 must be effective in all operating modes of the automation devices. Unlatching the emergency-stop devices must not cause a restart
- Devices that are designed for mounting in housings or control cabinets must only be operated and controlled after they have been installed and with the housing closed. Desktop or portable units must only be operated and controlled in enclosed housings
- Measures should be taken to ensure the proper restart of programs interrupted after a voltage DIP or failure. This should not cause dangerous operating states even for a short time. If necessary, emergency-stop devices should be implemented
- Wherever faults in the automation system may cause injury or material damage, external measures must be implemented to ensure a safe operating state in the event of a fault or malfunction (for example, by means of separate limit switches, mechanical interlocks, and so on)
- Depending on their degree of protection, adjustable frequency drives may contain live bright metal parts, moving or rotating components, or hot surfaces during and immediately after operation
- Removal of the required covers, improper installation, or incorrect operation of motor or adjustable frequency drive may cause the failure of the device and may lead to serious injury or damage
- The applicable national accident prevention and safety regulations apply to all work carried out on live adjustable frequency drives
- The electrical installation must be carried out in accordance with the relevant regulations (for example, with regard to cable cross sections, fuses, PE)
- Transport, installation, commissioning, and maintenance work must be carried out only by qualified personnel (IEC 60364, HD 384 and national occupational safety regulations)
- Installations containing adjustable frequency drives must be provided with additional monitoring and protective devices in accordance with the applicable safety regulations. Modifications to the variable frequency drives using the operating software are permitted
- All covers and doors must be kept closed during operation
- To reduce hazards for people or equipment, the user must include in the machine design measures that restrict the consequences of a malfunction or failure of the drive (increased motor speed or sudden standstill of motor). These measures include:
 - Other independent devices for monitoring safety-related variables (speed, travel, end positions, and so on)
 - Electrical or non-electrical system-wide measures (electrical or mechanical interlocks)
 - Never touch live parts or cable connections of the adjustable frequency drive after it has been disconnected from the power supply. Due to the charge in the capacitors, these parts may still be live after disconnection. Fit appropriate warning signs

Read this manual thoroughly and make sure you understand the procedures before you attempt to install, set up, operate or carry out any maintenance work on this variable frequency drive.

Definitions and symbols

WARNING

This symbol indicates high voltage. It calls your attention to items or operations that could be dangerous to you and other persons operating this equipment. Read the message and follow the instructions carefully.



This symbol is the "Safety Alert Symbol." It occurs with either of two signal words: CAUTION or WARNING, as described below.

WARNING

Indicates a potentially hazardous situation which, if not avoided, can result in serious injury or death.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, can result in minor to moderate injury, or serious damage to the product. The situation described in the CAUTION may, if not avoided, lead to serious results. Important safety measures are described in CAUTION (as well as WARNING).

Hazardous high voltage

WARNING

Motor control equipment and electronic controllers are connected to hazardous line voltages. When servicing drives and electronic controllers, there may be exposed components with housings or protrusions at or above line potential. Extreme care should be taken to protect against shock.

- Stand on an insulating pad and make it a habit to use only one hand when checking components
- Always work with another person in case an emergency occurs
- Disconnect power before checking controllers or performing maintenance
- Be sure equipment is properly earthed
- Wear safety glasses whenever working on electronic controllers or rotating machinery

WARNING

The components in the drive's power section remain energized after the supply voltage has been switched off. After disconnecting the supply, wait at least five minutes before removing the cover to allow the intermediate circuit capacitors to discharge.

Pay attention to hazard warnings!



DANGER
5 MIN

WARNING

Electric shock hazard—risk of injuries! Carry out wiring work only if the unit is de-energized.

WARNING

Do not perform any modifications on the AC drive when it is connected to mains.

Warnings and cautions

WARNING

Be sure to ground the unit following the instructions in this manual. Ungrounded units may cause electric shock and/or fire.

WARNING

This equipment should only be installed, adjusted, and serviced by qualified electrical maintenance personnel familiar with the construction and operation of this type of equipment and the hazards involved. Failure to observe this precaution could result in death or severe injury.

WARNING

Components within the drive are live when it is connected to power. Contact with this voltage is extremely dangerous and may cause death or severe injury.

WARNING

Line terminals (L1, L2, L3), motor terminals (U, V, W) and the DC link/brake resistor terminals (DC-, DC+/R+, R-) are live when the drive is connected to power, even if the motor is not running. Contact with this voltage is extremely dangerous and may cause death or severe injury.

⚠ WARNING

Even though the control I/O-terminals are isolated from line voltage, the relay outputs and other I/O-terminals may have dangerous voltage present even when the drive is disconnected from power. Contact with this voltage is extremely dangerous and may cause death or severe injury.

⚠ WARNING

This equipment has a large capacitive leakage current during operation, which can cause enclosure parts to be above ground potential. Proper grounding, as described in this manual, is required. Failure to observe this precaution could result in death or severe injury.

⚠ WARNING

Before applying power to this drive, make sure that the front and cable covers are closed and fastened to prevent exposure to potential electrical fault conditions. Failure to observe this precaution could result in death or severe injury.

⚠ WARNING

An upstream disconnect/protective device must be provided as required by the National Electric Code® (NEC®). Failure to follow this precaution may result in death or severe injury.

⚠ WARNING

This drive can cause a DC current in the protective earthing conductor. Where a residual current-operated protective (RCD) or monitoring (RCM) device is used for protection in case of direct or indirect contact, only an RCD or RCM of Type B is allowed on the supply side of this product.

⚠ WARNING

Carry out wiring work only after the drive has been correctly mounted and secured.

⚠ WARNING

Before opening the drive covers:

- Disconnect all power to the drive, including external control power that may be present
- Wait a minimum of five minutes after all the lights on the keypad are off. This allows time for the DC bus capacitors to discharge
- A hazard voltage may still remain in the DC bus capacitors even if the power has been turned off. Confirm that the capacitors have fully discharged by measuring their voltage using a multimeter set to measure the DC voltage

Failure to follow these precautions may cause death or severe injury.

⚠ WARNING

The opening of the branch-circuit protective device may be an indication that a fault current has been interrupted. To reduce the risk of fire or electric shock, current-carrying parts and other components of the controller should be examined and replaced if damaged. If burnout of the current element of an overload relay occurs, the complete overload relay must be replaced.

⚠ WARNING

Operation of this equipment requires detailed installation and operation instructions provided in the Installation/Operation manual intended for use with this product.

⚠ WARNING

Before servicing the drive:

- Disconnect all power to the drive, including external control power that may be present
- Place a “DO NOT TURN ON” label on the disconnect device
- Lock the disconnect device in the open position

Failure to follow these instructions will result in death or serious injury.

⚠ WARNING

The drive outputs (U, V, W) must not be connected to the input voltage or the utility line power as severe damage to the device may occur and there may be a risk of fire.

⚠ WARNING

The heat sink and/or outer enclosure may reach a high temperature.

Pay attention to hazard warnings!



Hot Surface—Risk of Burn. DO NOT TOUCH!

⚠ CAUTION

Any electrical or mechanical modification to this drive without prior written consent of manufacturer will void all warranties and may result in a safety hazard in addition and voiding of the UL® listing.

⚠ CAUTION

Install this drive on flame-resistant material such as a steel plate to reduce the risk of fire.

⚠ CAUTION

Install this drive on a perpendicular surface that is able to support the weight of the drive and is not subject to vibration, to lessen the risk of the drive falling and being damaged and/or causing personal injury.

⚠ CAUTION

Prevent foreign material such as wire clippings or metal shavings from entering the drive enclosure, as this may cause arcing damage and fire.

⚠ CAUTION

Install this drive in a well-ventilated room that is not subject to temperature extremes, high humidity, or condensation, and avoid locations that are directly exposed to sunlight, or have high concentrations of dust, corrosive gas, explosive gas, inflammable gas, grinding fluid mist, etc. Improper installation may result in a fire hazard.

⚠ CAUTION

When selecting the cable cross-section, take the voltage drop under load conditions into account. The consideration of other standards is the responsibility of the user.

The user is responsible for compliance with all international and national electrical standards in force concerning protective grounding of all equipment.

⚠ CAUTION

The specified minimum PE conductor cross-sections in this manual must be maintained.

Touch current in this equipment exceeds 3.5 mA (AC). The minimum size of the protective earthing conductor shall comply with the requirements of EN 61800-5-1 and/or the local safety regulations.

⚠ CAUTION

Touch currents in this frequency inverter are greater than 3.5 mA (AC). According to product standard IEC/EN 61800-5-1, an additional equipment grounding conductor of the same cross-sectional area as the original protective earthing conductor must be connected, or the cross-section of the equipment grounding conductor must be at least 10 mm² Cu. Drive requires that only copper conductor should be used.

⚠ CAUTION

Debounced inputs may not be used in the safety circuit diagram. Residual current circuit breakers (RCD) are only to be installed between the AC power supply network and the drive.

⚠ CAUTION

Debounced inputs may not be used in the safety circuit diagram. If you are connecting multiple motors on one drive, you must design the contactors for the individual motors according to utilization category AC-3.

Selecting the motor contactor is done according to the rated operational current of the motor to be connected.

⚠ CAUTION

Debounced inputs may not be used in the safety circuit diagram. A changeover between the drive and the input supply must take place in a voltage-free state.

⚠ CAUTION

Debounced inputs may not be used in the safety circuit diagram. Fire hazard!

Only use cables, protective switches, and contactors that feature the indicated permissible nominal current value.

⚠ CAUTION

Before connecting the drive to AC mains make sure that the EMC protection class settings of the drive are appropriately made according to instructions in this manual.

- If the drive is to be used in a floating distribution network, remove screws at MOV and EMC
- Disconnect the internal EMC filter when installing the drive on an IT system (an ungrounded power system or a high-resistance-grounded [over 30 ohm] power system), otherwise the system will be connected to ground potential through the EMC filter capacitors. This may cause danger, or damage the drive
- Disconnect the internal EMC filter when installing the drive on a corner grounded TN system, otherwise the drive will be damaged

Note: When the internal EMC filter is disconnected, the drive might be not EMC compatible.

- Do not attempt to install or remove the MOV or EMC screws while power is applied to the drive's input terminals.

Motor and equipment safety

CAUTION

Do not perform any meggar or voltage withstand tests on any part of the drive or its components. Improper testing may result in damage.

CAUTION

Prior to any tests or measurements of the motor or the motor cable, disconnect the motor cable at the drive output terminals (U, V, W) to avoid damaging the drive during motor or cable testing.

CAUTION

Do not touch any components on the circuit boards. Static voltage discharge may damage the components.

CAUTION

Before starting the motor, check that the motor is mounted properly and aligned with the driven equipment. Ensure that starting the motor will not cause personal injury or damage equipment connected to the motor.

CAUTION

Set the maximum motor speed (frequency) in the drive according to the requirements of the motor and the equipment connected to it. Incorrect maximum frequency settings can cause motor or equipment damage and personal injury.

CAUTION

Before reversing the motor rotation direction, ensure that this will not cause personal injury or equipment damage.

CAUTION

Make sure that no power correction capacitors are connected to the drive output or the motor terminals to prevent drive malfunction and potential damage.

CAUTION

Make sure that the drive output terminals (U, V, W) are not connected to the utility line power as severe damage to the drive may occur.

CAUTION

When the control terminals of two or more drive units are connected in parallel, the auxiliary voltage for these control connections must be taken from a single source which can either be one of the units or an external supply.

CAUTION

The drive will start up automatically after an input voltage interruption if the external run command is on.

CAUTION

Do not control the motor with the disconnecting device (disconnecting means); instead, use the control panel start and stop keys and, or commands via the I/O board of the drive. The maximum allowed number of charging cycles of the DC capacitors (i.e. power-ups by applying power) is five in ten minutes.

CAUTION

Improper drive operation:

- If the drive is not turned on for a long period, the performance of its electrolytic capacitors will be reduced
- If it is stopped for a prolonged period, turn the drive on at least every six months for at least 5 hours to restore the performance of the capacitors, and then check its operation. It is recommended that the drive is not connected directly to the line voltage. The voltage should be increased gradually using an adjustable AC source

Failure to follow these instructions can result in injury and/or equipment damage.

Sécurité



AVERTISSEMENT ! TENSION ÉLECTRIQUE DANGEREUSE !

Avant de commencer l'installation

- Débrancher l'alimentation de l'appareil
- S'assurer que les dispositifs ne peuvent pas être accidentellement redémarrés
- Vérifier l'isolement de l'alimentation
- Mettre l'appareil à la terre et le protéger contre les courts-circuits
- Couvrir ou enfermer tout composant sous tension adjacent
- Seul le personnel qualifié conformément à la norme EN 50110-1/-2 (VDE 0105 Partie 100) peut travailler sur cet appareil/ce système
- Avant l'installation et avant de toucher l'appareil, s'assurer de ne porter aucune charge électrostatique
- La terre fonctionnelle (FE, PSE) doit être raccordée à la terre de protection (PE) ou la compensation de potentiel. L'installateur du système a la responsabilité d'assurer cette connexion
- Les câbles de connexion et les lignes de signal doivent être installés de façon à ce que les interférences capacitives ou inductives ne compromettent pas les fonctions d'automatisation
- Installer les appareils d'automatisation et les éléments de fonctionnement associés de manière à ce qu'ils soient bien protégés contre tout fonctionnement accidentel
- Des dispositifs de sécurité matériels et logiciels appropriés doivent être utilisés en rapport avec l'interface des E/S afin qu'un circuit ouvert sur le côté signal ne résulte pas en états indéfinis dans les dispositifs d'automatisation
- Assurer une isolation électrique fiable sur le côté tension extra basse de l'alimentation 24 V. Utiliser uniquement des blocs d'alimentation conformes à la norme CEI 60364-4-41 (VDE 0100, partie 410) ou HD384.4.41 S2
- Les écarts entre la tension d'entrée et la tension nominale ne doivent pas dépasser les limites de tolérance indiquées dans les spécifications, au risque de provoquer un mauvais fonctionnement et une utilisation dangereuse du système
- Les dispositifs d'arrêt d'urgence conformes à la norme CEI/EN 60204-1 doivent être efficace dans tous les modes de fonctionnement des dispositifs d'automatisation. Le déverrouillage des dispositifs d'arrêt d'urgence ne doit pas entraîner un redémarrage
- Les dispositifs conçus pour un montage dans des boîtiers ou armoires de commande ne doivent être utilisés et contrôlés qu'après avoir été installés et avec le boîtier fermé. Les unités de bureau ou portatives ne doivent être utilisées et contrôlées que dans leurs boîtiers fermés
- Des mesures doivent être prises pour assurer un bon redémarrage des programmes interrompus après une chute ou une panne de tension. Ceci ne doit pas causer des états de fonctionnement dangereux, même pour un court laps de temps. Si nécessaire, des dispositifs d'arrêt d'urgence doivent être utilisés
- Quand des défaillances du système d'automatisation peuvent entraîner des blessures ou des dommages matériels, des mesures externes doivent être appliquées pour assurer un état de fonctionnement sans danger en cas de panne ou de mauvais fonctionnement (par exemple au moyen de disjoncteurs séparés, de verrouillages mécaniques, etc.)
- En fonction de leur degré de protection, les entraînements à fréquence variable peuvent contenir des pièces métalliques sous tension, des composants rotatifs ou en mouvement et des surfaces brûlantes, pendant le fonctionnement et immédiatement après l'arrêt
- Le retrait des protections requises, une installation incorrecte ou un mauvais fonctionnement du moteur ou de l'entraînement à fréquence variable peuvent causer la défaillance de l'appareil et entraîner des blessures graves et des dommages importants
- La réglementation nationale applicable en matière de sécurité et de prévention des accidents s'applique à tous les travaux effectués sur les entraînements à fréquence variable sous tension
- L'installation électrique doit être effectuée conformément aux réglementations applicables (par exemple, en ce qui concerne les sections transversales des câbles, les fusibles, la mise à la terre de protection)
- Le transport, l'installation, la mise en service et les travaux de maintenance doivent être effectués uniquement par un personnel qualifié (IEC 60364, HD 384 et règles de sécurité du travail)
- Les installations contenant des entraînements à fréquence variable doivent être équipées de dispositifs de surveillance et de protection, conformément aux réglementations applicables en matière de sécurité. Les modifications des entraînements à fréquence variable réalisées à l'aide du logiciel d'exploitation sont autorisées
- Toutes les protections et les portes doivent être maintenues fermées pendant le fonctionnement

- Pour réduire les risques d'accidents et de dommages matériels, l'utilisateur doit inclure dans la conception de la machine des mesures limitant les conséquences de panne ou de mauvais fonctionnement de l'entraînement (augmentation de la vitesse ou arrêt soudain du moteur). Ces mesures comprennent :
 - Autres dispositifs indépendants de surveillance des variables en rapport avec la sécurité (vitesse, voyages, positions d'extrémité, etc.)
 - Mesures électriques ou non électriques appliquées à l'ensemble du système (verrouillages électriques ou mécaniques)
 - Ne jamais toucher les pièces sous tension ni les connexions des câbles de l'entraînement à fréquence variable après leur déconnexion de l'alimentation. En raison de la charge dans les condensateurs, ces pièces peuvent être encore sous tension après la déconnexion. Installer les panneaux d'avertissement appropriés

Lire ce manuel en entier et s'assurer de bien comprendre les procédures avant de tenter d'installer, de configurer, d'utiliser et d'effectuer tout travail d'entretien sur cet entraînement à fréquence variable.

Définitions et symboles

AVERTISSEMENT

Ce symbole indique une haute tension. Il attire l'attention sur les éléments ou les opérations qui pourraient être dangereux pour les personnes utilisant cet équipement. Lire attentivement le message et suivre attentivement les instructions.



Ce symbole est le « symbole d'alerte de sécurité ». Il accompagne les deux termes d'avertissement suivants: MISE EN GARDE ou AVERTISSEMENT, comme décrit ci-dessous.

AVERTISSEMENT

Indique une situation potentiellement dangereuse qui, si elle n'est pas évitée, peut entraîner des blessures graves ou la mort.

MISE EN GARDE

Indique une situation potentiellement dangereuse qui, si elle n'est pas évitée, peut entraîner des blessures légères à modérées et d'importants dégâts matériels. La situation décrite dans la MISE EN GARDE peut, si elle n'est pas évitée, entraîner des conséquences graves. Des mesures de sécurité importantes sont décrites dans les MISES EN GARDE (ainsi que dans les AVERTISSEMENTS).

Haute tension dangereuse

AVERTISSEMENT

L'équipement de contrôle du moteur et les contrôleurs électroniques sont branchés sur des tensions secteur dangereuses. Lors de l'entretien des entraînements et des contrôleurs électroniques, il peut y avoir des composants exposés avec des boîtiers ou des protubérances au niveau du potentiel du réseau ou au-dessus. Toutes les précautions doivent être prises pour se protéger contre les chocs électriques.

- Se tenir sur un tapis isolant et prendre l'habitude de n'utiliser qu'une seule main pour vérifier les composants
- Toujours travailler avec une autre personne lorsqu'une situation d'urgence se produit
- Débrancher l'alimentation avant de vérifier les contrôleurs ou d'effectuer des travaux d'entretien
- S'assurer que l'équipement est correctement relié à la terre
- Porter des lunettes de sécurité lors des travaux sur les contrôleurs électroniques ou les machines rotatives

AVERTISSEMENT

Les composants de la section d'alimentation de l'entraînement restent sous tension après la coupure de la tension d'alimentation. Après la déconnexion de l'alimentation, attendre au moins cinq minutes avant de retirer le couvercle pour permettre la décharge des condensateurs du circuit intermédiaire.

Prêter attention aux avertissements signalant des dangers !



**DANGER
5 MIN**

AVERTISSEMENT

Risque de choc électrique - risque de blessures ! Effectuer le câblage uniquement si l'unité n'est plus sous tension.

AVERTISSEMENT

Ne pas effectuer de modifications sur l'entraînement CA lorsqu'il est connecté à l'alimentation secteur.

Avertissements et mises en garde

AVERTISSEMENT

S'assurer de mettre l'appareil à la terre en suivant les instructions de ce manuel. Les unités non mises à la terre peuvent causer des chocs électriques et des incendies.

AVERTISSEMENT

Cet équipement ne doit être installé, réglé et entretenu que par un personnel d'entretien électrique qualifié connaissant la construction et le fonctionnement de ce type d'équipement, ainsi que les risques encourus. Le non-respect de cette précaution peut entraîner la mort ou des blessures graves.

AVERTISSEMENT

Les composants à l'intérieur de l'entraînement sont sous tension lorsque l'entraînement est branché à l'alimentation. Le contact avec cette tension est extrêmement dangereux et peut causer la mort ou des blessures graves.

AVERTISSEMENT

Les bornes de phase (L1, L2, L3), les bornes du moteur (U, V, W) et les bornes de résistance de liaison CC/frein (DC-, DC+ /R+, R-) sont sous tension lorsque l'entraînement est branché à l'alimentation, même si le moteur ne tourne pas. Le contact avec cette tension est extrêmement dangereux et peut causer la mort ou des blessures graves.

AVERTISSEMENT

Même si les bornes E/S de commande sont isolées de la tension secteur, les sorties de relais et les autres bornes E/S peuvent présenter une tension dangereuse même lorsque l'entraînement est débranché. Le contact avec cette tension est extrêmement dangereux et peut causer la mort ou des blessures graves.

AVERTISSEMENT

Cet équipement a un grand courant de fuite capacitif pendant le fonctionnement, ce qui peut mettre les pièces du boîtier à un niveau supérieur au potentiel de terre. Une mise à la terre appropriée, telle que décrite dans ce manuel, est nécessaire. Le non-respect de cette précaution peut entraîner la mort ou des blessures graves.

AVERTISSEMENT

Avant de mettre l'entraînement sous tension, s'assurer que les protections avant et des câbles sont fermées et attachées pour empêcher l'exposition à d'éventuelles défaillances électriques. Le non-respect de cette précaution peut entraîner la mort ou des blessures graves.

AVERTISSEMENT

Un dispositif de protection/déconnexion en amont doit être fourni, tel que requis par le code électrique national (NEC®). Le non-respect de cette précaution peut entraîner la mort ou des blessures graves.

AVERTISSEMENT

Cet entraînement peut causer un courant CC dans le conducteur de mise à la terre de protection. Lorsqu'un dispositif de protection ou de surveillance à courant résiduel est utilisé pour la protection en cas de contact direct ou indirect, seul un dispositif de type B est autorisé sur le côté alimentation de ce produit.

AVERTISSEMENT

Ne travailler sur le câblage qu'après que l'entraînement a été correctement monté et attaché.

AVERTISSEMENT

Avant d'ouvrir les couvercles de l'entraînement :

- Débrancher toute l'alimentation allant à l'entraînement, y compris l'alimentation de commande externe pouvant être présente
- Attendre un minimum de cinq minutes après l'extinction de tous les voyants du clavier. Cela permet aux condensateurs de bus CC de se décharger
- Une tension dangereuse peut rester dans les condensateurs de bus CC même si l'alimentation a été coupée. Confirmer que les condensateurs sont entièrement déchargés en mesurant la tension à l'aide d'un multimètre réglé pour mesurer la tension CC

Le non-respect de cette précaution peut entraîner la mort ou des blessures graves.

AVERTISSEMENT

L'ouverture du dispositif de protection du circuit de dérivation peut indiquer que le courant de défaut a été interrompu. Pour réduire le risque d'incendie ou de choc électrique, les pièces porteuses de courant et les autres composants du contrôleur doivent être examinés et remplacés s'ils sont endommagés. Si l'élément de courant d'un relais de surcharge a grillé, le relais de surcharge doit être intégralement remplacé.

AVERTISSEMENT

Le fonctionnement de cet équipement nécessite le respect des instructions d'installation et de fonctionnement détaillées fournies dans le manuel d'installation/de fonctionnement destiné à être utilisé avec ce produit.

⚠ AVERTISSEMENT

Avant de procéder à l'entretien de l'entraînement :

- **Débrancher toute l'alimentation allant à l'entraînement, y compris l'alimentation de commande externe pouvant être présente**
- **Placer une étiquette « NE PAS UTILISER » sur le dispositif de déconnexion**
- **Verrouiller le dispositif de déconnexion en position ouverte**

Le non-respect de ces instructions peut entraîner la mort ou des blessures graves.

⚠ AVERTISSEMENT

Les sorties de l'entraînement (U, V, W) ne doivent pas être connectées à la tension d'entrée ni à l'alimentation secteur, car ceci pourrait gravement endommager l'appareil et causer un incendie.

⚠ AVERTISSEMENT

Le dissipateur de chaleur et/ou le boîtier externe peuvent atteindre une température élevée.

Prêter attention aux avertissements signalant des dangers !



Surface brûlante - Risque de brûlure. NE PAS TOUCHER !

⚠ MISE EN GARDE

Toute modification électrique ou mécanique de cet entraînement sans consentement écrit préalable fabricant annule toutes les garanties, peut entraîner un danger pour la sécurité et annuler l'homologation UL®.

⚠ MISE EN GARDE

Installer cet entraînement sur une matière résistante aux flammes, telle qu'une plaque d'acier, pour réduire les risques d'incendie.

⚠ MISE EN GARDE

Installer cet entraînement sur une surface perpendiculaire capable de supporter le poids de l'entraînement et non soumise à des vibrations afin de diminuer les risques de chute et de dommage de l'entraînement, ainsi que les risques de blessures.

⚠ MISE EN GARDE

Empêcher la pénétration de corps étrangers, tels que morceaux de fils et copeaux métalliques, dans le boîtier de l'entraînement, car ceci pourrait provoquer la formation d'un arc électrique et un incendie.

⚠ MISE EN GARDE

Installer cet entraînement dans une pièce bien aérée non soumise à des températures extrêmes, à une forte humidité ou à la condensation. Éviter les endroits directement exposés au soleil ou présentant de fortes concentrations de poussières, des gaz corrosifs, des gaz explosifs, des gaz inflammables, ou des vapeurs de liquide de meulage, etc. Une installation inadéquate peut entraîner un risque d'incendie.

⚠ MISE EN GARDE

Lors de la sélection de la section transversale des câbles, prendre en compte la chute de tension dans des conditions de charge. La prise en compte d'autres paramètres relève de la responsabilité de l'utilisateur.

Il relève de la responsabilité de l'utilisateur de respecter toutes les normes électriques nationales et internationales en vigueur concernant la mise à la terre de protection de l'ensemble de l'équipement.

⚠ MISE EN GARDE

Les spécifications minimum relatives aux sections transversales des conducteurs de terre de protection indiquées dans ce manuel doivent être respectées.

Le courant de fuite de cet équipement dépasse 3,5 mA (CA). La taille minimum du conducteur de la mise à la terre de protection doit être conforme aux exigences de la norme EN 61800-5-1 et/ou aux réglementations de sécurité locales.

⚠ MISE EN GARDE

Les courants de fuite de ce convertisseur de fréquence sont supérieures à 3,5 mA (CA). Conformément à la norme CEI/EN 61800-5-1, un conducteur de mise à la terre de l'équipement supplémentaire possédant la même superficie de coupe transversale que le conducteur de mise à la terre de protection d'origine doit être branché, ou la section transversale du conducteur de mise à la terre de l'équipement doit être d'au moins 10 mm² Cu. Seul un conducteur en cuivre doit être utilisé avec cet entraînement.

⚠ MISE EN GARDE

Les entrées anti-rebond ne sont pas permises dans le schéma du circuit de sécurité. Des disjoncteurs de courant résiduel (RCD) ne peuvent être installés qu'entre le réseau de courant alternatif et l'entraînement.

MISE EN GARDE

Les entrées anti-rebond ne sont pas permises dans le schéma du circuit de sécurité. Si plusieurs moteurs sont connectés à un entraînement, des contacteurs doivent être conçus pour les moteurs individuels conformément à la catégorie d'utilisation AC-3.

Sélectionner du contacteur du moteur en fonction du courant de fonctionnement nominal du moteur à connecter.

MISE EN GARDE

Les entrées anti-rebond ne sont pas permises dans le schéma du circuit de sécurité. Une commutation entre l'entraînement et l'alimentation d'entrée doit avoir lieu dans un état sans tension.

MISE EN GARDE

Les entrées anti-rebond ne sont pas permises dans le schéma du circuit de sécurité. Risque d'incendie !

Utiliser uniquement des câbles, des interrupteurs de protection et des contacteurs indiquant le courant nominal permis.

MISE EN GARDE

Avant de connecter l'entraînement à l'alimentation secteur CA, s'assurer que les réglages de la classe de protection CEM sont correctement effectués selon les instructions de ce manuel.

- Si l'entraînement doit être utilisé dans un réseau de distribution flottant, retirer les vis au niveau des VOM et CEM. Voir « Installation dans un réseau à une phase connectée à la terre (corner-grounded) »
- Débrancher le filtre CEM interne lors de l'installation de l'entraînement sur un réseau IT (système d'alimentation non mis à la terre ou système d'alimentation électrique mis à la terre haute résistance [plus de 30 ohms]) pour ne pas que le système soit connecté au potentiel de terre via les condensateurs du filtre CEM. Ceci peut être une cause de dangers ou endommager l'entraînement
- Débrancher le filtre CEM interne lors de l'installation de l'entraînement sur un système TN à une phase connectée à la terre pour ne pas endommager l'entraînement

Note: Lorsque le filtre CEM interne est débranché, l'entraînement peut ne pas être conforme aux normes de compatibilité électromagnétique.

- Ne pas tenter d'installer ou de retirer les vis des VOM et CEM lorsque l'alimentation est appliquée aux bornes d'entrée de l'entraînement

Sécurité du moteur et de l'équipement

MISE EN GARDE

N'effectuer aucun test de résistance de tension ou au mégohmmètre sur toute partie de l'entraînement ou de ses composants. Un test inadéquat peut entraîner des dommages.

MISE EN GARDE

Avant tout test ou mesure du moteur ou du câble du moteur, débrancher le câble du moteur au niveau des bornes de sortie de l'entraînement (U, V, W) pour éviter d'endommager ce dernier lors des tests.

MISE EN GARDE

Ne toucher aucun composant sur les cartes de circuit. Les décharges d'électricité statique peuvent endommager les composants.

MISE EN GARDE

Avant de mettre le moteur en marche, vérifier qu'il est correctement monté et aligné avec l'équipement entraîné. S'assurer que le démarrage du moteur ne risque pas de provoquer des blessures ou d'endommager l'équipement connecté au moteur.

MISE EN GARDE

Régler la vitesse maximale du moteur (fréquence) dans l'entraînement conformément aux exigences du moteur et de l'équipement qui lui est connecté. Des réglages de fréquence maximum incorrects peuvent endommager le moteur ou l'équipement et causer des blessures.

MISE EN GARDE

Avant d'inverser le sens de rotation du moteur, veiller à ce que cela ne risque pas de provoquer des blessures ou des dommages matériels.

MISE EN GARDE

S'assurer qu'aucun condensateur de correction de puissance n'est connecté à la sortie de l'entraînement ou aux bornes du moteur pour éviter un mauvais fonctionnement de l'entraînement et des dommages potentiels.

MISE EN GARDE

S'assurer que les bornes de sortie de l'entraînement (U, V, W) ne sont pas connectées à l'alimentation secteur, ce qui pourrait causer de graves dommages à l'entraînement.

MISE EN GARDE

Lorsque les bornes de commande de deux ou plusieurs unités d'entraînement sont raccordées en parallèle, la tension auxiliaire de ces connexions de commande doit être fournie par une source unique, qui peut être soit l'une des unités, soit une alimentation externe.

MISE EN GARDE

L'entraînement démarre automatiquement après une interruption de la tension d'entrée si la commande de démarrage externe est active.

MISE EN GARDE

Ne pas commander le moteur avec le dispositif de déconnexion ; à la place, utiliser les touches de marche et d'arrêt du tableau de contrôle ou les commandes du tableau des E/S de l'entraînement. Le nombre de cycles de charge maximum permis des condensateurs CC (c'est-à-dire les mises sous tension par application de puissance) est de cinq en dix minutes.

MISE EN GARDE

Fonctionnement incorrect de l'entraînement :

- Si l'entraînement n'est pas mis en marche pendant une longue période, la performance de ses condensateurs électrolytiques sera réduite
- S'il est arrêté pour une période prolongée, le mettre en marche au moins tous les six mois pendant au moins 5 heures pour restaurer la performance des condensateurs, puis vérifier son fonctionnement. Il est recommandé de ne pas brancher l'entraînement directement sur la tension secteur. La tension doit être augmentée progressivement en utilisant une source CA réglable

Le non-respect de ces instructions peut entraîner des blessures ou des dégâts matériels.

Variable Speed Drive Series III Overview

This series overview describes the purpose and contents of this manual, the receiving inspection recommendations and the Variable Speed Drive Series III Open Drive catalog numbering system.

How to use this manual

The purpose of this manual is to provide you with information necessary to install, set and customize parameters, start up, troubleshoot and maintain the Variable Speed Drive Series III Variable Frequency Drive (VFD). To provide for safe installation and operation of the equipment, read the safety guidelines at the beginning of this manual and follow the procedures outlined in the following chapters before connecting power to the Variable Speed Drive Series III VFD. Keep this operating manual handy and distribute to all users, technicians and maintenance personnel for reference.

Receiving and inspection

The Variable Speed Drive Series III VFD has met a stringent series of factory quality requirements before shipment. It is possible that packaging or equipment damage may have occurred during shipment. After receiving your Variable Speed Drive Series III VFD, please check for the following:

Check to make sure that the package includes the Instruction Leaflet, Quick Start Guide, and accessory packet. The accessory packet includes:

- Rubber grommets
- Control cable grounding clamps
- Additional grounding screw

Inspect the unit to ensure it was not damaged during shipment.

Make sure that the part number indicated on the nameplate corresponds with the catalog number on your order.

If shipping damage has occurred, please contact and file a claim with the carrier involved immediately.

If the delivery does not correspond to your order, please contact your Johnson Controls representative.

Note: Do not destroy the packing. The template printed on the protective cardboard can be used for marking the mounting points of the Variable Speed Drive Series III VFD on the wall or in a cabinet.

Real time clock battery activation

To activate the real time clock (RTC) functionality in the Variable Speed Drive Series III VFD, the RTC battery (already mounted in the drive) must be connected to the control board.

Simply remove the primary drive cover, locate the RTC battery directly below the keypad, and connect the white 2-wire connector to the receptacle on the control board.

Figure 1. RTC battery connection



Table 1. Common abbreviations

Abbreviation	Definition
CT	Constant torque with high overload rating (150%)
VT	Variable torque with low overload rating (110%)
I _H	High Overload (150%)
I _L	Low Overload (110%)
RTC	Real Time Clock
VFD	Variable Frequency Drive

Rating label

Figure 2. Rating label (VS3)

 Johnson Controls			
Cat No: VS3-005-4-UL1-0			
Style No: 3-4880-005UL1			
Article No: 3-4880-005UL1			
SERIES 3 VFD		Factory ID: 1	
VT		Input	Output
4KW	U(V~)	380-440 3Ø	0~Vin 3Ø
	F(Hz)	50/60 Hz	0-400 Hz
	I (A)	11.2	9
7.5HP	U(V~)	440-500 3Ø	0~Vin 3Ø
	F(Hz)	50/60 Hz	0-400 Hz
	I (A)	11.2	7.6
Enclosure Rating		TYPE 1/IP 21	
User Installation Manual: LIT-12012998 Serial No: 1234567890			
 NAED: 786685886053			
 			
			
N.W.: 6.10KG		G.W.: 7.10KG	
150512		Assembled in USA	
www.johnsoncontrols.com			

General information

The Variable Speed Drive Series III provides a wide selection of option boards to increase the number and type of control inputs and outputs (I/O) and communication interfaces to provide the versatility required for today's demanding motor control applications.

The input and output capability is designed with modularity in mind, comprised of option boards, each having its own input and output configuration. The control unit is designed to accept a total of two boards, the boards provide standard analog and digital inputs and outputs, fieldbus capability, and application specific hardware.

The basic, expander and adapter boards are installed in board slots, which are parts of the control board. The I/O boards are interchangeable between different members of the Variable Speed Drive Series III.

Option Card Slots

The control board is located inside the control unit of the Variable Speed Drive Series III. There are two slots, labeled A and B, on the control board. The different option boards can be added to any slots. For more information, see "Variable Speed Drive Series III Option Board Summary." When the Variable Speed Drive Series III is assembled at the factory, no option boards are installed in slots A and B. If an incorrect board is plugged into either slot, the board will not work, but there is no danger to personal or for equipment damage.

Figure 3. Variable Speed Drive Series III control board





Figure 4. Variable Speed Drive Series III control board location





Installing Variable Speed Drive Series III option board


Remove Utility line and control power from the drive. Install the option board in one of the slots available on the control board. To insert and remove the board, hold it in a horizontally straight position to avoid twisting the connector pins.

CAUTION

To prevent board damage, option cards and fieldbus boards must not be installed, removed or replaced while utility line or control power is applied to the drive.



Verify the board fits tightly in the metal clamp and plastic groove. If the board seems to be difficult to install in the slot, you should confirm that you are using one of the allowed slots for the option board.



Note: Check that the DIP switch settings on the board correspond to your need.

Control wiring

Digital I/O and 24 Vdc can use Stranded Cu or Solid Cu wire as specified below. Analog signal PT100 must use shielded cables. **Table 2** shows the wire sizes available. I/O terminals allow for 5.00 mm connectors.

Table 2. Wire sizes

Wire type	Wire size	Terminal torque
Solid Cu –90 °C	12–28 AWG (0.2–2.5 mm ²)	4.5 in-lb (0.5 Nm)
Stranded Cu –90 °C	12–30 AWG (0.2–2.5 mm ²)	4.5 in-lb (0.5 Nm)

EMC directive

For the electrical equipment installed in the EMC, directive states that the equipment must not disturb the environment and must be immune to other electromagnetic disturbances in the environment. **Table 3** indicates the requirements for the control wiring to meet this directive.

Table 3. Control wiring requirements

Item	Directive
Product	IEC 61800-2
Safety	UL 508C, IEC / EN 61800-5-1
EMC (at default settings)	Immunity: EN / IEC 61800-3, 2nd environment
	Radiated emissions: EN / IEC 61800-3 (Transient Testing included), 1st environment
	Conducted emissions: EN / IEC 61800-3
	Category C1: is possible with external filter connected to drive. Please consult factory
	Category C2: with internal filter maximum of 10m motor cable length (FR0: This is obtained with 2 turns on a ferrite core and using metal ground plate)
	Category C3: with internal filter maximum of 50m motor cable length (FR0: This is obtained with no ferrite core and metal plate)

Control cable grounding

It is recommended that the shielded cables be grounded as shown in **Figure 6**. Strip the cable insulation required allowing attachment to the frame with the grounding clamp.

Figure 5. Control cable grounding




Table 4. Variable Speed Drive Series III—option boards





Table 5. Variable Speed Drive Series III protocols

Protocols	VS3	On Board/Option Module
Modbus RTU	■	On Board
BACnet MSTP	■	On Board
Modbus TCP	■	On Board
PROFIBUS	■	Option Module
BACnet IP	■	On Board

Modbus RTU On-Board Communications

The drive product can be controlled via Modbus® RTU through the on-board RS-485 terminals.

Figure 6. Connection diagram



The figure shows a typical arrangement with a host computer (master) and any number maximum 31 subordinate of frequency inverters. Each frequency inverter has a unique address in the network. This addressing is executed individually for each VFD via the communication parameters.

The electrical connection between master and the subordinates connected in parallel are implemented via the serial interface A-B (A = positive, B = negative) with a shielded RS-485 twisted pair cable.

Modbus RTU specifications

Communication board connections

Table 6. Connections

Item	Description
Interface	
Data Transfer Method	RS-485, half-duplex
Transfer Cable	Twisted pair (1 pair and shield)
Electrical Isolation	

Communications

Table 7. Communications

Item	Description
Modbus RTU	As described in "Modicon Modbus Protocol Reference Guide" found at http://public.modicon.com/
Baud Rate	9600,19200,38400,57600,115200
Addresses	1 to 247

Connections

The RS-485 communication port is connected via the A and B terminals on the drives control board.

Figure 7. Terminal wiring





Figure 8. Termination resistor and shielding




Commissioning

RS-485 communication parameters

To commission the RS-485 communication board, enter the Keypad menu as described below.

Change the Modbus RTU commissioning parameter values.

Figure 9. VS3 keypad navigation to RS-485 menu



In this menu you will be able to scroll through the below settings to setup the communication protocol.

Table 8. Modbus RTU

VS3 code	Parameter	Min.	Max.	Unit	Default	ID	Note
P12.3.1.1	RS485 comm set				0	586	0 = Modbus RTU 1 = BACnet® MS/TP 2 = SA Bus
P12.3.2.1	Subordinate address	1	247		1	587	
P12.3.2.2	Baud rate				1	584	0 = 9600 1 = 19200 2 = 38400 3 = 57600 4 = 115200
P12.3.2.3	Parity type				2	585	0 = None, 2 Stop Bits 1 = Odd, 1 Stop Bit 2 = Even, 1 Stop Bit
P12.3.2.4	Protocol status				0	588	0 = Initial 1 = Stopped 2 = Operational 3 = Faulted
P12.3.2.5	Subordinate busy				0	589	0 = Not Busy 1 = Busy
P12.3.2.6	Modbus RTU/BACNet Fault Response	0	1		0	2516	0 = In Fieldbus Control 1 = in all Control


The parameters of every device must be set before connecting to the bus. Each parameter must be the same as the master configuration.

Modbus communication standards

The Modbus protocol is an industrial communications and distributed control system to integrate PLCs, computers, terminals, and other monitoring, sensing and control devices. Modbus is a Master-Subordinate communications protocol. The Master controls all serial activity by selectively polling one or more subordinate devices. The protocol provides for one master device and up to 247 subordinate devices on a common line. Each device is assigned an address to distinguish it from all other connected devices. The Modbus protocol uses the master-Subordinate technique, in which only one device (the master) can initiate a transaction. The other devices (the subordinates) respond by supplying the requested data to the master, or by taking the action requested in the query. The master can address individual subordinates or initiate a broadcast message to all subordinates. Subordinates return a message ("response") to queries that are addressed to them individually. Responses are not returned to broadcast queries from the master.

A transaction comprises a single query and single response frame or a single broadcast frame. The transaction frames are defined below.

Figure 10. The basic structure of a modbus frame



Valid subordinate device addresses are in the range of 0–247 decimal. The individual subordinate devices are assigned addresses in the range of 1–247. A master addresses a subordinate by placing the subordinate address in the address field of the message. When the subordinate sends its response, it places its own address in this address field of the response to let the master know which subordinate is responding.

The function code field of a message frame contains two characters (ASCII) or eight bits (RTU). Valid codes are in the range of 1–255 decimal. When a message is sent from a master to a subordinate device, the function code field tells the subordinate what kind of action to perform.

Examples are to read the ON/OFF states of a group of discrete coils or inputs; to read the data contents of a group of registers; to read the diagnostic status of the subordinate; to write to designated coils or registers; or to allow loading, recording or verifying the program within the subordinate.

When the subordinate responds to the master, it uses the function code field to indicate either a normal (error-free) response or that some kind of error occurred (called an exception response). For a normal response, the subordinate simply echoes the original function code. For an exception response, the subordinate returns a code that is equivalent to the original function code with its most significant bit set to a logic state of 1.

The data field is constructed using sets of two hexadecimal digits, in the range of 00 to FF hexadecimal. These can be made from a pair of ASCII characters, or from one RTU character, according to the network's serial transmission mode.

The data field of messages sent from a master to subordinate devices contains additional information that the subordinate must use to take the action defined by the function code. This can include items like discrete and register addresses, the quantity of items to be handled, and the count of actual data bytes in the field.

If no error occurs, the data field of a response from a subordinate to a master contains the data requested. If an error occurs, the field contains an exception code that the master application can use to determine the next action to be taken.

Two kinds of checksum are used for standard Modbus networks. The error checking field contents depend upon the transmission method that is being used.

Supported functions

Table 9. Functions

Function code	Description
0x01	Read coils
0x02	Read discrete inputs
0x03	Read holding registers
0x04	Read input registers
0x05	Write single coil
0x06	Write single register
0x07	Read exception status
0x08	Read diagnostics (Only support 0x00 return query data)
0x0F	Write multiple coils
0x10	Write multiple registers
0x17	Read/write multiple registers
0x2B/0x0E	Read device identity

Note: Note: Broadcasting can be used with codes 0x05, 0x06, 0x0F and 0x10.

Example of the request to read coils 2000–2003 from subordinate device 18.

Table 10. Request to read coils

Item	Code	Description
Subordinate address	0x12	
Function code	0x01	
Start address High	0x07	Starting address 0x07D0 hex (= 2000)
Start address Low	0xD0	
Number of coils High	0x00	Number of coils 0x0003 hex (= 3)
Number of coils Low	0x03	
CRC High	0x7E	
CRC Low	0x25	

Example of the request to read Discrete Inputs 2000–2003 from Subordinate device 18.

Table 11. Request to read discrete inputs

Item	Code	Description
Subordinate address	0x12	
Function code	0x02	
Start address High	0x07	Starting address 0x07D0 hex (= 2000)
Start address Low	0xD0	
Number of Discrete Inputs High	0x00	Number of Discrete Inputs 0x0003 hex (= 3)
Number of Discrete Inputs Low	0x03	
CRC High	0x3A	
CRC Low	0x25	

Example of the request to read Holding Registers 2000–2003 from Subordinate device 18.

Table 12. Request to read holding registers

Item	Code	Description
Subordinate address	0x12	
Function code	0x03	
Start address High	0x07	Starting address 0x07D0 hex (= 2000)
Start address Low	0xD0	
Number of Holding Registers High	0x00	Number of Holding Registers 0x0003 hex (= 3)
Number of Holding Registers Low	0x03	
CRC High	0x07	
CRC Low	0xE5	

Example of the request to read Input Registers 2000–2003 from Subordinate device 18.

Table 13. Request to read input registers

Item	Code	Description
Subordinate address	0x12	
Function code	0x04	
Start address High	0x07	Starting address 0x07D0 hex (= 2000)
Start address Low	0xD0	
Number of Input Registers High	0x00	Number of Input Registers 0x0003 hex (= 3)
Number of Input Registers Low	0x03	
CRC High	0xB2	
CRC Low	0x25	

Example of the request to read exception status from Subordinate device 18.

Table 14. Request to read exception status

Item	Code	Description
Subordinate address	0x12	
Function code	0x07	
CRC High	4C	
CRC Low	D2	

Example of Read Diagnostics from Subordinate address 18.

Table 15. Read diagnostics

Item	Code	Description
Subordinate address	0x12	
Function code	0x08	
Sub function High	0x00	Sub function code 0x0000 (= 0)
Sub function Low	0x00	Note. Only support sub function code 0x0000
Data High	0xA5	Data 0xA5A5 (= 42405)
Data Low	0xA5	
CRC High	0x59	
CRC Low	0x83	

Example of the request to write single coil 2000 from subordinate device 18, the output value is 65280.

Table 16. Request to write single coil

Item	Code	Description
Subordinate address	0x12	
Function code	0x05	
Output address High	0x07	Starting address 0x07D0 hex (= 2000)
Output address Low	0xD0	
Output value High	0xFF	Output value 0xFF00 hex (= 65280)
Output value Low	0x00	Note. Output value is 0x0000 or 0xFF00
CRC High	0x8E	
CRC Low	0x14	

Example of the request to write single register 2000 from Subordinate device 18, the output value is 5.

Table 17. Request to write single register

Item	Code	Description
Subordinate address	0x12	
Function code	0x06	
Output address High	0x07	Starting address 0x07D0 hex (= 2000)
Output address Low	0xD0	
Output value High	0x00	Output value 0x0005 hex (= 5)
Output value Low	0x05	
CRC High	0x4B	
CRC Low	0xE7	

Example of Write coils 19–28 from Subordinate device 18.

Table 18. Write coils 19–28

Item	Code	Description
Subordinate Address	0x12	
Function code	0x0F	
Starting Address High	0x00	Starting Address 0x0013 (= 19)
Starting Address Low	0x13	
Quantity of Outputs High	0x00	Quantity of Outputs 0x000A (= 10)
Quantity of Outputs Low	0x0A	
Bye Count	0x02	
Outputs Value High	0xCD	
Outputs Value Low	0x01	
CRC High	0xAB	
CRC Low	0xFB	

Note: The binary outputs in the previous example correspond to the outputs in the following way.

Binary bits and corresponding outputs

Bit	1	1	0	0	1	1	0	1	0	0	0	0	0	0	1
Output	26	25	24	23	22	21	20	19	—	—	—	—	—	28	27

Example of write Holding registers 2000-2001 from subordinate device 18.

Table 19. Request to write holding registers

Item	Code	Description
Subordinate Address	0x12	
Function code	0x10	
Starting Address High	0x07	Starting Address 0x07D0 (= 2000)
Starting Address Low	0xD0	
Quantity of Outputs High	0x00	Quantity of Outputs 0x0002 (= 2)
Quantity of Outputs Low	0x02	
Bye Count	0x04	
Outputs Value High	0x00	
Outputs Value Low	0x01	
Outputs Value High	0x00	
Outputs Value Low	0x02	
CRC High	0x53	
CRC Low	0x46	

Modbus registers

The variables and fault codes as well as the parameters can be read and written from Modbus. The parameter addresses are determined in the application. Every parameter and actual value have been given an ID number in the application. The ID numbering of the parameter as well as the parameter ranges and steps can be found in the application manual in question. The parameter value shall be given without decimals.

All values can be read with function codes 3 and 4 (all registers are 3X and 4X reference). Modbus registers are mapped to drive IDs as follows.

Table 20. Index table

ID	Modbus register	Group	R/W
1–98	40001–40098 (30001–30098)	Actual Values	1/1
100	40099 (30099)	Fault Code	1/1
101–1999	40101–41999 (30101–31999)	Parameters	1/1
2004–2011	42004–42011 (32004–32011)	Process Data In	1/1
2104–2111	42104–42111 (32104–32111)	Process Data Out	1/1

Process data

The process data fields are used to control the drive (e.g., Run, Stop, Reference, Fault Reset) and to quickly read actual values (e.g., Output frequency, Output current, Fault code). The fields are structured as follows.

Table 21. Process data subordinate → master (max. 22 bytes)

ID	Modbus register	Group	Range/Type
2101	32101, 42101	FB Status Word	Binary coded
2102	32102, 42102	FB General Status Word	Binary coded
2103	32103, 42103	FB Actual Speed	0–100.00%
2104	32104, 42104	FB Process Data Out 1	
2105	32105, 42105	FB Process Data Out 2	
2106	32106, 42106	FB Process Data Out 3	
2107	32107, 42107	FB Process Data Out 4	
2108	32108, 42108	FB Process Data Out 5	
2109	32109, 42109	FB Process Data Out 6	
2110	32110, 42110	FB Process Data Out 7	
2111	32111, 42111	FB Process Data Out 8	

Table 22. Process data master → subordinate (max. 22 bytes)

ID	Modbus register	Group	Range/Type
2001	32001, 42001	FB Control Word	Binary coded
2002	32002, 42002	FB General Control Word	Binary coded
2003	32003, 42003	FB Speed Reference	0–100.00% Hz
2004	32004, 42004	FB Process Data In 1	Integer 16
2005	32005, 42005	FB Process Data In 2	Integer 16
2006	32006, 42006	FB Process Data In 3	Integer 16
2007	32007, 42007	FB Process Data In 4	Integer 16
2008	32008, 42008	FB Process Data In 5	Integer 16
2009	32009, 42009	FB Process Data In 6	Integer 16
2010	32010, 42010	FB Process Data In 7	Integer 16
2011	32011, 42011	FB Process Data In 8	Integer 16

The use of process data depends on the application. In a typical situation, the device is started and stopped with the Control Word (CW) written by the Master and the Rotating speed is set with Reference (REF). With PD1–PD8 the device can be given other reference values (e.g., Torque reference). With the Status Word (SW) read by the Master, the status of the device can be seen. Actual Value (ACT) and PD1–PD8 show the other actual values.

Process data in

This register range is reserved for the control of the VFD. Process Data In is located in range ID 2001–2099. The registers are updated every 10 ms. See table below.

Table 23. Fieldbus basic input table

ID	Modbus register	Group	Range/Type	ID	Modbus register	Group	Range/Type
2001	32001, 42001	FB Control Word	Binary coded	2007	32007, 42007	FB Process Data In 4	Integer 16
2002	32002, 42002	FB General Control Word	Binary coded	2008	32008, 42008	FB Process Data In 5	Integer 16
2003	32003, 42003	FB Speed Reference	0–100.00%	2009	32009, 42009	FB Process Data In 6	Integer 16
2004	32004, 42004	FB Process Data In 1	Integer 16	2010	32010, 42010	FB Process Data In 7	Integer 16
2005	32005, 42005	FB Process Data In 2	Integer 16	2011	32011, 42011	FB Process Data In 8	Integer 16
2006	32006, 42006	FB Process Data In 3	Integer 16				

Note: For FB Process Data In, see section below on Process Data IN.

Control word

The drive uses 16 bits as shown below. These bits are application specific.

Binary bits and corresponding outputs

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
①	①	①	①	①	①	FB Ref	FB Ctrl	Bypass	FB DI 4	FB DI 3	FB DI 2	FB DI 1	Fault Reset	Reverse	RUN

Note:

① The bit is not used.

Table 24. FB control word

Bit	Description Value = 0	Value = 1
0	Drive Output Off	Drive Output On
1	Clockwise Rotation	Counter Clockwise
2	No Reset	Fault Reset
3	FB INDATA1 Off	FB INDATA1 On
4	FB INDATA2 Off	FB INDATA2 On
5	FB INDATA3 Off	FB INDATA3 On
6	FB INDATA4 Off	FB INDATA4 On
7	Bypass Relay Disable	Bypass Relay Enable
8	FB Control Off	FB Control On
9	FB Reference Off	FB Reference On
10–15	Not in use	Not in use

The scaling on this value is 0–100.00% of the Maximum Frequency. The 0 to 100.00% is represented by 0 to 10,000 value indicating 0 or 0% as Minimum Frequency and 10,000 or %100.00 as Maximum Frequency. This value has 2 decimal places in it.

Process data in 1 to 8

Process Data In values 1 to 8 can be used in applications for various purposes. See Process Data IN section for setup.

FB General Control Word

The Variable Speed Drive Series III does not use the FB General Control Word. The main control word is used to provide commands to the drive.

Speed reference

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
MSB	—	—	—	—	—	—	—	—	—	—	—	—	—	—	LSB

This is the Reference 1 to the VFD. Used normally as Speed reference.

Process data out

This register range is normally used to fast monitoring of the VFD. Process Data Out is located in range ID 2101–2199. See table below.

Table 25. Fieldbus basic output table

ID	Modbus Register	Group	Range/Type
2101	32101, 42101	FB Status Word	Binary coded
2102	32102, 42102	FB General Status Word	Binary coded
2103	32103, 42103	FB Actual Speed	%
2104	32104, 42104	FB Process Data Out 1	
2105	32105, 42105	FB Process Data Out 2	
2106	32106, 42106	FB Process Data Out 3	
2107	32107, 42107	FB Process Data Out 4	
2108	32108, 42108	FB Process Data Out 5	
2109	32109, 42109	FB Process Data Out 6	
2110	32110, 42110	FB Process Data Out 7	
2111	32111, 42111	FB Process Data Out 8	

FB Status Word

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	—	—	—	Direction	Fault	Direction	Running	Ready

Information about the status of the device and messages is indicated in the FB Status Word. The FB Status Word is composed of 16 bits that have the following meanings.

Table 26. FB Status Word Bit Descriptions

Bit	Description Value = 0	Value = 1
0	Not Ready	Ready
1	STOP	RUN
2	Clockwise	Counterclockwise
3	—	Faulted
4	—	Warning
5	Ref. frequency not reached	Ref. frequency reached
6	Bypass not activated	Bypass activated
7	Run disable	Run Enable
8	Not in use	Not in use
9–15	Not in use	Not In use

Table 27. FB general status word

Bit	Description Value = 0	Value = 1
0	Not Ready	Ready
1	Stop	Run
2	Clockwise	Counter Clockwise
3	No Fault	Fault
4	No Warning	Warning
5	Ref. Frequency Not Reached	Ref. Frequency Reached
6	Ref > 0 Speed	Ref = 0 speed
7	Motor Flux Off	Motor Flux On ①
8	Motor Speed Limit On	Motor Speed Limit Off ①
9	Encoder Direction Off	Encoder Direction On ①
10	Under Voltage Fast Stop Off	Under Voltage Fast Stop On ①
11	DC Brake Off	DC Brake On
12	FB Ref Not Enable	FB Ref Enabled
13	Motor Start Delay Off	Motor Start Delay On
14	Remote Not Enable	Remote Enable
15	FB WD Pulse Not Enabled	FB WD Pulse Enable ①

Note:

① The bit is not used.

Speed reference

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
MSB	—	—	—	—	—	—	—	—	—	—	—	—	—	—	LSB

This is the Actual Speed of the motor. This value comes back in the form of %.

Process data out 1 to 8

Process Data Out values 1 to 8 can be used in application for various purposes. See below tables for additional information.

Process data OUT (subordinate -> master)

The fieldbus master can read the VFD actual values using process data variables. The applications use process data as follows. These values are selectable via the Fieldbus Process Data parameter group. These values would correspond to the Modbus ID value. See **Appendix A** for Parameter ID table showing values can be set.

Table 28. Process data OUT

Id	Data	Value	Default value	Default para	Unit	Scale
2104	Process Data OUT 1	-32768–32767	1	Output Frequency	Hz	
2105	Process Data OUT 2	-32768–32767	2	Motor Speed	RPM	
2106	Process Data OUT 3	-32768–32767	3	Motor Current	A	
2107	Process Data OUT 4	-32768–32767	4	Motor Torque	%	
2108	Process Data OUT 5	-32768–32767	5	Motor Power	%	
2109	Process Data OUT 6	-32768–32767	6	Motor Voltage	V	
2110	Process Data OUT 7	-32768–32767	7	DC Link Voltage	V	
2111	Process Data OUT 8	-32768–32767	28	Latest Fault Code	—	

Process data IN (master → subordinate)

Control Word, Reference and Process Data are used with All-in-One applications as follows.

Table 29. Process data IN

ID	Data	Value	Unit	Scale
2003	Reference	Speed Reference	Hz	0.01
2001	Control Word	—	—	—
2004	Process Data IN1	①	%	0.01%
2005	Process Data IN2	①	%	0.01%
2006	Process Data IN3	①	%	0.01%
2007	Process Data IN4	①	%	0.01%
2008	Process Data IN5	①	%	0.01%
2009	Process Data IN6	①	%	0.01%
2010	Process Data IN7	①	%	0.01%
2011	Process Data IN8	①	%	0.01%

Note:

① Process Data IN1 through Process Data IN8 change based off the selected application. See **Appendix B** for layout.

Startup test

Select Fieldbus (Bus/Comm) as the active control and reference place.

1. Set FB control word (Modbus Address 42001) value to 301hex
2. The drive status is RUN
3. Set FB Speed reference (Modbus Address 42003) value to 5000 (= 50.00%)
4. The Actual value is 5000 and the output frequency is 50.00%
5. Set FB control word (Modbus Address 42001) value to 300hex
6. The drive status is STOP

Modbus TCP On-Board communications

Modbus/TCP specifications

Table 30. Modbus/TCP technical data

General	Description	Specification
Ethernet connections	Interface	RJ-45 connector
Communications	Transfer cable	Shielded twisted pair
	Speed	10/100 Mb
	Duplex	Half/full
	Default IP-address Mode	DHCP with Auto-IP
Default static IP configurations	Default static IP address	192.168.1.254
	Default Network Mask	255.255.255.0
	Default Gateway Address	192.168.1.1

Modbus/TCP protocol

Modbus/TCP is a variant of the Modbus family. It is a manufacturer-independent protocol for monitoring and controlling automatic devices. Modbus/TCP is a client-server protocol. The client makes queries to the server by sending "request" messages to the server's TCP port 502. The server answers client queries with "response" messages. The term "client" can refer to a master device that runs queries. Correspondingly, the term "server" refers to a subordinate device that serves the master device by answering its queries. Both the request and the response messages are composed as follows.


- Byte 0. Transaction ID High
- Byte 1. Transaction ID Low
- Byte 2. Protocol ID High
- Byte 3. Protocol ID Low
- Byte 4. Length field High
- Byte 5. Length field Low
- Byte 6. Unit identifier
- Byte 7. Modbus function code
- Byte 8. Data (of variable length)

Modbus/TCP vs. Modbus RTU

Compared to the Modbus RTU protocol, the Modbus/TCP differs mostly in error checking and subordinate addresses. As the TCP already includes an efficient error checking function, the Modbus/TCP protocol does not include a separate CRC field. In addition to the error checking functionality, the TCP is responsible for resending packets and for splitting long messages so that they fit the TCP frames. The subordinate address field of the Modbus/RTU is named as the unit identifier field in Modbus/TCP, and it is only used when one IP address stands for several endpoints.

Hardware specifications

Ethernet port LED indications



Ethernet LED

1. Ethernet Link Status
2. Ethernet Link Speed

Table 31. Ethernet LED description


LED	Meaning
Ethernet link status	Flashes with Ethernet message activity.
Ethernet link speed	Displays the link speed. Yellow LED on the Ethernet Jack is ON when link speed is 100 mbps Yellow LED on the Ethernet Jack is OFF when link speed is 10 mbps

Ethernet LED indications at power up

When the drive is powered up, an indicator test will be performed. To allow a visual inspection, the following sequence will be performed.

1. Turn first indicator Green, all other indicators off
2. Leave first indicator on Green for approximately 0.25 second
3. Turn first indicator on Red for approximately 0.25 second
4. Turn first indicator on Green
5. Turn second indicator (if present) on Green for approximately 0.25 second
6. Turn second indicator (if present) on Red for approximately 0.25 second
7. Turn second indicator (if present) Off

If other indicators are present, test each indicator in sequence as prescribed by the second indicator above. If a Module Status indicator is present, it will be the first indicator in the sequence, followed by any Network Status indicators present. After completion of this power up test, the indicator(s) will turn to a normal operational state.

Figure 11. Module and network status

Module status indications

Represents the state of the drive.

Table 32. Module status LED description

Indicator state	Summary	Meaning
Steady Off	No power	No power is supplied to the device.
Steady Green	Device operational	Device is operating correctly.
Flashing Green ①	Standby	Device has not been configured.
Flashing Red ①	Minor fault	Device has detected a recoverable minor fault. Note. An incorrect or inconsistent configuration would be considered a minor fault. Also check that on clearing the fault, it turns off.
Steady Red	Major fault	Device has detected a non-recoverable major fault.
Flashing Green/Red ①	Self-test	Device is performing its power up testing.

① Flash rate is 1 flash per second.

Network status indications

Represents the state of the Ethernet port network interface.

Table 33. Network status LED description

Indicator state	Summary	Meaning
Steady Off	Not powered, no IP address	Device is powered off, or is powered on but with no IP address configured (Interface Configuration attribute of the TCP/IP Interface Object).
Flashing Green ①	No connections	An IP address is configured, but no CIP connections are established, and an Exclusive Owner connection has not timed out.
Steady Green	Connected	At least one CIP connection (any transport class) is established, and an Exclusive Owner connection has not timed out.
Flashing Red ①	Connection timeout	Device is powered on and an exclusive Owner connection has timed out. It returns to steady green only when all timed out Exclusive Owner connections are established.
Steady Red	Major fault	Device has detected a non-recoverable major fault.
Flashing Green/Red ①	Self-test	Device is performing its power up testing.

① Flash rate is 1 flash per second.

Commissioning

Connections and wiring

The Ethernet port supports 10/100 Mb speeds in both full and half-duplex modes. The boards must be connected to the Ethernet network with a shielded CAT-5e cable. A crossover cable (at least CAT-5e cable with STP, shielded twisted pair) may be needed if you want to connect the EtherNet/IP board directly to the master appliance.

Use only industrial standard components in the network and avoid complex structures to minimize the length of response time and the amount of incorrect dispatches. It is often a good practice to use a subnet that is different from other devices not related to the drive control.

Figure 12. CAT-5e cable





Figure 13. VS3 keypad navigation to ethernet comm settings



In this menu you will be able to scroll through the below settings to setup the communication protocol.

Table 34. EtherNet/IP / Modbus TCP

VS3 code	Parameter	Min.	Max.	Unit	Default	ID	Note
P12.4.1.1	IP Address Mode				1	1500	0 = Static IP 1 = DHCP with AutoIP
P12.4.1.2	Active IP Address					1507	
P12.4.1.3	Active Subnet Mask					1509	
P12.4.1.4	Active Default Gateway					1511	
P12.4.1.5	MAC Address					1513	
P12.4.1.6	Static IP Address				192.168.1.254	1501	
P12.4.1.7	Static Subnet Mask				255.255.255.0	1503	
P12.4.1.8	Static Default Gateway				192.168.1.1	1505	
P12.4.1.9	Enable BACnet IP	0	1		0	1725	0 = Disable 1 = Enable
P12.4.2.1	Connection Limit	0	5		5	609	
P12.4.2.2	Modbus TCP Unit ID				1	610	
P12.4.2.3	Comm Timeout Modbus TCP			ms	10000	611	
P12.4.2.4	Protocol Status				0	612	0 = Stopped 1 = Operational 2 = Faulted
P12.4.2.5	Modbus TCP Fault Response	0	1		0	2517	0 = In Fieldbus Control 1 = In all Control

DHCP

The EtherNet/IP communication supports DHCP for easier network configuration. Dynamic Host Configuration Protocol (DHCP) is a network protocol that is used to configure network devices so that they can communicate on an IP network. As a DHCP client, the EtherNet/IP negotiates with the DHCP server to determine its IP address and obtain any other initial configuration details it needs for network operation.

IP address

IP is divided into four parts. (Part = Octet) Default Static IP Address is 192.168.1.254

Communication timeout

Defines how much time can pass from the last received message from the client device before fieldbus fault is generated. Default communication timeout is 10 seconds.

Note: If the network cable is broken from the EtherNet/IP port, a fieldbus error is generated immediately.

Static IP address

In most cases the user may want to establish a Static IP Address for the EtherNet/IP based on their network configuration.

Static IP address default configurations are as defined in "EtherNet/IP network settings" table, provided in "Connections and Wiring" section.

The user can manually define the network address for the EtherNet/IP as long as all units connected to the network are given the same network portion of the address. In these situations, the user will need to manually set the IP Address in the device by using the drive keypad. Be aware that overlapping IP addresses can cause conflicts between devices on the network. For more information about selecting IP addresses, contact your network administrator.

Unit identifier

The Unit Identifier used in Modbus TCP is used for the Modbus protocol in place of the subordinate address used in Modbus RTU. This Unit Identifier is used to communicate via devices such as bridges, routers and gateways that use a single IP address to support multiple independent Modbus end units.

Manual IP address configuration

Using the Variable Speed Drive Series III keypad

Using the Drive Keypad to set the IP Address manually in the device.


1. Select IP addressing mode as Static IP. Static IP mode configurations will be loaded.

Note: Change in IP address mode will require drive to power cycle to get this change effective. Also ensure device MAC address.

Figure 14. VS3 Static IP mode



Figure 15. VS3 Static IP address



2. Using the drive keypad, set the IP address in the device to the desired address setting by.
 - a. Setting Static IP Address
 - b. Setting Static Subnet Mask
 - c. Setting Static Default Gateway
 - d. Setting Modbus TCP Unit ID
3. Make note of the changed IP Address.
4. Using drive keypad, read "Active IP Address," "Active Subnet Mask," "Active Default Gateway" parameters to ensure that IP address has been set to desired IP address.

Modbus communication standards

Example of the request to read coils 2000–2003 from Subordinate device 18.

Table 35. Request to read coils

Item	Code	Description
Subordinate address	0x12	
Function code	0x01	
Start address High	0x07	Starting address 0x07D0 hex (= 2000)
Start address Low	0xD0	
Number of coils High	0x00	Number of coils 0x0003 hex (= 3)
Number of coils Low	0x03	
CRC High	0x7E	
CRC Low	0x25	

Example of the request to read Discrete Inputs 2000–2003 from Subordinate device 18.

Table 36. Request to read discrete inputs

Item	Code	Description
Subordinate address	0x12	
Function code	0x02	
Start address High	0x07	Starting address 0x07D0 hex (= 2000)
Start address Low	0xD0	
Number of Discrete Inputs High	0x00	Number of Discrete Inputs 0x0003 hex (= 3)
Number of Discrete Inputs Low	0x03	
CRC High	0x3A	
CRC Low	0x25	

Example of the request to read Holding Registers 2000–2003 from Subordinate device 18.

Table 37. Request to read holding registers

Item	Code	Description
Subordinate address	0x12	
Function code	0x03	
Start address High	0x07	Starting address 0x07D0 hex (= 2000)
Start address Low	0xD0	
Number of Holding Registers High	0x00	Number of Holding Registers 0x0003 hex (= 3)
Number of Holding Registers Low	0x03	
CRC High	0x07	
CRC Low	0xE5	

Example of the request to read Input Registers 2000–2003 from Subordinate device 18.

Table 38. Request to read input registers

Item	Code	Description
Subordinate address	0x12	
Function code	0x04	
Start address High	0x07	Starting address 0x07D0 hex (= 2000)
Start address Low	0xD0	
Number of Input Registers High	0x00	Number of Input Registers 0x0003 hex (= 3)
Number of Input Registers Low	0x03	
CRC High	0xB2	
CRC Low	0x25	

Example of the request to read exception status from Subordinate device 18.

Table 39. Request to read exception status

Item	Code	Description
Subordinate address	0x12	
Function code	0x07	
CRC High	4C	
CRC Low	D2	

Example of Read Diagnostics from Subordinate address 18.

Table 40. Read diagnostics

Item	Code	Description
Subordinate address	0x12	
Function code	0x08	
Sub function High	0x00	Sub function code 0x0000 (= 0)
Sub function Low	0x00	Note. Only support sub function code 0x0000
Data High	0xA5	Data 0xA5A5 (= 42405)
Data Low	0xA5	
CRC High	0x59	
CRC Low	0x83	

Example of the request to write single coil 2000 from Subordinate device 18, the output value is 1.

Table 41. Request to write single coil

Item	Code	Description
Subordinate address	0x12	
Function code	0x05	
Output address High	0x07	Starting address 0x07D0 hex (= 2000)
Output address Low	0xD0	
Output value High	0xFF	Output value 0xFF00 hex (= 65280)
Output value Low	0x00	Note. Output value is 0x0000 or 0xFF00
CRC High	0x8E	
CRC Low	0x14	

Example of the request to write single register 2000 from Subordinate device 18, the output value is 5.

Table 42. Request to write single register

Item	Code	Description
Subordinate address	0x12	
Function code	0x06	
Output address High	0x07	Starting address 0x07D0 hex (= 2000)
Output address Low	0xD0	
Output value High	0x00	Output value 0x0005 hex (= 5)
Output value Low	0x05	
CRC High	0x4B	
CRC Low	0xE7	

Example of Write coils 19–28 from Subordinate device 18.

Table 43. Write coils 19–28

Item	Code	Description
Subordinate Address	0x12	
Function code	0x0F	
Starting Address High	0x00	Starting Address 0x0013 (= 19)
Starting Address Low	0x13	
Quantity of Outputs High	0x00	Quantity of Outputs 0x000A (= 10)
Quantity of Outputs Low	0x0A	
Bye Count	0x02	
Outputs Value High	0xCD	
Outputs Value Low	0x01	
CRC High	0xAB	
CRC Low	0xFB	

Note: The binary outputs in the previous example correspond to the outputs in the following way.

Binary bits and corresponding outputs

Bit	1	1	0	0	1	1	0	1	0	0	0	0	0	0	1
Output	26	25	24	23	22	21	20	19	—	—	—	—	—	28	27

Example of write Holding registers 2000–2001 from Subordinate device 18.

Table 44. Write holding registers

Item	Code	Description
Subordinate Address	0x12	
Function code	0x10	
Starting Address High	0x07	Starting Address 0x07D0 (= 2000)
Starting Address Low	0xD0	
Quantity of Outputs High	0x00	Quantity of Outputs 0x0002 (= 2)
Quantity of Outputs Low	0x02	
Bye Count	0x04	
Outputs Value High	0x00	
Outputs Value Low	0x01	
Outputs Value High	0x00	
Outputs Value Low	0x02	
CRC High	0x53	
CRC Low	0x46	

Modbus registers

The variables and fault codes as well as the parameters can be read and written from Modbus. The parameter addresses are determined in the application. Every parameter and actual value have been given an ID number in the application. The ID numbering of the parameter as well as the parameter ranges and steps can be found in the application manual in question. The parameter value shall be given without decimals.

All values can be read with function codes 3 and 4 (all registers are 3X and 4X reference). Modbus registers are mapped to drive IDs as follows.

Table 45. Index table

ID	Modbus register	Group	R/W
1–98	40001–40098 (30001–30098)	Actual Values	1/1
100	40099 (30099)	Fault Code	1/1
101–1999	40101–41999 (30101–31999)	Parameters	1/1
2004–2011	42004–42011 (32004–32011)	Process Data In	1/1
2104–2111	42104–42111 (32104–32111)	Process Data Out	1/1

Process data

The process data fields are used to control the drive (e.g., Run, Stop, Reference, Fault Reset) and to quickly read actual values (e.g., Output frequency, Output current, Fault code). The fields are structured as follows.

Table 46. Process data subordinate → master (max. 22 bytes)

ID	Modbus register	Group	Range/Type
2101	32101, 42101	FB Status Word	Binary coded
2102	32102, 42102	FB General Status Word	Binary coded
2103	32103, 42103	FB Actual Speed	0–100.00%
2104	32104, 42104	FB Process Data Out 1	
2105	32105, 42105	FB Process Data Out 2	
2106	32106, 42106	FB Process Data Out 3	
2107	32107, 42107	FB Process Data Out 4	
2108	32108, 42108	FB Process Data Out 5	
2109	32109, 42109	FB Process Data Out 6	
2110	32110, 42110	FB Process Data Out 7	
2111	32111, 42111	FB Process Data Out 8	

Table 47. Process data master → subordinate (max. 22 bytes)

ID	Modbus register	Group	Range/Type
2001	32001, 42001	FB Control Word	Binary coded
2002	32002, 42002	FB General Control Word	Binary coded
2003	32003, 42003	FB Speed Reference	0–100.00%
2004	32004, 42004	FB Process Data In 1	Integer 16
2005	32005, 42005	FB Process Data In 2	Integer 16
2006	32006, 42006	FB Process Data In 3	Integer 16
2007	32007, 42007	FB Process Data In 4	Integer 16
2008	32008, 42008	FB Process Data In 5	Integer 16
2009	32009, 42009	FB Process Data In 6	Integer 16
2010	32010, 42010	FB Process Data In 7	Integer 16
2011	32011, 42011	FB Process Data In 8	Integer 16

The use of process data depends on the application. In a typical situation, the device is started and stopped with the ControlWord (CW) written by the Master and the Rotating speed is set with Reference (REF). With PD1–PD8 the device can be given other reference values (e.g., Torque reference). With the StatusWord (SW) read by the Master, the status of the device can be seen. Actual Value (ACT) and PD1–PD8 show the other actual values.

Process data in

This register range is reserved for the control of the VFD. Process Data In is located in range ID 2001–2099. The registers are updated every 10 ms. See table below.

Table 48. Fieldbus basic input table

ID	Modbus register	Group	Range/Type
2001	32001, 42001	FB Control Word	Binary coded
2002	32002, 42002	FB General Control Word	Binary coded
2003	32003, 42003	FB Speed Reference	0–100.00%
2004	32004, 42004	FB Process Data In 1	Integer 16
2005	32005, 42005	FB Process Data In 2	Integer 16
2006	32006, 42006	FB Process Data In 3	Integer 16
2007	32007, 42007	FB Process Data In 4	Integer 16
2008	32008, 42008	FB Process Data In 5	Integer 16
2009	32009, 42009	FB Process Data In 6	Integer 16
2010	32010, 42010	FB Process Data In 7	Integer 16
2011	32011, 42011	FB Process Data In 8	Integer 16

FB control word

The drive uses 16 bits as shown below. These bits are application specific.

Binary bits and corresponding outputs

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
①	①	①	①	①	①	FB Ref	FB Ctrl	BYS	FB DIN 4	FB DIN 3	FB DIN 2	FB DIN 1	F_RST	DIR	RUN

Note:

① The bit is not used.

FB general control word

The drive does not use the FB General Control Word. The main control word is used to provide commands to the drive.

Table 49. FB control word

Bit	Description value = 0	Value = 1
0	Drive Output Off	Drive Output On
1	Clockwise Rotation	Counter Clockwise
2	No Reset	Fault Reset
3	FB INDATA1 Off	FB INDATA1 On
4	FB INDATA2 Off	FB INDATA2 On
5	FB INDATA3 Off	FB INDATA3 On
6	FB INDATA4 Off	FB INDATA4 On
7	Bypass Relay Disable	Bypass Relay Enable
8	FB Control Off	FB Control On
9	FB Reference Off	FB Reference On
10–15	Not in use	Not in use

Speed reference

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
MSB	—	—	—	—	—	—	—	—	—	—	—	—	—	—	LSB

This is the Reference 1 to the VFD. Used normally as Speed reference.

The scaling on this value is 0–100.00% of the Maximum Frequency (P1.2). The 0 to 100.00% is represented by 0 to 10,000 value indicating 0 or 0% as Minimum Frequency (P1.1) and 10,000 or %100.00 as Maximum Frequency (P1.2). This value has 2 decimal places in it.

Process data in 1 to 8

Process Data In values 1 to 8 can be used in applications for various purposes. See below Process Data IN section for setup.

Process data out

This register range is normally used to fast monitoring of the VFD. Process Data Out is located in range ID 2101–2199. See table below.

Table 50. Fieldbus basic output table

ID	Modbus register	Group	Range/Type
2101	32101, 42101	FB Status Word	Binary coded
2102	32102, 42102	FB General Status Word	Binary coded
2103	32103, 42103	FB Actual Speed	%
2104	32104, 42104	FB Process Data Out 1	
2105	32105, 42105	FB Process Data Out 2	
2106	32106, 42106	FB Process Data Out 3	
2107	32107, 42107	FB Process Data Out 4	
2108	32108, 42108	FB Process Data Out 5	
2109	32109, 42109	FB Process Data Out 6	
2110	32110, 42110	FB Process Data Out 7	
2111	32111, 42111	FB Process Data Out 8	

FB status word

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	RUNEN	BYS	AREF	WARN	FLT	DIR	RUN	RDY

Information about the status of the device and messages is indicated in the Status Word. The Status Word is composed of 16 bits that have the following meanings.

Table 51. FB status word bit descriptions

Bit	Description Value = 0	Value = 1
0	Not Ready	Ready
1	STOP	RUN
2	Clockwise	Counterclockwise
3	—	Faulted
4	—	Warning
5	Ref. frequency not reached	Ref. frequency reached
6	Bypass not activated	Bypass activated
7	Run disable	Run Enable
8	Not in use	Not in use
9–15	Not in use	Not In use

Table 52. FB general status word

Bit	Description value = 0	Value = 1
0	Not Ready	Ready
1	Stop	Run
2	Clockwise	Counter Clockwise
3	No Fault	Fault
4	No Warning	Warning
5	Ref. Frequency Not Reached	Ref. Frequency Reached
6	Ref > 0 Speed	Ref = 0 speed
7	Motor Flux Off	Motor Flux On ①
8	Motor Speed Limit On	Motor Speed Limit Off ①
9	Encoder Direction Off	Encoder Direction On ①
10	Under Voltage Fast Stop Off	Under Voltage Fast Stop On ①
11	DC Brake Off	DC Brake On
12	FB Ref Not Enable	FB Ref Enabled
13	Motor Start Delay Off	Motor Start Delay On
14	Remote Not Enable	Remote Enable
15	FB WD Pulse Not Enabled	FB WD Pulse Enable ①

① Indicates the bit is not used.

Actual speed

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
MSB	—	—	—	—	—	—	—	—	—	—	—	—	—	—	LSB

This is the Actual Speed of the motor. This value comes back in the form of %

Process data out 1 to 8

Process Data Out values 1 to 8 can be used in application for various purposes. See below tables for additional information.

Process data OUT (subordinate → master)

The fieldbus master can read the VFD's actual values using process data variables. Variable Speed Drive Series III applications use process data as follows. These values are selectable via the Fieldbus Process Data parameter group. These values would correspond to the Modbus ID value. See **Appendix A** for Parameter ID table showing values can be set.

Table 53. Process data OUT

ID	Data	Value	Default value	Default para	Unit	Scale
2104	Process Data OUT 1	-32768–32767	1	Output Frequency	Hz	
2105	Process Data OUT 2	-32768–32767	2	Motor Speed	RPM	
2106	Process Data OUT 3	-32768–32767	3	Motor Current	A	
2107	Process Data OUT 4	-32768–32767	4	Motor Torque	%	
2108	Process Data OUT 5	-32768–32767	5	Motor Power	%	
2109	Process Data OUT 6	-32768–32767	6	Motor Voltage	V	
2110	Process Data OUT 7	-32768–32767	7	DC Link Voltage	V	
2111	Process Data OUT 8	-32768–32767	28	Latest Fault Code	—	

Process data IN (master → subordinate)

Control Word, Reference and Process Data are used with All-in-One applications as follows.

Table 54. Process data IN

ID	Data	Value	Unit	Scale
2003	Reference	Speed Reference	%	0.01
2001	Control Word	—	—	—
2004	Process Data IN1	①	%	0.01%
2005	Process Data IN2	①	%	0.01%
2006	Process Data IN3	①	%	0.01%
2007	Process Data IN4	①	%	0.01%
2008	Process Data IN5	①	%	0.01%
2009	Process Data IN6	①	%	0.01%
2010	Process Data IN7	①	%	0.01%
2011	Process Data IN8	①	%	0.01%

① Process Data IN1 through Process Data IN8 change based off the selected application. See **Appendix B** for layout.

BACnet MS/TP—On-Board Communication

BACnet stands for Building Automation and Control Networks. It is the common name for the communication standard ISO 16484-5 which defines the methods and the protocol for cooperating building automation devices to communicate. Devices can be designed to operate using BACnet communication protocol as well as utilizing BACnet protocol to communicate between systems. BACnet is an internationally accepted protocol for building automation (such as lightning control, air conditioning and heating automation) and control over a communications network. BACnet provides a method by which computer-based control equipment, from different manufacturers can work together, or “interoperate.” For this to be achieved, components must be able to exchange and understand BACnet data messages. Your drive is equipped with BACnet support as standard.

BACnet MS/TP specifications


Table 55. BACnet MS/TP technical data

Item	Description
Interface	RS-485
Data transfer method	RS-485, half-duplex
Transfer cable	STP (Shielded Twisted Pair), type Belden or similar
Connection: Electrical isolation	Communication: Functional
Connection: BACnet MS/TP	Communication: As described in ANSI/ASHRAE Standards 135-2004
Connection: Baud rate	Communication: 9600, 19200, 38400, 76800, 115200

BACnet MS/TP connections

The control board is located inside the control unit of the drive.

Figure 16. Principal example diagram



Prepare for use through MS/TP


1. Open the cover of the AC drive.

WARNING

The relay outputs and other I/O-terminals may have a dangerous control voltage present even when drive is disconnected from mains.

2. Locate the components that you will need on the drive to connect and run the BACnet cables.
3. Strip about 0.59 in (15 mm) of the RS-485 cable and cut off the grey cable shield. Remember to do this for both bus cables (except for the last device). Leave no more than 0.39 in (10 mm) of the cable outside the terminal block and strip the cables at about 0.20 in (5 mm) to fit in the terminals. See illustration below.

Figure 17. Stripping the cable




Also strip the cable now at such a distance from the terminal that you can fix it to the frame with the grounding clamp. Strip the cable at a maximum length of 0.59 in (15 mm).

IMPORTANT


Do not strip the aluminum cable shield!

Figure 18. RS-485 Cable strip (Aluminum Shield)




4. Then connect the cable to its appropriate terminals on the drive standard terminal block, terminals A and B (A = positive, B = negative). See illustration below.

Figure 19. Drive terminals (BACnet)



5. Using the cable clamp included in the delivery of the drive, ground the shield of the RS-485 cable to the frame of the AC drive.

Figure 20. Serial ground




6. If the drive is the last device on the bus, the bus termination must be set. Locate the DIP switches to the right of the keypad of the drive and turn the switch for the RS-485 bus termination resistor to position ON. Biasing is built in the termination resistor. See also step 8 below.

Figure 21. RS-485 Bus termination setup



BACnet MS/TP bus termination

Figure 22. BACnet bus termination



7. Remount the AC drive cover.

Note: When planning the cable runs, remember to keep the distance between the fieldbus cable and the motor cable at a minimum of 11.81 in (30 cm).


8. The bus termination must be set for the first and last device of the fieldbus line. See illustration below. See also step 6 above. We recommend that the first device on the bus terminated is the Master device.

Commissioning

BACnet programming

The navigation path to the fieldbus parameters may differ from application to application. The exemplary paths below apply to the drive.

Figure 23. VS3 BACnet MSTP parameter navigation



1. First ensure that the right fieldbus protocol is selected.

Navigate:

Main Menu → Parameter → Communication → RS485 Bus → RS-485 Comm Set → Edit →
(Choose Protocol as BACnet MS/TP)

BACnet MS/TP Parameters and monitoring values

Table 56. BACnet MS/TP Parameter Table

VS3 code	Parameter	Min.	Max.	Unit	Default	ID	Note
P12.3.1.1	RS485 Comm Set				0	586	0 = Modbus RTU 1 = BACnet MS/TP
P12.3.3.1	BACnet Baud Rate				2	594	0 = 9600 1 = 19200 2 = 38400 3 = 768000 4 = 115200
P12.3.3.2	MAC Address	0	127		1	595	
P12.3.3.3	Instance Number	0	4194302		varies	596	
P12.3.3.4	Comm Timeout BACnet			ms	10000	598	
P12.3.3.5	Protocol Status				0	599	0 = Stopped 1 = Operational 2 = Faulted
P12.3.3.6	Fault Code				0	600	0 = None 1 = Sole Master
P12.3.3.7	Modbus RTU/BACnet Fault Response	0	1		0	2516	0 = In Fieldbus Control 1 = in all Control
P12.3.3.8	Max Master	0	127		127	1537	

BACnet MS/TP parameters

Baud Rate

Select the communication speed for the network. The default value is 38400 baud.

MAC address

The parameters of every device must be set before connecting to the bus. Especially the parameters MAC Address and baud rate must be the same as in the master's configuration. The first parameter, MAC (Medium Access Control) address, must be unique on the network to which it is connected. The same MAC address may be used on a device on another network within the internetwork. Addresses 128–254 are reserved for subordinates. Addresses 1–127 are valid for both masters and subordinates. The portion of the address space that is actually used for masters in a particular installation is determined by the value of the Max_Master property of the device object. It is recommended that MAC address 0 be reserved for the MS/TP router and MAC address 255 is used for broadcasts.

Instance number

The Device Object's Instance number is used in conjunction with the MAC address to assign the devices on the network. The instance number can have up to 127 nodes on it before a different instance number is required.

Communication time-out

BACnet board initiates a communication error if the board is a "sole master" in the network for a time defined with this parameter.

BACnet overview

BACnet technical data

Protocol Implementation Conformance Statement (PICS)

Controller Profile

- B—ASC

Segmentation Capability

- Not supported

Data Link Layer and Routing Options

- MS/TP Master Baud rates (9600, 19200, 38400, 76800, 115200)

Character Sets Supported

- UTF8

BIBBS Supported

- Data Sharing
 - ReadProperty—B
 - WriteProperty—B
- Device Management
 - Dynamic Device Binding—B
 - Dynamic Object Binding—B
 - DeviceCommunicationControl—B
 - ReinitializeDevice—B

- Alarms and Events: Not supported

- Schedules: Not supported

- Trends: Not supported

- Network Management: Not supported

Table 57. Supported object types and properties summary

Property	Device object type	Analog input object type	Analog value object type	Binary value object type	Multiple state value object type
Active_Cov_Subscriptions					
Active_Text				X	
Active_Vt_Sessions					
Alarm_Value					
Alarm_Values					
Align_Intervals					
Apdu_Segment_Timeout					
Apdu_Timeout	X				
Application_Software_Version	X				
Auto_Subordinate_Discovery					
Backup_And_Restore_State					
Backup_Failure_Timeout					
Backup_Preparation_Time					
Change_Of_State_Count					
Change_Of_State_Time					
Configuration_Files					
Cov_Increment					
Database_Revision	X				
Daylight_Savings_Status					
Deadband					
Description	X	X	X	X	X
Device_Address_Binding	X				
Device_Type					
Elapsed_Active_Time					
Event_Algorithm_Inhibit					
Event_Algorithm_Inhibit_Ref					
Event_Detection_Enable					
Event_Enable					
Event_Message_Texts					
Event_Message_Texts_Config					
Event_State		X	X	X	X
Event_Time_Stamps					
Fault_Values					
Firmware_Revision	X				
High_Limit					
Inactive_Text				X	
Interval_Offset					
Last_Restart_Reason					
Last_Restore_Time					
Limit_Enable					
Local_Date					
Local_Time					

Table 57. Supported object types and properties summary, continued

Property	Device object type	Analog input object type	Analog value object type	Binary value object type	Multiple state value object type
Location					
Low_Limit					
Manual_Subordinate_Address_Binding					
Max_Apdu_Length_Accepted	X				
Max_Info_Frames	X				
Max_Master	X				
Max_Pres_Value					
Max_Segments_Accepted					
Min_Pres_Value					
Minimum_Off_Time					
Minimum_On_Time					
Model_Name	X				
Notification_Class					
Notify_Type					
Number_Of_Apdu_Retries	X				
Number_Of_States					X
Object_Identifier	X	X	X	X	X
Object_List	X				
Object_Name	X	X	X	X	X
Object_Type	X	X	X	X	X
Out_Of_Service		X	X	X	X
Password ①	X				
Present_Value		X	X	X	X
Priority_array			X	X	
Profile_Name	X				
Protocol_Object_Types_supported	X				
Protocol_Revision	X				
Protocol_Services_Supported	X				
Protocol_Version	X				
Reliability					
Reliability_Evaluation_Inhibit					
Relinquish_Default			X	X	
Resolution					
Restart_Notification_Recipients					
Restore_Completion_Time					
Restore_Preparation_Time					
Segmentation_Supported	X				

- ① Password is a vendor specific property added to device object with property identifier as 600. Default value of password is empty string; this is a writable property with max length of 20, it always returns ***** on read. Same password will be used for Reinitialize Device Service and Device communication Control service.

Table 57. Supported object types and properties summary, continued

Property	Device object type	Analog input object type	Analog value object type	Binary value object type	Multiple state value object type
Serial_Number	X				
Subordinate_Address_Binding					
Subordinate_Proxy_Enable					
State_Text					X
Status_Flags		X	X	X	X
Structured_Object_list					
System_Status	X				
Time_Delay					
Time_Delay_Normal					
Time_Of_Active_Time-reset					
Time_Of_Device_Restart					
Time_Of_State_Count_Reset					
Time_Synchronization_Interval					
Time_Synchronization_Recipients					
Units		X	X		
Update_Interval					
Utc_Offset					
Utc_Time_Synchronization_Recipients					
Vendor_Identifier	X				
Vendor_Name	X				
Vt_Classes_Supported					

Object instance summary*Binary Value Object Instance Summary*

The following table summarizes the Binary Value Objects supported.

Table 58. Binary value object instance summary

Instance ID	Object name (related To drive parameter)	Description	Inactive/Active text	Preset value access
BV0	Ready State	Indicates whether the drive is ready or not	Not Ready/Ready	R
BV1	Run/Stop State	Indicates whether the drive is running or stopped	Stop/Run	R
BV2	Fwd/Rev State	Indicates the rotation direction of motor	Fwd/Rev	R
BV3	Fault State	Indicates if a fault is active	OK/Fault	R
BV4	Warning State	Indicates if a warning is active	OK/Warning	R
BV5	At Setpoint	Ref. Frequency reached	False/True	R
BV6	At Zero Speed	Motor Running at zero speed	False/True	R
BV7	Motor Ctrl source	Command to change active source for controlling motor	LocalMotorCtrl / FBMotorCtrl	C
BV8	Speed Reference Source	Command to change source of motor speed reference	LocalSpeedRef / FBSpeedRef	C
BV9	Run/Stop CMD	Command to start drive	Stop/Run	C
BV10	Fwd/Rev CMD	Command to change rotational direction	Fwd/Rev	C
BV11	Reset Fault	Command to reset active Fault from drive	0/Reset	C
BV12	Digital Input 1	Digital Input 1	OFF/ON	R
BV13	Digital Input 2	Digital Input 2	OFF/ON	R
BV14	Digital Input 3	Digital Input 3	OFF/ON	R
BV15	Digital Input 4	Digital Input 4	OFF/ON	R
BV16	Digital Input 5	Digital Input 5	OFF/ON	R
BV17	Digital Input 6	Digital Input 6	OFF/ON	R
BV18	Digital Input 7	Digital Input 7	OFF/ON	R
BV19	Digital Input 8	Digital Input 8	OFF/ON	R
BV20	Digital Output 1	Digital Output 1	OFF/ON	R
BV21	Digital Output 2	Relay 1 Output	OFF/ON	R
BV22	Digital Output 3	Relay 2 Output	OFF/ON	R
BV23	Digital Output 4	Relay 3 Output	OFF/ON	R
BV24	Stop By Coast	Indicates if drive stop by coast	ON/OFF	C
BV25	Stop By Ramp	Indicates if drive stop by Ramp	OFF/ON	C
BV26	Belt Broken	Indicates If belt is broken	OFF/ON	R
BV27	Drive Fan Failure	Indicates if Drive Fan failed	OFF/ON	R
BV28	Force Bypass	Command to take Drive in Bypass Mode	OFF/ON	C
BV29	Fire Mode	Enable Fire Mode	OFF/ON	C
BV30	DIN 1	Fieldbus Digital Input	OFF/ON	C
BV31	DIN 2	Fieldbus Digital Input	OFF/ON	C
BV32	DIN 3	Fieldbus Digital Input	OFF/ON	C
BV33	DIN 4	Fieldbus Digital Input	OFF/ON	C

Note: For Present Value Access Types, R = Read-only, W = Writeable, C = Commandable.

Commandable values support priority arrays and relinquish defaults.

Analog value object instance summary

The following table summarizes the Analog Value Objects supported.

Table 59. Analog value object instance summary

Instance ID	Object name	Description	Units	Preset value access
AV0	Speed Reference	Motor speed reference from network	Percent	C
AV1	Current Limit	Current Limit	Amps	W
AV2	Min Frequency	Minimum Frequency	Hz	W
AV3	Maximum Frequency	Maximum Frequency	Hz	W
AV4	Accel Time 1	Acceleration Time	seconds	W
AV5	Decel Time 1	Deceleration Time	seconds	W
AV6	AnyParam ID	Parameter ID number to be accessed	No Units	W
AV7	AnyParam Value	Value of parameter defined by AV6	No Units	W
AV8	Process Data In 1	Fieldbus Process Data In 1	NA	C
AV9	Process Data In 2	Fieldbus Process Data In 2	NA	C
AV10	Process Data In 3	Fieldbus Process Data In 3	NA	C
AV11	Process Data In 4	Fieldbus Process Data In 4	NA	C
AV12	Process Data In 5	Fieldbus Process Data In 5	NA	C
AV13	Process Data In 6	Fieldbus Process Data In 6	NA	C
AV14	Process Data In 7	Fieldbus Process Data In 7	NA	C
AV15	Process Data In 8	Fieldbus Process Data In 8	NA	C

Note: For Present Value Access Types, R = Read-only, W = Writeable, C = Commandable.
Commandable values support priority arrays and relinquish defaults.

Table 60. Analog Input object instance summary

Instance ID	Object name	Description	Units	Preset value access
AI0	Frequency Setpoint	Frequency Setpoint	Hz	R
AI1	Output Frequency	Output Frequency	Hz	R
AI2	Motor Speed	Motor Speed	Rpm	R
AI3	Motor Load	Motor Load	Percent	R
AI4	Kilowatt Hours total	Kilowatt Hour Counter (Total) scaled by 1000	KWh	R
AI5	Motor Current	Motor Current	Amps	R
AI6	DC link Voltage	DC link Voltage	Volts	R
AI7	Motor Voltage	Motor Voltage	Volts	R
AI8	Unit Temperature	Heatsink Temperature	°C	R
AI9	Motor Torque	In % of motor nominal Torque	Percent	R
AI10	Operating Days	Operating Days (resettable)	Day	R
AI11	Operating Hours	Operating Hours (resettable)	Hour	R
AI12	Motor Temperature	Motor Temperature	Percent	R
AI13	Analog Input 1	Analog Input 1	Volts	R
AI14	Analog Input 2	Analog Input 2	Volts	R
AI15	Analog Output 1	Analog Output 1	Volts	R
AI16	Analog Output 2	Analog Output 2	Volts	R
AI17	Kilowatt Instantaneous	Kilowatt Instantaneous	KW	R


Table 60. Analog Input object instance summary, continued

Instance ID	Object name	Description	Units	Preset value access
AI18	Process Data Out 1	Fieldbus Process Data Out 1	NA	R
AI19	Process Data Out 2	Fieldbus Process Data Out 2	NA	R
AI20	Process Data Out 3	Fieldbus Process Data Out 3	NA	R
AI21	Process Data Out 4	Fieldbus Process Data Out 4	NA	R
AI22	Process Data Out 5	Fieldbus Process Data Out 5	NA	R
AI23	Process Data Out 6	Fieldbus Process Data Out 6	NA	R
AI24	Process Data Out 7	Fieldbus Process Data Out 7	NA	R
AI25	Process Data Out 8	Fieldbus Process Data Out 8	NA	R

Note: Line length depends on different transmission speeds.

Table 61. Multi state object instance summary

Instance ID	Object name	Description	State text	Preset value access
MV0	Control mode	Indicates the drive control mode - local, remote or off	0 Local(Hand) / 1 – Remote / 2 - OFF	R
MV1	Active fault code	Indicates the latest active fault code of the drive	State text w.r.t the active fault code	R

Figure 24. Fault tracing

PROFIBUS-DP External Communication Cards

Variable Speed Drive Series III can be connected to the PROFIBUS® DP using an optional PROFIBUS communication card. Variable Speed Drive Series III can be controlled, monitored and programmed from the Host system. The devices are connected in a bus structure. There is a max of 32 stations (master or subordinate) can be connected to one segment bus. The bus is terminated at beginning and end of each segment. To ensure error-free operation, both bus terminations must always be powered, if more than 32 stations are used, repeaters are required.

PROFIBUS specifications

Table 62. PROFIBUS technical data

Items	Value
Terminal	DB9 connector (Female) or 5.00 mm connector (male)
Data transfer method	RS-485 half-duplex
Cable	Twisted pair (1 pair and shield)
Isolation	500 Vdc
Protocol	PROFIBUS-DP-V1
DOIO type	ST1 Telegram
Baud rate	9.6K-12M
Addresses	2-125
Environment	
Ambient operating temperature	-10°C to +55°C
Storing temperature	-40°C to +60°C
Humidity	<95%, no condensation allowed
Altitude	Max. 1000m
Vibration	0.5G at 9-200 Hz
Safety	Fulfills EN 50178 standard


Table 63. Line length

Baud rate (kbit/s)	9.6	19.2	93.75	187.5	500	1500	3000-12000
Length line A [m]	1200	1200	1200	1000	400	200	100
Length line B [m]	1200	1200	1200	600	200	—	—

Note: Line length depends on different transmission speeds.

Hardware specifications

Figure 25. Com1 PROFIBUS card layout



LEDs

PROFIBUS LEDs are as stated below.

Table 64. PROFIBUS LEDs

ON (GREEN, the left one)	BF (RED, the middle one)	SF (RED, the right one)	Fault condition
Blinking	Blinking	Blinking	Board Initialization
ON	OFF	OFF	Everything OK
ON	ON	OFF	No communication
ON	blinking	OFF	Communication, but not in data exchange
ON	ON	ON	No communication and system fault
ON	OFF	ON	Communication and system fault

PROFIBUS-DP External Communication Cards

Connector On-Board

Use DB-9 connector, pin assignment as below.





Table 65. Connector and pin assignment

Pin number	Purpose
Housing	Shield, Connected to PE
1	No use (or Shield, shield or protect GND)
2	No use (or M24, Minus 24V output Voltage)
3	RXD/TXD-P, Positive of Receive or Transmit signal
4	RTS, Request To Send
5	DGND, GND of signal (Isolated GND from RS-485 side)
6	VP, +5V, (Voltage- Plus, Isolated 5V from RS-485 side)
7	No use (or P24, Plus 24V Output Voltage)
8	RXD/TXD-N, Negative of Receive or Transmit signal
9	No use (or CNTR_N, Control-N)

Use 5.0 mm connector and pin assignment.


Connector on customer side

Customer side connector for DB9.



Customer side connector for 5.0 mm.

Figure 26. Com1 PROFIBUS DB9 adapter



PROFIBUS cable

Two types of cables can be used for PROFIBUS connection.

Table 66. PROFIBUS cable connections

Parameter	Line A	Line B
Impedance	135–165 Ω (3–20 MHz)	100–130 Ω (f >100 kHz)
Capacity	<30 pF/m	<60 pf/m
Resistance	<100 Ω/km	—
Wire gauge	>0.64 mm	>0.53 mm
Conductor area	>0.34 mm ²	>0.22 mm ²

Table 67. Recommended cable

Cable	Description	Part Number
Belden	PROFIBUS Data Cable	3079A
Olflex	PROFIBUS Cable	21702xx
Siemens	SINEC L2 LAN cable for PROFIBUS	6XV1830 = 0AH0


Commissioning

The PROFIBUS board is commissioned by inserting it into the Slot A or Slot B on the drive control board. Once the card is inserted to the slot, the device will recognize it and will show a warning for "Device Added." This warning will be shown for 5 seconds and will be cleared. Once the card is detected, the keypad will show the menu for this card in Optional Card Menu.

Optional comm cards parameters

Once the card is detected, following parameters can be set on keypad for the PROFIBUS.

Figure 27. PROFIBUS parameter menu



PROFIBUS-DP External Communication Cards

Table 68. PROFIBUS parameters

VS3 code	Parameter	Min.	Max.	Unit	Default	ID (Slot A/Slot B)	Note
BX.1	Monitor						
BX.1.1	Device Parameters						
BX.1.1.1	Board Status				0	883/910	B0 = Optional Comm. Card Fault B1 = Board HW Fault B2 = Reserved B3 = Fieldbus Fault B4 = Reserved
BX.1.1.2	Firmware Version					1064/1067	V1.06.0005
BX.1.1.3	Protocol Status				0	2131/2142	B0 = Waiting for Parameterization B1 = Parameterization Fault B2 = Waiting for Configuration B3 = Configuration Fault B4 = Data Exchange
BX.1.1.4	PDP-Telegram Selection	1	1		1	1244/1252	1=Standard Telegram 1
BX.1.1.5	Fault Counter PDP	0	65535				
BX.1.1.6	Fault Situations Max				8x8		
BX.1.1.7	PDP-Profil Number				341		
BX.1.1.8	PDP-Control Word	0x0000	0xFFFF				
BX.1.1.9	PDP-Status Word	0x0000	0xFFFF				
BX.1.2	Parameter Access						
BX.1.2.1	PDP-MaxBlockLength				30		
BX.1.2.2	PDP-NoOfMultiparameter				1		
BX.1.2.3	PDP-MaxLatency				2		
BX.1.3	DO Identification						
BX.1.3.1	PDP-DO Manufacturer				0x019D		
BX.1.3.2	PDP-DO Device Type				0x3000		
BX.1.3.3	PDP-DO FW-Interface						
BX.1.3.5	PDP-DO FW-DayMonth						
BX.1.3.6	PDP-DO NoOfDOs				1		
BX.1.3.7	PDP-DO Subclass				1		
BX.2	Parameters						
BX.2.1	Subordinate Address	2	125		118	1242/1250	Address of the PROFIBUS Subordinate
BX.2.1	Baud Rate	1	10		10	1243/1251	Baud Rate for PROFIBUS 10 = Automatic
BX.2.2	Operation Mode	1	2		1	1245/1253	Operation Mode 0 = PROFIdrive 1 = Echo 2 = Bypass
BX.2.3	Comm. Card FB Fault Response					2519/2520	
BX.2.4	Parameter Access	0	1		1		0=Local Control;

Table 68. PROFIBUS parameters, continued

VS3 code	Parameter	Min.	Max.	Unit	Default	ID (Slot A/Slot B)	Note
BX.2.5	Process Data Access	0	5		1		1=Fieldbus; 2=NET Control, Local Ref; 4=NET, Local on Fault; 5=NET & Local CMD;
BX.2.6	Fault Situation Counter						
BX.2.7	Parameter Sets					619	

Note: X will depend on the slot the drive is in (Slot A = 7, Slot B = 14).

The parameters of every device must be set before connecting to the bus. Especially the parameters "Subordinate Address" must be same as set in Master.

PROFIBUS—VS3

General

Data transfer between PROFIBUS-DP master and subordinate takes place via the input/output data field. The master writes to subordinate's output data and the subordinate answers by sending the contents of its inputs data to master. The content of the input/output data is defined in the device profile. The device profile for drives is PROFIdrive.

The drive can be controlled by PROFIBUS-DP Master using ST1 telegram of the PROFIdrive profile using the ST1 standard telegram in Drive profile mode, or using other modules in Bypass Mode. The Modules where Process Data values are returned can be used via the Bypass Operation mode. When Fieldbus has been selected as the active control place, the drive operation is controlled from PROFIBUS-DP Master as long as PNU927 = 1 and PNU928 = 1 by default. When these bits are disabled, it only allows monitoring values via cyclic and acyclic commands.

Operation mode

The parameter Operation Mode BX.2.4 above defines how the input/output data is handled on the option board.

PROFIdrive

Data transfer follows the document PROFIBUS Profile for variable speed drives, PROFIdrive following the Standard Telegram 1.

Echo

The OUTPUT data written by the Master is echoed back to the Master in the INPUT field.

The data is not shown in the drive, but echoing is carried out on the option board.

This mode can be used when the function of the bus connection is tested.

Bypass

The information of the Process data field is transferred to the application interface without handling.

The desired Modules define the amount of data that is transferred. Once drive is set in Bypass mode, it will give the ability to set the desired module.

PROFIdrive interface

PROFIdrive profile 4.1 allows:

- Direct control of the drive using PROFIBUS Master
- Full access to all drive parameters

PROFIBUS-DP External Communication Cards

Control word and status word

The Control Word and Status Word used when in Bypass mode using one of the 4 modules will follow the layout used in Modbus for the CW, SW, Ref Speed, ACT Speed, and FB Data points.

Control word

The drive uses 16 bits as shown below. These bits are application specific.

Table 69. Binary bits and corresponding outputs

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
①	①	①	①	①	①	FB Ref	FB Ctrl	BYS	FB DIN 4	FB DIN 3	FB DIN 2	FB DIN 1	F_RST	DIR	RUN

① The bit is not used.

FB general control word

The drive does not use the FB General Control Word. The main control word is used to provide commands to the drive.

FB control word

Bit	Description value = 0	Value = 1
0	Drive Output Off	Drive Output On
1	Clockwise Rotation	Counter Clockwise
2	No Reset	Fault Reset
3	FB INDATA1 Off	FB INDATA1 On
4	FB INDATA2 Off	FB INDATA2 On
5	FB INDATA3 Off	FB INDATA3 On
6	FB INDATA4 Off	FB INDATA4 On
7	Bypass Relay Disable	Bypass Relay Enable
8	FB Control Off	FB Control On
9	FB Reference Off	FB Reference On
10–15	Not in use	Not in use

Speed reference

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
MSB	—	—	—	—	—	—	—	—	—	—	—	—	—	—	LSB

This is the Reference 1 to the VFD. Used normally as Speed reference.

The scaling on this value is 0–100.00% of the Maximum Frequency (P1.2). The 0 to 100.00% is represented by 0 to 10,000 value indicating 0 or 0% as Minimum Frequency (P1.1) and 10,000 or %100.00 as Maximum Frequency (P1.2). This value has 2 decimal places in it.

Process data in 1 to 8

Process Data In values 1 to 8 can be used in applications for various purposes.

Table 70. Bypass mode process data modules

Module	Byte 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9
Module 1 ①	CW	REF	FBData_In_1	FBData_In_2						
	SW	ACT	FBData_Out_1	FBData_Out_2						
Module 2 ①	CW	REF	FBData_In_1	FBData_In_2	FBData_In_3	FBData_In_4				
	SW	ACT	FBData_Out_1	FBData_Out_2	FBData_Out_3	FBData_Out_4				
Module 3 ①	CW	REF	FBData_In_1	FBData_In_2	FBData_In_3	FBData_In_4	FBData_In_5	FBData_In_6		
	SW	ACT	FBData_Out_1	FBData_Out_2	FBData_Out_3	FBData_Out_4	FBData_Out_5	FBData_Out_6		
Module 4 ①	CW	REF	FBData_In_1	FBData_In_2	FBData_In_3	FBData_In_4	FBData_In_5	FBData_In_6	FBData_In_7	FBData_In_8
	SW	ACT	FBData_Out_1	FBData_Out_2	FBData_Out_3	FBData_Out_4	FBData_Out_5	FBData_Out_6	FBData_Out_7	FBData_Out_8

① Only available in bypass mode.

Process data out

This register range is normally used to fast monitoring of the VFD. Process Data Out is located in range ID 2104–2111. See table below.

Table 71. Fieldbus basic output table

ID	Modbus register	Group	Range/Type
2101	32101, 42101	FB Status Word	Binary coded
2102	32102, 42102	FB General Status Word	Binary coded
2103	32103, 42103	FB Actual Speed	%
2104	32104, 42104	FB Process Data Out 1	
2105	32105, 42105	FB Process Data Out 2	
2106	32106, 42106	FB Process Data Out 3	
2107	32107, 42107	FB Process Data Out 4	
2108	32108, 42108	FB Process Data Out 5	
2109	32109, 42109	FB Process Data Out 6	
2110	32110, 42110	FB Process Data Out 7	
2111	32111, 42111	FB Process Data Out 8	

Note: FB Process data is defined in **Appendix B**.

Status word

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
—	—	—	—	—	—	—	—	RUNEN	BYS	AREF	WARN	FLT	DIR	RUN	RDY

Information about the status of the device and messages is indicated in the Status Word. The Status Word is composed of 16 bits that have the following meanings.

Table 72. Status word bit descriptions

Bit	Description value = 0	Value = 1
0	Not Ready	Ready
1	STOP	RUN
2	Clockwise	Counterclockwise
3	—	Faulted
4	—	Warning
5	Ref. frequency not reached	Ref. frequency reached
6	Bypass not activated	Bypass activated
7	Run disable	Run Enable
8	Not in use	Not in use
9–15	Not in use	Not in use

Actual speed

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
MSB	—	—	—	—	—	—	—	—	—	—	—	—	—	—	LSB

This is the Actual Speed of the motor. This value comes back in the form of Hz.

PROFIBUS overview

PROFIBUS is a vendor independent, open fieldbus standard for a wide range of applications in manufacturing, process and building automation. Vendor independence and openness are guaranteed by the PROFIBUS standard EN 50 170. With PROFIBUS, devices of different manufactures can communicate without special interfaces adjustment. PROFIBUS can be used for both high-speed time critical data transmission and extensive complex communication tasks.

PROFIBUS-DP—Optimized for high speed and inexpensive hookup, this PROFIBUS version is designed especially for communication between automation and control systems and distributed I/O at the device level. PROFIBUS-DP can be used to replace parallel signal transmission with 24V or 0 to 20 mA.

The PROFIBUS Family—PROFIBUS specifies the technical and functional characteristics of a serial fieldbus system with decentralized digital controllers can be networked together from the field level to the cell level. PROFIBUS distinguishes between master and subordinate devices.

Master Devices—Determines the data communication on the bus. A master can send messages without an external request when it holds access rights (the token). Master are also called “active stations” in the PROFIBUS protocol.

Subordinate Devices are peripheral devices. Typical devices include input/output devices, valves, drives and measuring transmitters. They do not have bus access rights and they can only acknowledge received messages or send messages to the master when requested to do so. Subordinates are also called ‘passive stations.’


Profiles—The PROFIBUS-DP protocol defines how user data to be transmitted between stations over the bus. User data are not evaluated by the PROFIBUS transmission protocol. The meaning is specified in the profiles. In addition, the profiles specify how PROFIBUS-DP is to be used in the drives PROFIBUS Fieldbus board.

Leading manufacturers of drive technology have jointly defined the PROFIdrive profile. The profile specifies how the drives are to be parameterized and how the set points and actual values are to be transmitted. This enables drives from different vendors to be exchanged. The profile contains necessary specifications for speed control and positioning. It specifies the basic drive functions while leaving sufficient freedom for application-specific expansions and further developments. The profile describes the mapping of the application functions for DP.

PROFIdrive consists of a general part and a bus specific part. The following properties are defined in the general part.

- Base Model
- Parameter model
- Application Model

Figure 28. PROFIdrive



The PROFIdrive base model describes an automation system in terms of a number of devices and their interrelationships (application interfaces, parameter access). The base model distinguishes between following device classes.

Communication Services—Two communication services are defined in the PROFIdrive profile; namely, cyclic data exchange and acyclic data exchange.

Cyclic data exchange via a cyclic data channel

Motion control system need cyclically updated data during operation for open and closed loop control purposes. This data must be sent to the drive units in the form of set points or transmitted from the drive units in the form of actual values, via the communication systems.

Acyclic data exchange via an acyclic data channel

In addition to cyclic data exchange, there is an acyclic parameter channel for exchanging parameters between control/supervisor and drive units. Access to this data is not time critical.


Application classes

The integration of drives into automation solutions depend strongly upon the drive task. To cover the extensive range of drive application from the most simple frequency convertor up to highly dynamic synchronized multi axis systems with a single profile. PROFIdrive defines six application categories but the drives PROFIBUS optional card support below application class 1.

Table 73. Application class

SN	Application class	Interface	Function
1	Standard Drive (e.g., pumps, fans, agitators)	n-set point	Cyclic I/O data interface

Figure 29. Application class



PROFIBUS-DP External Communication Cards

Startup test

Set up the communication with Master and follow below steps.

1. Complete Parameterization of the device. Below parameters are important to control device on PROFIBUS.
 - a. Parameterization Enable/Disable = 1 (Enabled)
 - b. Local / remote selection = 1 (Remote control)
 - c. Remote 1 control place = 1 (Fieldbus)
 - d. Remote 1 reference = 7 (Fieldbus Ref)
 - e. PNU927-Opern priority of param = 1
 - f. PNU928 Ctrl priority DOIO Data = 1
 - g. ProfiBus Operation Mode = 0 (ProfiDrive)
2. Select the "Standard Telegram 1" in the Configuration step in the PLC
3. Set control word value to 0x0406 to enter ProfiDrive State S2
4. Set control word value to 0x0407 to enter ProfiDrive State S3
5. Set control word value to 0x047F and Set Frequency reference to 0x04000 to enter ProfiDrive State S4
6. Check drive is running on output frequency 100%.
7. Set control word value to 0x047E to drive stop and ProfiDrive State S2
8. Check drive is in stop mode and output frequency 0%

Control and status words

The Control Word (PROFIBUS Parameter number (PNU) = 967) is the principal means for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive, the adapter module acting as a gateway.

The drive switches between its states according to the bit-coded instructions on the Control Word, and returns status information to the master in the Status Word (PROFIBUS Parameter number (PNO) = 968).

Control word 1 (STW1)

To improve the exchange of devices of different manufacturers in a control application, we strongly recommend using the device-specific bits only for the control of manufacturer specific functions. The device-specific bits shall not be necessary for the operation of a device in the speed control mode and in the positioning mode (default of the device-specific bits = 0).

Table 74. PROFIdrive control word 1—STW1 message examples

Bit	Value	Significance	Comments
0	1	ON	"Switched on" condition; voltage at the power converter, i.e. the main contact is closed (if present).
	0	OFF (OFF 1)	Power-down (the drive returns to the "ready for switching on" condition); the drive is ramped-down along the ramp (RFG) or along the current limit or along the voltage limit of the d.c. link; if standstill is detected, the voltage is isolated; the main contact is opened (if present). During deceleration bit 1 of ZSW1 is still set. An OFF command is interruptible.
1	1	No Coast Stop (no OFF 2)	All "Coast Stop (OFF2)" commands are withdrawn.
	0	Coast Stop (OFF 2)	Voltage is isolated. The main contact is then opened (if present) and the drive goes into the "Switching On Inhibited" condition; the motor coasts down to a standstill.
2	1	No Quick Stop (no OFF 3)	All "Quick Stop (OFF3)" commands are withdrawn.
	0	Quick Stop (OFF 3)	Quick stop; if required, withdraw the operating enable, the drive is decelerated as fast as possible, e.g., along the current limit or at the voltage limit of the d.c. link, at $n/f = 0$; if the rectifier pulses are disabled, the voltage is isolated (the contact is opened) and the drive goes into the "Switching On Inhibited" condition. A Quick Stop command is not interruptible.
3	1	Enable Operation (Start)	Enable electronics and pulses. The drive then runs-up to the set point.
	0	Disable Operation (Stop)	The drive coasts down to a standstill (ramp-function generator to 0 or tracking) and goes into the "Switched on" condition (refer to control word 1, bit 0).

Table 74. PROFIdrive control word 1—STW1 message examples, continued

Bit	Value	Significance	Comments
4	1	Enable Ramp Generator	
	0	Reset Ramp Generator	Output of the RFG is set to 0. The main contact remains closed, the converter is not isolated from the line, the drive decelerates along the current limit or along the voltage limit of the d.c. link.
5	1	Unfreeze Ramp Generator	
	0	Freeze Ramp Generator	Freeze the actual set point entered by the ramp-function generator. If Application Class 4 is used Bit 5 is not relevant.
6	1	Enable Set point	The value selected at the input of the RFG is switched-in.
	0	Disable Set point	The value selected at the input of the RFG is set to 0.
7	1	Fault Acknowledge (0→1)	The group signal is acknowledged with a positive edge; the drive reaction to a fault depends on the type of fault. If the fault reaction has isolated the voltage, the drive then goes into the "Switching On Inhibited" condition.
	0	No significance	
8	1	Jog 1 Ona	Prerequisite. Operation is enabled, drive is in standstill and STW1 bit 4, 5, 6 = 0. The drive runs up along the ramp of RFG to jogging set point 1.
	0	Jog 1 OFFa	Drive brakes along the ramp of RFG, if "Jog 1" was previously ON, and goes into "Operation Enabled" when drive comes to a standstill.
9	1	Jog 2 Ona	N/A
	0	Jog 2 OFFa	N/A
10	1	Control By PLC	Control via interface, DO I/O Data valid (refer to 6.3.11).
	0	No Control By PLC	DO I/O Data not valid; expect Sign-Of-Life. If loosing the control priority bit the reaction is device-specific. Possible reactions. 1) speed control. "old" process data is kept, 2) positioning. DO I/O Data are set to 0.
11	1	Device Specific	N/A
	0	Device Specific	N/A
12	1	Device Specific	N/A
	0	Device Specific	N/A
13	1	Device Specific	N/A
	0	Device Specific	N/A
14	1	Device Specific	N/A
	0	Device Specific	N/A
15	1	Device Specific	N/A
	0	Device Specific	N/A

PROFIBUS-DP External Communication Cards

Below is various defined control word (STW1) command.

Table 75. Control word (STW1) message examples

SN	Control word (STW1)	Control word description (STW1)	Comment
1	0x0400	Set PLC Control	PLC Control should be set in MCU
2	0x0000	Clear PLC Control	PLC Control should be reset in MCU
3	0x040F	Run Command without RFG	Motor Off as no RAMP Generator
4	0x0407	Clear Run Command	Motor Off as earlier
5	0x041F	Run Command with RFG and without Set point	Motor Off as no Set point Generator
6	0x0407	Clear Run Command	Motor Off as earlier
7	0x047F	Run Command with RFG and with Set point	Motor ON with RFG
8	0x0407	Clear Run Command	Motor Off as earlier
9	0x047F	Run Command with RFG and with Set point	Motor ON with RFG
10	0x045F	Set Freeze of Ramp	Motor ON with Ramp Freeze
11	0x047F	Clear Freeze of Ramp	Motor ON with Following Ramp Timing
12	0x047E	OFF 1 Command	Motor Off with RFG
13	0x047F	Run Command with RFG and with Set point	Motor ON with RFG
14	0x047D	OFF 2 Command (Coast Stop)	Motor Off with Coast
15	0x047F	Run Command with RFG and with Set point	Motor ON with RFG
16	0x047B	OFF 3 Command (Quick Stop)	Motor Off with 0 DECEL Time
17	0x047F	Run Command with RFG and with Set point	Motor ON with RFG
18	0x0477	Disable Operation	Motor Off with Coast
19	0x057F	Run Command with RFG and with Set point At Jog Speed	Motor ON at Jog Speed
20	0x0477	Disable Operation	Motor Off with Coast
21	0x0480	Fault Reset bit	Fault should get reset

Status word 1 (ZSW1)

Table 76. Application status word PROFIdrive

Bit	Value	Significance	Comments
0	1	Ready To Switch On	Power supply is switched on, electronics initialized, main contact, if available, has dropped out, pulses are inhibited.
	0	Not Ready To Switch On	
1	1	Ready To Operate	Refer to control word 1, bit 0.
	0	Not Ready To Operate	
2	1	Operation Enabled	Drive follows set point. This means, that the electronic and pulses are enabled (Refer to control word 1, bit 3), the closed loop control is active and controls the motor and the output of the set point channel is the input for the closed loop control.
	0	Operation Disabled	Either the pulses are disabled or the drive doesn't follow the output value of the set point channel.
3	1	Fault Present	Unacknowledged faults or currently not acknowledgeable faults (fault messages) are present (in the fault buffer). The fault reaction is fault-specific and device-specific. The acknowledging of a fault may only be successful, if the fault cause has disappeared or has been removed before. If the fault has isolated the voltage, the drive goes into the "Switching On Inhibited" condition, otherwise the drive returns to operation. The related fault numbers are in the fault buffer.
	0	No Fault	
4	1	Coast Stop Not Activated (No OFF 2)	
	0	Coast Stop Activated (OFF 2)	"Coast Stop (OFF 2)" command is present.

Table 76. Application status word PROFIdrive, continued

Bit	Value	Significance	Comments
5	1	Quick Stop Not Activated (No OFF 3)	
	0	Quick Stop Activated (OFF 3)	"Quick Stop (OFF 3)" command is present.
6	1	Switching On Inhibited	The drive goes only again in the "Switched On" condition with "No Coast Stop AND No Quick Stop" followed by "ON." This means that the "Switching On Inhibited" bit is only set back to zero if the OFF command is set after "No Coast Stop AND No Quick Stop."
	0	Switching On Not Inhibit	
7	1	Warning Present	Warning information present in the service/maintenance parameter; no acknowledgement.
	0	No Warning	There is no warning or the warning has disappeared again.
8	1	Speed Error Within Tolerance Range	Actual value is within a tolerance band; dynamic violations are permissible for $t < t_{max}$, e.g., $n = n_{set} \pm$, $f = f_{set} \pm$, etc., t_{max} may be parameterised
	0	Speed Error Out Of Tolerance Range	
9	1	Control Requested	The automation system is requested to assume control (refer to 6.3.11).
	0	No Control Requested	Control by the automation system is not possible, only possible at the device or by another interface.
10	1	f Or n Reached Or Exceeded	Actual value $\geq$ comparison value (set point) which may be set via the parameter number.
	0	f Or n Not Reached	
11	1	Device Specific	N/A
	0	Device Specific	N/A
12	1	Device Specific	N/A
	0	Device Specific	N/A
13	1	Device Specific	N/A
	0	Device Specific	N/A
14	1	Device Specific	N/A
	0	Device Specific	N/A
15	1	Device Specific	N/A
	0	Device Specific	N/A

References

References are 16-bit words containing a sign bit and a 15-bit integer. A negative reference is formed by calculating the 2's complement from the corresponding positive reference.

Table 77. References

SN	N2 data type hex	N2 data type decimal	N2 data type percentage	Frequency in decimal
1	4000	16384	100	50
2	3000	12288	74	37
3	2000	8192	50	25
4	1000	4096	24	12
5	0	0	0	0
6	F000	61440	-25	12
7	E000	57344	-50	25
8	D000	53248	-75	37
9	C000	49152	-100	50


Actual values

Actual values are 16-bit words containing information on the operation of the drive. The function to be monitored are selected by a drive parameter. The scaling of the integers sent to the master as Actual Values depends on the selected function.

General state machine

State diagrams are defined for the operating modes. In the PROFIdrive control profile, the controls bits 0 to 3 perform the basic start-up / power down functions whereas the control bits 4 to 15 perform application-oriented control.

Figure 30. General state diagram



Notes: STW1 bit x, y = These control word bits shall be set by the control.

ZSW1 bit x, y = These status word bits indicate the actual state.

Standstill detected is an internal result of a stop operation.

a Abbr.: "p.e." = "Pulses enabled" optional.

b The internal condition "fault with ramp stop" also activates this transition.

Information on the general state diagram

- The green blocks represent states, the arrows represent transitions
- From several states, several transitions are possible
- The more points that a transition has, the higher is its priority. A transition without points has the lowest priority
- The PROFIBUS interfaces between this controller and the DO has the control priority (PNO 928)
- ZSW1 Bit 9 is set by the DO
- STW1 Bit 10 is set by the controller
- The bits defined for positioning mode are only relevant, if the drive is in the state "S4" operation
- All stop-reactions caused by faults (Fault with Ramp stop, Fault with Quick stop, Fault with Coast stop) for the general state machine to switch to state S1 (Switching on Inhibited) or S2 (Ready For switching)

DO I/O data

The set points to the Axis and also the actual from the Axis are transferred as DO I/O data. The DO I/O data is transferred using the cyclic data exchange. The representation of data shall be in big endian format.

The following advantages are obtained due to the telegram configuring and normalization.

- Interoperability and interchangeability of PROFIdrive Controllers and Drive Objects
- Standard components may be simply commissioned
- Automation mechanisms in the controller application

Signals

A series of signals with appropriate signal numbers is defined to configure the DO I/O Data (set points, actual values).

The following values are permissible for the signal numbers.

- 0 = not assigned
- 1-99 = standard signal numbers (profile-specific signal numbers)
- 100-65535 = signal numbers (device-specific)

The Variable Speed Drive Series III PROFIBUS optional card, the defined signal numbers are listed in the following.

Table 78. PROFIBUS option Card

Signal no.	Significance	Abbreviation	Length
1	Control word 1	STW1	16
2	Status word 1	ZSW1	16
5	Speed set point A	NSOLL_A	16
6	Speed actual value A	NIST_A	16

Standard telegram 1

Standard telegram 1 is defined for speed set point interface operations application class (AC1). The standard telegrams are selected when configuring the DO I/O Data.

The standard telegram 1 has the following structure.

- n set interface, 16 bit

Table 79. Standard telegram 1

I/O Data Number	Set point	Actual value
1	STW1	ZSW1
2	NSOLL_A	NIST_A

PROFIdrive Profile

The PROFIdrive profile PNU numbers are listed in **Appendix A** of this manual.

DPV1 acyclic communication

Base model parameter access, whose structure is defined in the PROFIdrive profile 4.2, is always used for communicating the writing/reading parameters for PROFIdrive drives.

Under this arrangement, parameters access always consists of two elements. Under this arrangement, parameter access always consists of two elements.

Write request ("Write data set ")

Read request ("Read data set")

Write request or Request can be send via DPV1 master class 1 or master class 2.

The DP V1 command/response part is used for the standard DP V1 read/Write on the Slot 0, Index47 data block.

Parameter requests and parameter responses

A parameter consists of three segments.

Request header

ID for the request and number of parameters which are accessed. Multi-Axis and Modular drives, Addressing of one DO.

Parameter address

Addressing of a parameter. If parameters are accessed, there are correspondingly many parameter addresses but can only be accessed on a single case. The parameter address appears only in the request, not in the response.

Parameter value. Per addressed parameter, there is a segment for the parameter values. Depending on the request ID, parameter values appear only either in the request or in the reply.

Words and double words

The following telegram contents are displayed in words (a word or 2 bytes per line). Words or double words will have the most significant byte being transmitted first (big endian).

Table 80. Words and Double Words

Word	Byte 1	Byte 2
Double Word	Byte 1	Byte 2
	Byte 3	Byte 4

According to the Base Model Parameter access the structure of the parameter request and parameter response as shown in Table 82 and Table 83.

Table 81. Base mode parameter request

Block definition	Byte n	Byte n +1	n
Request Header	Request reference	Request ID 0	0
	Axis-No. / DO-ID	No. of parameters = i	2
1st Parameter address	Attribute	No. of elements	4
	Parameter number (PNU)		
	Subindex		
ith Parameter address	...		4 + 6 × (i-1)
1st Parameter value(s) (only for request "change parameter")	Format	No. of values	4 + 6 × i
	Value		
	...		
ith Parameter value	...		4 + 6 × i + ... + (Format_n × Qty_n)

Table 82. Base model response

Block definition	Byte n	Byte n +1	n
Response header	Request Ref. mirrored	Response ID	0
	Axis-No. / DO-ID mirrored	No. of parameters = i	2
1st Parameter Value (s) (only after request "Request")	Format	No.of values	4
	Values or error values		
	...		
ith Parameter values	...		4 +... + (Format_n × Qty_n)

Coding

Coding of the fields in parameter request/parameter response of base model parameter access.

PROFIBUS board support only single parameter and single element.

Max No. of Parameters = 1

Max No. of Elements = 1

Max No. of Values = 1

Table 83. Field coding

Field	Data Type	Value	Comment	
Request Reference	Unsigned 8	0x00	Reserved	
		0x01...0xFF		
Response ID	Unsigned 8	0x00	Reserved	
		0x01	Request parameter (+)	
		0x02	Change parameter(+)	
		0x03...0x3F	Reserved	
		0x40	INCORRECT Request Ref	
		0x41	INCORRECT Request ID	
		0x42	INVALID NOS PARAM	
		0x43	INVALID_Axis_DO_DI	
		0x44...0x7F	Manufacturer-specific	
		0x80	Reserved	
		0x81	Request parameter (–)	
		0x82	Change parameter (–)	
		0x83...0xBF	Reserved	
		0xC0...0xFF	Manufacturer-specific	
Axis/DO-ID	Unsigned 8	0x00	Device-Representative	Zero is not a DO but representative of the access to the drive unit.
		0x01...0xFE	DO-ID-Number 1–254	
		0xFF	Reserved	
No. of Parameters	Unsigned 8	0x00	Reserved	There may be an additional limitation through the communication system (telegram length) or optional scalability.
		0x01...0x27	Quantity 1–39	
		0x28...0xFF	Reserved	
Attribute	Unsigned 8	0x00	Reserved	The four less significant bits are reserved for (future) expansion of “No. of Elements” to 12 bits.
		0x10	Value	
		0x20	Description	
		0x30	Text	
		0x40...0x70	Reserved	
		0x80...0xF0	Manufacturer-specific	
No. of Elements	Unsigned 8	0x00	Special Function	Limitation through compatibility with PROFIBUS process data ASE telegram length.
		0x01...0xEA	Quality 1–234	
		0xEB...0xFF	Reserved	
Parameter Number	Unsigned 16	0x0000	Reserved	
		0x0001	Number 1–65535	
		0xFFFF		
Subindex	Unsigned 16	0x0000...	Number 0–65534	
		0xFFFF		

Table 83. Field coding, continued

Field	Data type	Value	Comment
Format	Unsigned 8	0x00	Reserved
		0x01...0x36	Data types
		0x37...0x3F	Reserved
		0x40	Zero
		0x41	Byte
		0x42	Word
		0x43	Double word
		0x44	Error
		0x45...0xFF	Reserved
No. of Values	Unsigned 8	0x00...0xEA	Quantity 0–234
		0xEB...0xFF	Reserved
Error Number	Unsigned 16	0x0000...	Error numbers
		0x00FF	

Generic station description (GSD) file

Please refer GSD file “EATN0EF5.gsd”

BACnet/IP On-Board Communication—Variable Speed Drive Series III

BACnet stands for Building Automation and Control Networks. It is the common name for the communication standard ISO 16484-5 that defines the methods and the protocol for cooperating building automation devices to communicate. Devices can be designed to operate using BACnet communication protocol as well as utilizing BACnet protocol to communicate between systems. BACnet is an internationally accepted protocol for building automation (such as lightning control, air conditioning, and heating automation) and control over a communications network. BACnet provides a method by which computer-based control equipment, from different manufacturers can work together, or “interoperate.” For this to be achieved, components must be able to exchange and understand BACnet data messages. Your drive is equipped with BACnet support as standard

BACnet/IP specifications


Table 84. BACnet/IP Protocol

Connection	Communication
Interface	100BaseTX, IEEE 802.3 compatible
Data transfer method	Ethernet half-/full-duplex
Data transfer speed	10/100 MBit/s, autosensing
Protocol	BACnet over UDP/IP
Connector	Shielded RJ45 connector
Cable type	CAT5e STP
BACnet/IP	As described in ANSI/ASHRAE Standards 135-2004
Default/IP	Selectable: Fixed or DHCP

BACnet/IP connections

The control board is located inside the control unit of the drive.

Figure 31. Principle example diagram of BACnet



Prepare to use BACnet/IP through RJ45 port

1. Open the cover of the AC drive.


WARNING

The relay outputs and other I/O-terminals may have a dangerous control voltage present even when drive is disconnected from mains.

2. Connect Ethernet cable.
3. Remount the AC drive cover.

Note: When planning the cable runs, remember to keep the distance between the fieldbus cable and the motor cable at a minimum of 11.81 in (30 cm).

RJ45 port LED indications



RJ45 LED

1. Ethernet Link Status
2. Ethernet Link Speed

Commissioning

Connections and wiring


The RJ45 port supports 10/100 Mb speeds in both full and half-duplex modes. The boards must be connected to the RJ45 network with a shielded CAT-5e cable. A crossover cable (at least CAT-5e cable with STP, shielded twisted pair) may be needed if you want to connect the drive directly to the master appliance.

Use only industrial standard components in the network and avoid complex structures to minimize the length of response time and the amount of incorrect dispatches.

It is often a good practice to use a subnet that is different from other devices not related to the drive control.

Figure 32. CAT-5e cable



Figure 33. VS3 keypad navigation to ethernet comm settings

In this menu you will be able to scroll through the below settings to setup the communication protocol.

Table 85. EtherNet/IP

VS3 code	Parameter	Min.	Max.	Unit	Default	ID	Note
P12.4.1.1	IP Address Mode				1	1500	0 = Static IP 1 = DHCP with AutoIP
P12.4.1.2	Active IP Address					1507	
P12.4.1.3	Active Subnet Mask					1509	
P12.4.1.4	Active Default Gateway					1511	
P12.4.1.5	MAC Address					1513	
P12.4.1.6	Static IP Address				192.168.1.254	1501	
P12.4.1.7	Static Subnet Mask				255.255.255.0	1503	
P12.4.1.8	Static Default Gateway				192.168.1.1	1505	
P12.4.1.9	Enable BACnet IP	0	1		0	1725	0 = Disable 1 = Enable

Note: BACnet/IP uses parameters from EtherNet/IP.

DHCP

The BACnet/IP network communication supports DHCP for easier network configuration. Dynamic Host Configuration Protocol (DHCP) is a network protocol that is used to configure network devices so that they can communicate on an IP network. As a DHCP client, the device negotiates with the DHCP server to determine its IP address and obtain any other initial configuration details it needs for network operation.

IP address

IP is divided into four parts. (Part = Octet) Default Static IP Address is 192.168.1.254

Communication timeout

Defines how much time can pass from the last received message from the client device before fieldbus fault is generated. Default communication timeout is 10 seconds.

Note: If the network cable is broken from the RJ45 port, a fieldbus error is generated immediately.

Static IP address

In most cases the user may want to establish a Static IP Address for the BACnet/IP based on their network configuration.

Static IP address default configurations are as defined in “EtherNet/IP network settings” table, provided in “Connections and Wiring” section.

The user can manually define the network address for the BACnet/IP as long as all units connected to the network are given the same network portion of the address. In these situations, the user will need to manually set the IP Address in the device by using the drive keypad. Be aware that overlapping IP addresses can cause conflicts between devices on the network. For more information about selecting IP addresses, contact your network administrator.

Enable BACnet/IP

The enable BACnet/IP will enable the BACnet/IP ability and disable the BACnet MSTP protocol function.

Manual IP address configuration

Using the Variable Speed Drive Series III keypad

Using the Drive Keypad to set the IP Address manually in the device.

1. Select IP addressing mode as Static IP. Static IP mode configurations will be loaded.

Note: Change in IP address mode will require drive to power cycle to get this change effective. Also ensure device MAC address.


2. Using the drive keypad, set the IP address in the device to the desired address setting by.

- a. Setting Static IP Address
- b. Setting Static Subnet Mask
- c. Setting Static Default Gateway

Figure 34. VS3 Static IP mode



Figure 35. VS3 Static IP address



3. Make note of the changed IP Address.
4. Using drive keypad, read "Active IP Address," "Active Subnet Mask," "Active Default Gateway" parameters to ensure that IP address has been set to desired IP address.

Table 86. BACnet/IP

VS3 code	Parameter	Min.	Max.	Unit	Default	ID	Note
P12.4	EtherNet Bus						
P12.4.1	Basic Setting						
P12.4.1.1	IP Address Mode				1	1500	0 = Static IP 1 = DHCP with AutoIP
P12.4.1.2	Active IP Address					1507	
P12.4.1.3	Active Subnet Mask					1509	
P12.4.1.4	Active Default Gateway					1511	
P12.4.1.5	MAC Address					1513	
P12.4.1.6	Static IP Address				192.168.1.254	1501	
P12.4.1.7	Static Subnet Mask				255.255.255.0	1503	
P12.4.1.8	Static Default Gateway				192.168.1.1	1505	
P12.4.1.9	Enable BACnetIP	0	1		0	1725	0 = Disabled 1 = Enabled
P12.4.3	BACnet IP						
P12.4.3.1	BACnet IP UDP port number	47808	47823		47808	1733	47808 = BAC0, 47809 = BAC1, 47810 = BAC2, 47811 = BAC3, 47812 = BAC4, 47813 = BAC5, 47814 = BAC6, 47815 = BAC7, 47816 = BAC8, 47817 = BAC9, 47818 = BACA, 47819 = BACB, 47820 = BACC, 47821 = BACD, 47822 = BACE, 47823 = BACF
P12.4.3.2	BACnet IP Foreign Device	0	1		0	1734	0 = Disabled 1 = Enabled
P12.4.3.3	BACnet IP BBMD IP				0.0.0.0	1735	
P12.4.3.4	BACnet IP BBMD Port	47808	47823		47808	1737	47808 = BAC0, 47809 = BAC1, 47810 = BAC2, 47811 = BAC3, 47812 = BAC4, 47813 = BAC5, 47814 = BAC6, 47815 = BAC7, 47816 = BAC8, 47817 = BAC9, 47818 = BACA, 47819 = BACB, 47820 = BACC, 47821 = BACD, 47822 = BACE, 47823 = BACF
P12.4.3.5	BACnet IP Registration Interval	0	65535	Sec	10	1738	
P12.4.3.6	BACnet IP Comm Timeout	0	60000	Sec	0	1739	
P12.4.3.7	BACnet IP Protocol Status				0	1740	0 = Stopped, 1 = Operational, 2 = Faulted
P12.4.3.8	BACnet IP Fault Behavior	0	1		0	1741	0 = In Fieldbus Control 1 = in all Control
P12.4.3.9	BACnetIP Instance Number	0	4194302		0	1742	

BACnet/IP parameters

Table 87. BACnet/IP parameter descriptions

ID	Name	Description
P12.4.1.9	Enable BACnet/IP	This parameter enables BACnet IP communications. When this parameter is enabled, other parameters in menu becomes visible, else they are hidden.
P12.4.3.1	BACnet/IP UDP port number	The UDP port for the BACnet IP communication.
P12.4.3.2	BACnet/IP Foreign Device	The foreign device feature is used when the device is located in a different network than the BBMD. A normal router does not send broadcast messages between different networks. The 'Foreign device' feature solves this problem by establishing a connection to the BBMD with unicast messages. All broadcast messages are forwarded to a BBMD device that takes care of receiving and transmitting broadcast messages in both directions for all foreign devices.
P12.4.3.3	BACnet/IP BBMD IP	The IP address of the BACnet IP Broadcast Management Device.
P12.4.3.4	BACnet/IP BBMD Port	The BBMD Port number.
P12.4.3.5	BACnet/IP Registration Interval	The registration interval to keep a live connection to the BBMD. Unit is seconds.
P12.4.3.6	BACnet/IP Comm Timeout	Defines the number of seconds after a timeout is indicated after a communication break or disconnected EtherNet link. Value 0 disables communication link supervision.
P12.4.3.7	BACnet/IP Protocol Status	Fieldbus Protocol Status tells the status of the protocol.
P12.4.3.8	BACnet/IP Fault Behavior	Defines when Fieldbus fault to be raise if fault condition is detected.
P12.4.3.9	BACnet/IP Instance Number	The Device Object's Instance number is used in conjunction with the MAC address to assign the devices on the network. The instance number can have up to 127 nodes on it before a different instance number is required.

BACnet overview

BACnet technical data

Protocol Implementation Conformance Statement (PICS)

Controller Profile

- B—ASC

Segmentation Capability

- Not supported

Data Link Layer and Routing Options

- 10/100 MBit/s, Autosensing

Character Sets Supported

- UTF8

BIBBS Supported

- Data Sharing
 - ReadProperty—B
 - WriteProperty—B
- Device Management
 - Dynamic Device Binding—B
 - Dynamic Object Binding—B
 - DeviceCommunicationControl—B
 - ReinitializeDevice—B
- Alarms and Events: Not supported
- Schedules: Not supported
- Trends: Not supported
- Network Management: Not supported

Table 88. Supported object types and properties summary

Property	Device object type	Analog input object type	Analog value object type	Binary value object type	Multiple state value object type
Acked_Transitions					
Active_Cov_Subscriptions					
Active_Text				■	
Active_Vt_Sessions					
Alarm_Value					
Alarm_Values					
Align_Intervals					
Apdu_Segment_Timeout					
Apdu_Timeout	■				
Application_Software_Version	■				
Auto_Subordinate_Discovery					
Backup_And_Restore_State					
Backup_Failure_Timeout					
Backup_Preparation_Time					
Change_Of_State_Count					
Change_Of_State_Time					
Configuration_Files					
Cov_Increment					
Database_Revision	■				
Daylight_Savings_Status					
Deadband					
Description	■	■	■	■	■
Device_Address_Binding	■				
Device_Type					
Elapsed_Active_Time					
Event_Algorithm_Inhibit					
Event_Algorithm_Inhibit_Ref					
Event_Detection_Enable					
Event_Enable					
Event_Message_Texts					
Event_Message_Texts_Config					
Event_State		■	■	■	■
Event_Time_Stamps					
Fault_Values					
Firmware_Revision	■				
High_Limit					
Inactive_Text				■	
Interval_Offset					
Last_Restart_Reason					
Last_Restore_Time					
Limit_Enable					
Local_Date					
Local_Time					
Location					
Low_Limit					
Manual_Subordinate_Address_Binding					
Max_Apdu_Length_Accepted	■				
Max_Pres_Value					
Max_Segments_Accepted					
Min_Pres_Value					

Table 88. Supported object types and properties summary, continued

Property	Device object type	Analog input object type	Analog value object type	Binary value object type	Multiple state value object type
Minimum_Off_Time					
Minimum_On_Time					
Model_Name	■				
Notification_Class					
Notify_Type					
Number_Of_Apdu_Retries	■				
Number_Of_States					■
Object_Identifier	■	■	■	■	■
Object_List	■				
Object_Name	■	■	■	■	■
Object_Type	■	■	■	■	■
Out_Of_Service		■	■	■	■
Password	■				
Present_Value		■	■	■	■
Priority_array			■	■	
Profile_Name	■				
Protocol_Object_Types_supported	■				
Protocol_Revision	■				
Protocol_Services_Supported	■				
Protocol_Version	■				
Reliability					
Reliability_Evaluation_Inhibit					
Relinquish_Default			■	■	
Resolution					
Restart_Notification_Recipients					
Restore_Completion_Time					
Restore_Preparation_Time					
Segmentation_Supported	■				
Serial_Number	■				
Subordinate_Address_Binding					
Subordinate_Proxy_Enable					
State_Text					■
Status_Flags		■	■	■	■
Structured_Object_list					
System_Status	■				
Time_Delay					
Time_Delay_Normal					
Time_Of_Active_Time-reset					
Time_Of_Device_Restart					
Time_Of_State_Count_Reset					
Time_Synchronization_Interval					
Time_Synchronization_Recipients					
Units		■	■		
Update_Interval					
Utc_Offset					
Utc_Time_Synchronization_Recipients					
Vendor_Identifier	■				
Vendor_Name	■				
Vt_Classes_Supported					

Object instance summary

Binary Value Object Instance Summary

The following table summarizes the Binary Value Objects supported.

Table 89. Binary value object instance summary

Instance ID	Object name (related to drive parameter)	Description	Inactive/active text	Preset value access
BV0	Ready State	Indicates whether the drive is ready or not	Not Ready/Ready	R
BV1	Run/Stop State	Indicates whether the drive is running or stopped	Stop/Run	R
BV2	Fwd/Rev State	Indicates the rotation direction of motor	Fwd/Rev	R
BV3	Fault State	Indicates if a fault is active	OK/Fault	R
BV4	Warning State	Indicates if a warning is active	OK/Warning	R
BV5	At Setpoint	Ref. Frequency reached	False/True	R
BV6	At Zero Speed	Motor Running at zero speed	False/True	R
BV7	Motor Ctrl source	Command to change active source for controlling motor	LocalMotorCtrl / FBMotorCtrl	C
BV8	Speed Reference Source	Command to change source of motor speed reference	LocalSpeedRef / FBSpeedRef	C
BV9	Run/Stop CMD	Command to start drive	Stop/Run	C
BV10	Fwd/Rev CMD	Command to change rotational direction	Fwd/Rev	C
BV11	Reset Fault	Command to reset active Fault from drive	0/Reset	C
BV12	Digital Input 1	Digital Input 1	OFF/ON	R
BV13	Digital Input 2	Digital Input 2	OFF/ON	R
BV14	Digital Input 3	Digital Input 3	OFF/ON	R
BV15	Digital Input 4	Digital Input 4	OFF/ON	R
BV16	Digital Input 5	Digital Input 5	OFF/ON	R
BV17	Digital Input 6	Digital Input 6	OFF/ON	R
BV18	Digital Input 7	Digital Input 7	OFF/ON	R
BV19	Digital Input 8	Digital Input 8	OFF/ON	R
BV20	Digital Output 1	Digital Output 1	OFF/ON	R
BV21	Digital Output 2	Relay 1 Output	OFF/ON	R
BV22	Digital Output 3	Relay 2 Output	OFF/ON	R
BV23	Digital Output 4	Relay 3 Output	OFF/ON	R
BV24	Stop By Coast	Indicates if drive stop by coast	ON/OFF	C
BV25	Stop By Ramp	Indicates if drive stop by Ramp	OFF/ON	C
BV26	Belt Broken	Indicates If belt is broken	OFF/ON	R
BV27	Drive Fan Failure	Indicates if Drive Fan failed	OFF/ON	R
BV28	Force Bypass	Command to take Drive in Bypass Mode	OFF/ON	C
BV29	Fire Mode	Enable Fire Mode	OFF/ON	C
BV30	DIN 1	Fieldbus Digital Input	OFF/ON	C
BV31	DIN 2	Fieldbus Digital Input	OFF/ON	C
BV32	DIN 3	Fieldbus Digital Input	OFF/ON	C
BV33	DIN 4	Fieldbus Digital Input	OFF/ON	C

Note: For Present Value Access Types, R = Read-only, W = Writeable, C = Commandable.

Commandable values support priority arrays and relinquish defaults.

Analog value object instance summary

The following table summarizes the Analog Value Objects supported.

Table 90. Analog value object instance summary

Instance ID	Object name	Description	Units	Preset value access
AV0	Speed Reference	Motor speed reference from network	Percent	C
AV1	Current Limit	Current Limit	Amps	W
AV2	Min Frequency	Minimum Frequency	Hz	W
AV3	Maximum Frequency	Maximum Frequency	Hz	W
AV4	Accel Time 1	Acceleration Time	seconds	W
AV5	Decel Time 1	Deceleration Time	seconds	W
AV6	AnyParam ID	Parameter ID number to be accessed	No Units	W
AV7	AnyParam Value	Value of parameter defined by AV6	No Units	W
AV8	Process Data In 1	Fieldbus Process Data In 1	N/A	C
AV9	Process Data In 2	Fieldbus Process Data In 2	N/A	C
AV10	Process Data In 3	Fieldbus Process Data In 3	N/A	C
AV11	Process Data In 4	Fieldbus Process Data In 4	N/A	C
AV12	Process Data In 5	Fieldbus Process Data In 5	N/A	C
AV13	Process Data In 6	Fieldbus Process Data In 6	N/A	C
AV14	Process Data In 7	Fieldbus Process Data In 7	N/A	C
AV15	Process Data In 8	Fieldbus Process Data In 8	N/A	C

Note: For Present Value Access Types, W = Writeable, C = Commandable.

Commandable values support priority arrays and relinquish defaults.

Analog input object instance summary

The following table summarizes the Analog Input Objects supported.

Table 91. Analog input object instance summary

Instance ID	Object name	Description	Units	Preset value access
AI0	Frequency Setpoint	Frequency Setpoint	Hz	R
AI1	Output Frequency	Output Frequency	Hz	R
AI2	Motor Speed	Motor Speed	Rpm	R
AI3	Motor Load	Motor Load	Percent	R
AI4	Kilowatt Hours total	Kilowatt Hour Counter (Total) scaled by 1000	KWh	R
AI5	Motor Current	Motor Current	Amps	R
AI6	DC link Voltage	DC link Voltage	Volts	R
AI7	Motor Voltage	Motor Voltage	Volts	R
AI8	Unit Temperature	Heatsink Temperature	°C	R
AI9	Motor Torque	In % of motor nominal Torque	Percent	R
AI10	Operating Days	Operating Days (resettable)	Day	R
AI11	Operating Hours	Operating Hours (resettable)	Hour	R
AI12	Motor Temperature	Motor Temperature	Percent	R
AI13	Analog Input 1	Analog Input 1	Volts	R
AI14	Analog Input 2	Analog Input 2	Volts	R
AI15	Analog Output 1	Analog Output 1	Volts	R
AI16	Analog Output 2	Analog Output 2	Volts	R
AI17	Kilowatt Instantaneous	Kilowatt Instantaneous	kW	R
AI18	Process Data Out 1	Fieldbus Process Data Out 1	N/A	R
AI19	Process Data Out 2	Fieldbus Process Data Out 2	N/A	R
AI20	Process Data Out 3	Fieldbus Process Data Out 3	N/A	R
AI21	Process Data Out 4	Fieldbus Process Data Out 4	N/A	R
AI22	Process Data Out 5	Fieldbus Process Data Out 5	N/A	R
AI23	Process Data Out 6	Fieldbus Process Data Out 6	N/A	R
AI24	Process Data Out 7	Fieldbus Process Data Out 7	N/A	R
AI25	Process Data Out 8	Fieldbus Process Data Out 8	N/A	R

Note: For Present Value Access Types, R = Read-only.

Commandable values support priority arrays and relinquish defaults.

Multi state object instance summary

The following table summarizes the Multi State Objects supported.

Table 92. Multi state object instance summary


Instance ID	Object name	Description	State text	Preset value access
MV0	Control Mode	Indicates the Drive Control Mode - Local, Remote or OFF	0 = Local(Hand) / 1 = Remote / 2 = OFF	R
MV1	Active Fault Code	Indicates the Latest Active Fault Code of the Drive	State Text w.r.t the Active Fault Code	R

Note: For Present Value Access Types, R = Read-only.

Commandable values support priority arrays and relinquish defaults.

Fault tracing

Figure 36. Fault tracing



Sensor/actuator bus system protocol

SA bus general information

The SA bus communications protocol is used by Johnson Controls to connect terminal unit controllers to supervisory controllers.

The physical characteristics of the SA bus are three-wire RS-485. Logically, the SA bus is a master-subordinate protocol, the supervisory controller normally being the master. Data is partitioned into common HVAC control objects, such as Analog Input, Analog Value, Binary Value, Multi-State Value. SA bus messaging supports the reading and overriding of these points.

Prepare for use through MS/TP


Refer to **page 28**, Steps 1–3.

WARNING

The relay outputs and other I/O-terminals may have a dangerous control voltage present even when the VSD Series III is disconnected from mains.

SA bus technical data**Table 93. SA bus protocol**

Connection	Communication
Interface	RS-485
Data transfer method	RS-485 MS/TP, half-duplex
Data transfer cable	STP (Shielded Twisted Pair), type Belden or similar
Connector	2.5 mm ²
Electrical isolation	Functional
Baud rate	38400
Addresses	204 to 254

Figure 37. VS3 SA bus parameter navigation

1. First ensure that the right fieldbus protocol is selected.

Navigate:

Main Menu → Parameter → Communication → RS485 Bus → RS-485 Comm Set → Edit →
(Choose Protocol as SA bus)

Wiring diagram

Figure 38. Wiring diagram




Figure 38 shows a typical arrangement with a host computer (master) and any number maximum 31 subordinates of frequency inverters. Each frequency inverter has a unique address in the network. This addressing is executed individually for each VFD via the communication parameters.

The electrical connection between master and the subordinates connected in parallel are implemented via the serial interface A-B (A = positive, B = negative) with a shielded RS-485 twisted pair cable.

Connections

The RS-485 communication port is connected via the A and B terminals on the drives control board.

Figure 39. Terminal wiring





Figure 40. Termination resistor and shielding**Table 94. SA bus menu parameters**

VS3 code	Parameter	Min.	Max.	Unit	Default	ID	Note
P12.3	RS485 Bus						
P12.3.1	Basic Setting						
P12.3.1.1	RS485 Comm Set	0	2		0	586	0 = Modbus RTU 1 = BACnet MS/TP 2 = SA Bus
P12.3.4	SA Bus						
P12.3.4.1	SA Bus Baud Rate	0	4		2	1727	0 = 9600 1 = 19200 2 = 38400 3 = 57600 4 = 115200
P12.3.4.2	SA Bus Device Address	128	254		204	1726	
P12.3.4.3	SA Bus Instance Number	0	4194302		0	1728	
P12.3.4.4	SA Bus Comm Timeout	0	60000		10000	1730	
P12.3.4.5	SA Bus Protocol Status				0	1731	0 = Stopped 1 = Operational 2 = Faulted
P12.3.4.6	SA Bus Fault Response				0	1732	0 = In Fieldbus Control 1 = In all Control

Table 95. SA bus parameter descriptions

Parameter	Parameter name	Description
P12.3.4.1	SA Bus Baud Rate	Select the communication speed for the network. The default value is 38400 baud.
P12.3.4.2	SA Bus Device Address	The address of the device on the network. Each device to have unique address in the network.
P12.3.4.3	SA Bus Instance Number	The Device Object's Instance number is used in conjunction with the MAC address to assign the devices on the network. The instance number can have up to 127 nodes on it before a different instance number is required.
P12.3.4.4	SA Bus Comm Timeout	BACnet board initiates a communication error if the board is a "sole master" in the network for a time defined with this parameter.
P12.3.4.5	SA Bus Protocol Status	Fieldbus Protocol Status tells the status of the protocol.
P12.3.4.6	SA Bus Fault Response	Defines when Fieldbus fault to be raise if fault condition is detected.

Table 96. Object instance summary

Object name	Object description	Object Function	NetDeviceRefAttrID	I/O	Units	States text	Set members
VSD1-C	VSD Command	Run/Stop	Drive Command	Output		Off/On	0=Off 1=On
VSD1-O	VSD Output	Output	Reference Command	Output	%		
VSD1-BYPASS	VSD Bypass Drive	Bypass Enable	Bypass Enable	Output		Off/On	0=Off 1=On
VSD1-RESET	VSD Reset Drive Fault	Reset Drive Fault	Reset Drive Fault	Output		Off/Reset	0=Off 1=Reset
VSD1-%	VSD Speed Feedback	Speed Setpoint	Speed Setpoint	Input	%		
VSD1-FAULT	VSD Fault Code	Fault Code	Fault Code	Input		Drive Fault	Fault Code
VSD1-HOA	VSD Control Mode	Control Mode	Control Mode	Input		Hand Off Auto	0=Hand 1=Off 2=Auto
VSD1-HZ	VSD Output Frequency	Frequency	Output Frequency	Input	Hz		
VSD1-KWH	VSD Kilowatt Hours	Kilowatt Hours	Kilowatt Hours	Input	kWh		
VSD1-RPM	VSD Motor Speed	Motor Speed	Motor Speed	Input	rpm		
VSD1-S	VSD Status	Status	Drive Running	Input		Off/On	0=Off 1=On

Attribute descriptions

Drive Command

This attribute is an object reference to a Binary Value object that represents the Drive Command parameter of the DRIVE. The VSD will monitor any write to the Present Value attribute of this object and forward the updated value to the associated property in the DRIVE. A read of the Present Value of this object will only get what was last written and not the current state of the property in the DRIVE. The Present Value of this object is a Boolean that when written will forward a 0-Stop or 1-Run command to the DRIVE.

Reference Command

This attribute is an object reference to an Analog Value object that represents the Reference Command parameter of the DRIVE. The VSD will monitor any write to the Present Value attribute of this object and forward the updated value to the associated parameter in the DRIVE. A read of the Present Value of this object will only get what was last written and not the current state of the parameter in the DRIVE. The Present Value of this object is a Float 32 that when written will forward 0 to 100 percent command to change the speed of the DRIVE.

Bypass Drive

This attribute is an object reference to a Binary Value object that represents the Bypass Drive parameter of the DRIVE. The VSD will monitor any write to the Present Value attribute of this object and forward the updated value to the associated property in the DRIVE. A read of the Present Value of this object will only get what was last written and not the current state of the property in the DRIVE. The Present Value of this object is a Boolean that when written will forward a 0-False (bypass disabled) or 1-True (bypass enabled) command to the DRIVE.

Reset Drive Fault

This attribute is an object reference to a Binary Value object that represents the Reset Drive Fault parameter of the DRIVE. The VSD will monitor any write to the Present Value attribute of this object and forward the updated value to the associated property in the DRIVE. A read of the Present Value of this object will only get what was last written and not the current state of the property in the DRIVE. The Present Value of this object is a Boolean that when written will forward a 0-N/A (do nothing) or 1-Reset command to the DRIVE. The Reset command will reset the DRIVE Fault Code parameter to "0-No Fault". The DRIVE will re-evaluate the fault condition after being sent a reset drive fault command.

Speed Feedback

This attribute is an object reference to an Analog Input object that represents the Speed Setpoint parameter of the DRIVE. The DRIVE supplies the VSD object with the Present Value.

Fault Code

This attribute is an object reference to a Multi-State Value object that represents the Fault Code parameter of the DRIVE. The DRIVE supplies the VSD object with the Present Value. The Present Value of this object is an enumeration with 21 states. All fault codes 21 or above will report as Drive Fault. Field Service would need to look at the DRIVE keypad for more diagnostic details.

Control Mode

This attribute is an object reference to a Multi-State Value object that represents the Control Mode parameter of the DRIVE. The DRIVE supplies the VSD object with the Present Value. The Present Value of this object is an enumeration with 3 states of 0-Hand, 1-Off, and 2-Auto.

Output Frequency

This attribute is an object reference to an Analog Input object that represents the Output Frequency parameter of the DRIVE. The DRIVE supplies the VSD object with Present Value.

Kilowatt Hours

This attribute is an object reference to an Analog Input object that represents the Kilowatt Hours parameter of the DRIVE. The DRIVE supplies the VSD object with the Present Value.

Motor Speed

This attribute is an object reference to an Analog Input object that represents the Motor Speed parameter of the DRIVE. The DRIVE supplies the VSD object with the Present Value.

Drive Running

This attribute is an object reference to a Binary Value object that represents the Drive Running parameter of the DRIVE. The DRIVE supplies the VSD object with the Present Value. The Present Value of this object is a Boolean where 0-False means that the drive is not running and 1-True means that the drive is running.

Appendix A—Parameter ID list

Parameter descriptions

Table 97. VS3 Parameter ID list

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
M1.1	1	502	0	Output Frequency	INTEGER	2	x100
M1.2	24	1	0	Freq Reference	INTEGER	2	x100
M1.3	2	503	0	Motor Speed	INTEGER	2	x0
M1.4	3	504	0	Motor Current	INTEGER	2	x10
M1.5	4	507	0	Motor Torque	INTEGER	2	x10
M1.6	5	513	1	Motor Power	INTEGER	2	x10
M1.7	6	501	0	Motor Voltage	INTEGER	2	x10
M1.8	7	501	1	DC-link Voltage	INTEGER	2	x0
M1.9	8	822	6	Unit Temperature	INTEGER	2	x10
M1.10	9	822	4	Motor Temperature	INTEGER	2	x10
M1.11	28	NA	NA	Latest Fault Code	BYTE	1	x0
M1.12	1686	NA	NA	Instant Motor Power	DOUBLE	4	x1000
M1.13	583	790	0	RTC Battery Status	BYTE	1	x0
M2.1	10	560	0	Analog Input 1	INTEGER	2	x100
M2.2	11	560	1	Analog Input 2	INTEGER	2	x100
M2.3	25	570	0	Analog Output 1	INTEGER	2	x100
M2.4	575	570	1	Analog Output 2	INTEGER	2	x100
M2.5	12	760	0	DI1, DI2, DI3	BYTE	1	x0
M2.6	13	760	1	DI4, DI5, DI6	BYTE	1	x0
M2.7	576	760	2	DI7, DI8	BYTE	1	x0
M2.8	14	754	0	DO1,Virtual RO1,Virtual RO2	BYTE	1	x0
M2.9	557	762	0	RO1, RO2, RO3	BYTE	1	x0
M3.1	27	580	0	PT100 Temperture	INTEGER	2	x10
M4.1	2120	NA	NA	Energy Savings	DOUBLE	4	x1000
M5.1	2209	NA	NA	Control Board DIDO Status	INTEGER	2	x0
M5.2	2210	NA	NA	SlotA DIDO Status	INTEGER	2	x0
M5.3	2211	NA	NA	SlotB DIDO Status	INTEGER	2	x0
M5.4	29	NA	NA	Application Status Word	INTEGER	2	x0
M5.5	2414	NA	NA	Standard Status Word	INTEGER	2	x0
M6.1	16	2150	0	PID1 Set Point	DOUBLE	4	x100
M6.2	18	2864	0	PID1 Feedback	DOUBLE	4	x100
M6.3	20	2167	0	PID1 Error Value	DOUBLE	4	x100
M6.4	22	2124	0	PID1 Output	INTEGER	2	x100
M6.5	23	2133	0	PID1 Status	BYTE	1	x0
M6.6	32	2150	1	PID2 Set Point	DOUBLE	4	x100
M6.7	34	2864	1	PID2 Feedback	DOUBLE	4	x100
M6.8	36	2167	1	PID2 Error Value	DOUBLE	4	x100
M6.9	38	2124	1	PID2 Output	INTEGER	2	x100
M6.10	39	2133	1	PID2 Status	BYTE	1	x0
M7.1	558	763	0	TC1, TC2, TC3	BYTE	1	x0
M7.2	559	3125	0	Interval 1	BOOLEAN	1	x0
M7.3	560	3125	1	Interval 2	BOOLEAN	1	x0
M7.4	561	3125	2	Interval 3	BOOLEAN	1	x0
M7.5	562	3125	3	Interval 4	BOOLEAN	1	x0
M7.6	563	3125	4	Interval 5	BOOLEAN	1	x0
M7.7	569	3101	0	Timer 1	DOUBLE	4	x0
M7.8	571	3101	1	Timer 2	DOUBLE	4	x0

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
M7.9	573	3101	2	Timer 3	DOUBLE	4	x0
M8.1	2445	NA	NA	Output	DOUBLE	4	x100
M8.2	2447	NA	NA	Reference	DOUBLE	4	x100
M9.1	601	520	2	Total MWh Count	DOUBLE	4	x10000
M9.2	603	522	0	Total Power Day Count	INTEGER	2	x0
M9.3	606	821	1	Total Power Hr Count	DOUBLE	4	x0
M9.4	604	806	0	Trip MWh Count	DOUBLE	4	x10000
M9.5	636	870	0	Trip Power Day Count	INTEGER	2	x0
M9.6	637	871	0	Trip Power Hr Count	DOUBLE	4	x0
M10.1	30	329	0	Multi-Monitoring	BYTE	3	x0
P1.1	101	20	0	Min Frequency	INTEGER	2	x100
P1.2	102	20	1	Max Frequency	INTEGER	2	x100
P1.3	103	130	0	Accel Time 1	INTEGER	2	x10
P1.4	104	134	0	Decel Time 1	INTEGER	2	x10
P1.5	486	210	0	Motor Nom Current	INTEGER	2	x10
P1.6	489	217	0	Motor Nom Speed	INTEGER	2	x0
P1.7	490	215	0	Motor PF	INTEGER	2	x100
P1.8	487	211	0	Motor Nom Voltage	INTEGER	2	x0
P1.9	488	216	0	Motor Nom Frequency	INTEGER	2	x100
P1.10	2465	NA	NA	HOA Source	BYTE	1	x0
P1.11	1695	NA	NA	Hand Control Place	BYTE	1	x0
P1.12	136	436	0	Hand Reference	BYTE	1	x0
P1.13	135	408	0	Auto 1 Control Place	BYTE	1	x0
P1.14	137	437	0	Auto 1 Reference	BYTE	1	x0
P1.15	138	408	1	Auto 2 Control Place	BYTE	1	x0
P1.16	139	437	1	Auto 2 Reference	BYTE	1	x0
P2.1.1	483	636	0	Damper Start	BYTE	1	x0
P2.1.2	484	118	0	Damper Time Out	INTEGER	2	x0
P2.1.3	485	118	1	Damper Delay	INTEGER	2	x0
P2.1.4	144	35	1	AI Ref Scale Min Value	INTEGER	2	x100
P2.1.5	145	34	1	AI Ref Scale Max Value	INTEGER	2	x100
P2.2.1	143	425	0	IO Terminal 1 Start Stop Logic	BYTE	1	x0
P2.2.2	190	414	0	IO Terminal 1 Start Signal 1	BYTE	1	x0
P2.2.3	191	414	1	IO Terminal 1 Start Signal 2	BYTE	1	x0
P2.2.4	2206	NA	NA	IO Terminal 2 Start Stop Logic	BYTE	1	x0
P2.2.5	2207	NA	NA	IO Terminal 2 Start Signal 1	BYTE	1	x0
P2.2.6	2208	NA	NA	IO Terminal 2 Start Signal 2	BYTE	1	x0
P2.2.7	881	409	0	Thermistor Input Select	BYTE	1	x0
P2.2.8	198	421	2	Reverse	BYTE	1	x0
P2.2.9	192	446	0	Ext. Fault 1 NO	BYTE	1	x0
P2.2.10	193	447	0	Ext. Fault 1 NC	BYTE	1	x0
P2.2.11	2297	NA	NA	Ext. Fault 1 Text	BYTE	1	x0
P2.2.12	2293	NA	NA	Ext. Fault 2 NO	BYTE	1	x0
P2.2.13	2294	NA	NA	Ext. Fault 2 NC	BYTE	1	x0
P2.2.14	2298	NA	NA	Ext. Fault 2 Text	BYTE	1	x0
P2.2.15	2295	NA	NA	Ext. Fault 3 NO	BYTE	1	x0
P2.2.16	2296	NA	NA	Ext. Fault 3 NC	BYTE	1	x0
P2.2.17	2299	NA	NA	Ext. Fault 3 Text	BYTE	1	x0
P2.2.18	200	400	7	Fault Reset	BYTE	1	x0
P2.2.19	194	400	16	Run Enable	BYTE	1	x0
P2.2.20	205	432	0	Preset Speed B0	BYTE	1	x0

Appendix A—Parameter ID list

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P2.2.21	206	432	1	Preset Speed B1	BYTE	1	x0
P2.2.22	207	432	2	Preset Speed B2	BYTE	1	x0
P2.2.23	199	400	8	Jog Enable	BYTE	1	x0
P2.2.24	195	435	0	Accel/Decel Time Set	BYTE	1	x0
P2.2.25	201	400	5	Accel/Decel Prohibit	BYTE	1	x0
P2.2.26	215	402	5	No Access To Param	BYTE	1	x0
P2.2.27	196	406	0	Auto Control	BYTE	1	x0
P2.2.28	197	406	1	Hand Control	BYTE	1	x0
P2.2.29	209	407	0	Auto 1/2 Select	BYTE	1	x0
P2.2.30	2395	NA	NA	HOA On/Off	BYTE	1	x0
P2.2.31	217	417	0	Second Motor Para Select	BYTE	1	x0
P2.2.32	2312	NA	NA	Parameter Set1/2 Sel	BYTE	1	x0
P2.2.33	208	415	0	AI Ref Source Select	BYTE	1	x0
P2.2.34	218	NA	NA	Bypass Start	BYTE	1	x0
P2.2.35	1246	1804	0	Bypass Overload	BYTE	1	x0
P2.2.36	550	2134	0	PID1 Control Enable	BYTE	1	x0
P2.2.37	553	2134	1	PID2 Control Enable	BYTE	1	x0
P2.2.38	351	410	0	PID1 Set Point Select	BYTE	1	x0
P2.2.39	352	410	1	PID2 Set Point Select	BYTE	1	x0
P2.2.40	202	402	4	DC Brake Active	BYTE	1	x0
P2.2.41	219	402	2	Smoke Mode	BYTE	1	x0
P2.2.42	220	402	3	Fire Mode	BYTE	1	x0
P2.2.43	221	439	0	Fire Mode Ref 1/2 Select	BYTE	1	x0
P2.2.44	2119	NA	NA	Fire Mode Reverse	BYTE	1	x0
P2.2.45	224	3104	0	Start Timer 1	BYTE	1	x0
P2.2.46	225	3104	1	Start Timer 2	BYTE	1	x0
P2.2.47	226	3104	2	Start Timer 3	BYTE	1	x0
P2.3.1	105	5	1	Preset Speed 1	INTEGER	2	x100
P2.3.2	106	5	2	Preset Speed 2	INTEGER	2	x100
P2.3.3	118	5	3	Preset Speed 3	INTEGER	2	x100
P2.3.4	119	5	4	Preset Speed 4	INTEGER	2	x100
P2.3.5	120	5	5	Preset Speed 5	INTEGER	2	x100
P2.3.6	121	5	6	Preset Speed 6	INTEGER	2	x100
P2.3.7	122	5	7	Preset Speed 7	INTEGER	2	x100
P2.3.8	117	1	9	Jog Reference	INTEGER	2	x100
P2.4.1	222	263	0	AI1 Mode	BYTE	1	x0
P2.4.2	175	260	0	AI1 Signal Range	BYTE	1	x0
P2.4.3	176	264	0	AI1 Custom Min	INTEGER	2	x100
P2.4.4	177	265	0	AI1 Custom Max	INTEGER	2	x100
P2.4.5	174	266	0	AI1 Filter Time	INTEGER	2	x100
P2.4.6	181	267	0	AI1 Signal Invert	BOOLEAN	1	x0
P2.4.7	178	1711	0	AI1 Joystick Hyst	INTEGER	2	x100
P2.4.8	179	1720	0	AI1 Sleep Limit	INTEGER	2	x100
P2.4.9	180	1721	0	AI1 Sleep Delay	INTEGER	2	x100
P2.4.10	133	1712	0	AI1 Joystick Offset	INTEGER	2	x100
P2.5.1	223	263	1	AI2 Mode	BYTE	1	x0
P2.5.2	183	260	1	AI2 Signal Range	BYTE	1	x0
P2.5.3	184	264	1	AI2 Custom Min	INTEGER	2	x100
P2.5.4	185	265	1	AI2 Custom Max	INTEGER	2	x100
P2.5.5	182	266	1	AI2 Filter Time	INTEGER	2	x100
P2.5.6	189	267	1	AI2 Signal Invert	BOOLEAN	1	x0

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P2.5.7	186	1711	1	AI2 Joystick Hyst	INTEGER	2	x100
P2.5.8	187	1720	1	AI2 Sleep Limit	INTEGER	2	x100
P2.5.9	188	1721	1	AI2 Sleep Delay	INTEGER	2	x100
P2.5.10	134	1712	1	AI2 Joystick Offset	INTEGER	2	x100
P3.1.1	151	461	0	DO1 Function	BYTE	1	x0
P3.1.2	152	451	0	RO1 Function	BYTE	1	x0
P3.1.3	2112	NA	NA	RO1 On Delay	INTEGER	2	x10
P3.1.4	2113	NA	NA	RO1 Off Delay	INTEGER	2	x10
P3.1.5	153	451	1	RO2 Function	BYTE	1	x0
P3.1.6	2114	NA	NA	RO2 On Delay	INTEGER	2	x10
P3.1.7	2115	NA	NA	RO2 Off Delay	INTEGER	2	x10
P3.1.8	538	451	2	RO3 Function	BYTE	1	x0
P3.1.9	2116	NA	NA	RO3 On Delay	INTEGER	2	x10
P3.1.10	2117	NA	NA	RO3 Off Delay	INTEGER	2	x10
P3.1.11	2118	NA	NA	RO3 Reverse	BYTE	1	x0
P3.1.12	2463	NA	NA	Virtual RO1 Function	BYTE	1	x0
P3.1.13	2464	NA	NA	Virtual RO2 Function	BYTE	1	x0
P3.2.1	154	1201	0	Freq Limit 1 Supv	BYTE	1	x0
P3.2.2	155	1101	0	Freq Limit 1 Supv Val	INTEGER	2	x100
P3.2.3	2200	NA	NA	Freq Limit 1 Supv Hyst	INTEGER	2	x100
P3.2.4	157	1201	1	Freq Limit 2 Supv	BYTE	1	x0
P3.2.5	158	1101	1	Freq Limit 2 Supv Val	INTEGER	2	x100
P3.2.6	2201	NA	NA	Freq Limit 2 Supv Hyst	INTEGER	2	x100
P3.2.7	159	1202	0	Torque Limit Supv	BYTE	1	x0
P3.2.8	160	1102	0	Torque Limit Supv Val	INTEGER	2	x10
P3.2.9	2202	NA	NA	Torque Limit Supv Hyst	INTEGER	2	x10
P3.2.10	161	1200	0	Ref Limit Supv	BYTE	1	x0
P3.2.11	162	1100	0	Ref Limit Supv Val	INTEGER	2	x100
P3.2.12	2203	NA	NA	Ref Limit Supv Hyst	INTEGER	2	x100
P3.2.13	165	1222	1	Temp Limit Supv	BYTE	1	x0
P3.2.14	166	822	0	Temp Limit Supv Val	INTEGER	2	x10
P3.2.15	2204	NA	NA	Temp Limit Supv Hyst	INTEGER	2	x10
P3.2.16	167	1203	0	Power Limit Supv	BYTE	1	x0
P3.2.17	168	1103	0	Power Limit Supv Val	INTEGER	2	x10
P3.2.18	2205	NA	NA	Power Limit Supv Hyst	INTEGER	2	x10
P3.2.19	170	1504	0	AI Supv Select	BYTE	1	x0
P3.2.20	171	1204	0	AI Limit Supv	BYTE	1	x0
P3.2.21	172	1404	0	AI Limit Supv Val	INTEGER	2	x100
P3.2.22	2198	NA	NA	AI Supv Hyst	INTEGER	2	x100
P3.2.23	2189	NA	NA	Motor Current 1 Supv	BYTE	1	x0
P3.2.24	2190	NA	NA	Motor Current 1 Supv Value	INTEGER	2	x10
P3.2.25	2196	NA	NA	Motor Current 1 Supv Hyst	BYTE	1	x10
P3.2.26	2191	NA	NA	Motor Current 2 Supv	BYTE	1	x0
P3.2.27	2192	NA	NA	Motor Current 2 Supv Value	INTEGER	2	x10
P3.2.28	2197	NA	NA	Motor Current 2 Supv Hyst	BYTE	1	x10
P3.2.29	2193	NA	NA	Second AI Supv Select	BYTE	1	x0
P3.2.30	2194	NA	NA	Second AI Limit Supv	BYTE	1	x0
P3.2.31	2195	NA	NA	Second AI Limit Supv Val	INTEGER	2	x100
P3.2.32	2199	NA	NA	Second AI Supv Hyst	INTEGER	2	x100
P3.2.33	1346	2860	0	PID1 Superv Enable	BOOLEAN	1	x0
P3.2.34	1347	2861	0	PID1 Superv Upper Limit	DOUBLE	4	x100

Appendix A—Parameter ID list

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P3.2.35	1349	2862	0	PID1 Superv Lower Limit	DOUBLE	4	x100
P3.2.36	1351	2863	0	PID1 Superv Delay	INTEGER	2	x0
P3.2.37	1408	2860	1	PID2 Superv Enable	BOOLEAN	1	x0
P3.2.38	1409	2861	1	PID2 Superv Upper Limit	DOUBLE	4	x100
P3.2.39	1411	2862	1	PID2 Superv Lower Limit	DOUBLE	4	x100
P3.2.40	1413	2863	1	PID2 Superv Delay	INTEGER	2	x0
P3.3.1	227	276	0	A01 Mode	BYTE	1	x0
P3.3.2	146	460	0	A01 Function	BYTE	1	x0
P3.3.3	149	279	0	A01 Minimum	BYTE	1	x0
P3.3.4	147	277	0	A01 Filter Time	INTEGER	2	x100
P3.3.5	150	274	0	A01 Scale	INTEGER	2	x0
P3.3.6	148	278	0	A01 Inversion	BOOLEAN	1	x0
P3.3.7	173	275	0	A01 Offset	INTEGER	2	x100
P3.4.1	228	276	1	A02 Mode	BYTE	1	x0
P3.4.2	229	460	1	A02 Function	BYTE	1	x0
P3.4.3	232	279	1	A02 Minimum	BYTE	1	x0
P3.4.4	230	277	1	A02 Filter Time	INTEGER	2	x100
P3.4.5	233	274	1	A02 Scale	INTEGER	2	x0
P3.4.6	231	278	1	A02 Inversion	BOOLEAN	1	x0
P3.4.7	234	275	1	A02 Offset	INTEGER	2	x100
P3.5.1	751	2002	0	Logic Function Select	BYTE	1	x0
P3.5.2	752	2000	0	Logic Operation Input A	BYTE	1	x0
P3.5.3	753	2001	0	Logic Operation Input B	BYTE	1	x0
P4.1.1	141	1	8	Keypad Reference	INTEGER	2	x100
P4.1.2	116	621	1	Keypad Direction	BOOLEAN	1	x0
P4.1.3	114	622	1	Keypad Stop	BOOLEAN	1	x0
P4.1.4	1724	NA	NA	Hand Key Enable	BYTE	1	x0
P4.1.5	1679	622	3	Reverse Enable	BYTE	1	x0
P4.1.6	2515	NA	NA	Change Phase Sequence Motor	BYTE	1	x0
P4.1.7	1685	NA	NA	Power Up HOA Select	BYTE	1	x0
P4.1.8	2462	NA	NA	Bumpless Enable	BYTE	1	x0
P4.1.9	2423	NA	NA	Run Delay Time	INTEGER	2	x0
P4.1.10	252	620	0	Start Mode	BYTE	1	x0
P4.1.11	253	620	1	Stop Mode	BYTE	1	x0
P4.1.12	247	117	0	Ramp 1 Shape	INTEGER	2	x10
P4.1.13	248	117	1	Ramp 2 Shape	INTEGER	2	x10
P4.1.14	249	130	1	Accel Time 2	INTEGER	2	x10
P4.1.15	250	134	1	Decel Time 2	INTEGER	2	x10
P4.1.16	267	639	0	Power Loss Function	BYTE	1	x0
P4.1.17	268	151	0	Power Loss Time	INTEGER	2	x10
P4.1.18	2444	NA	NA	2nd Stage Ramp Frequency	INTEGER	2	x100
P4.2.1	254	2227	0	DC-Brake Current	INTEGER	2	x10
P4.2.2	263	2222	0	Start DC-Brake Time	INTEGER	2	x100
P4.2.3	262	2223	0	Stop DC-Brake Frequency	INTEGER	2	x100
P4.2.4	255	2222	1	Stop DC-Brake Time	INTEGER	2	x100
P4.2.5	251	2204	0	Brake Chopper Define	BYTE	1	x0
P4.2.6	266	2214	0	Flux Brake	BOOLEAN	1	x0
P4.2.7	265	2217	0	Flux Brake Current	INTEGER	2	x10
P4.3.1	264	43	0	Skip Range Ramp Factor	INTEGER	2	x10
P4.3.2	256	41	0	Skip F1 Low Limit	INTEGER	2	x100
P4.3.3	257	42	0	Skip F1 High Limit	INTEGER	2	x100

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P4.3.4	258	41	1	Skip F2 Low Limit	INTEGER	2	x100
P4.3.5	259	42	1	Skip F2 High Limit	INTEGER	2	x100
P4.3.6	260	41	2	Skip F3 Low Limit	INTEGER	2	x100
P4.3.7	261	42	2	Skip F3 High Limit	INTEGER	2	x100
P4.4.1	2122	NA	NA	Currency	BYTE	1	x0
P4.4.2	2123	NA	NA	Energy Cost	INTEGER	2	x100
P4.4.3	2124	NA	NA	Data Type	BYTE	1	x0
P4.4.4	2125	NA	NA	Energy Savings Reset	BYTE	1	x0
P5.1.1	287	255	0	Motor Control Mode	BYTE	1	x0
P5.1.2	107	281	0	Current Limit	INTEGER	2	x10
P5.1.3	109	60	0	V/Hz Optimization	BOOLEAN	1	x0
P5.1.4	108	61	0	V/Hz Ratio	BYTE	1	x0
P5.1.5	289	23	0	Field Weakening Point	INTEGER	2	x100
P5.1.6	290	24	0	Voltage at FWP	INTEGER	2	x100
P5.1.7	291	23	1	V/Hz Mid Frequency	INTEGER	2	x100
P5.1.8	292	24	1	V/Hz Mid Voltage	INTEGER	2	x100
P5.1.9	293	27	0	Zero Frequency Voltage	INTEGER	2	x100
P5.1.10	2522	NA	NA	Switching Frequency	INTEGER	2	x10
P5.1.11	1665	341	0	Sine Filter Enable	BYTE	1	x0
P5.1.12	294	626	3	OverVoltage Control	BYTE	1	x0
P5.1.13	298	2901	0	Load Drooping	INTEGER	2	x100
P5.1.14	1630	2902	0	Droop Control Filter Time Constant	INTEGER	2	x0
P5.2.1	577	210	1	Motor Nom Current 2	INTEGER	2	x10
P5.2.2	578	217	1	Motor Nom Speed 2	INTEGER	2	x0
P5.2.3	579	215	1	Motor PF 2	INTEGER	2	x100
P5.2.4	580	211	1	Motor Nom Volt 2	INTEGER	2	x0
P5.2.5	581	216	1	Motor Nom Freq 2	INTEGER	2	x100
P6.1.1	308	840	9040	Output Phase Fault	BYTE	1	x0
P6.1.2	309	840	9008	Ground Fault	BYTE	1	x0
P6.1.3	2158	NA	NA	Ground Fault Limit	BYTE	1	x0
P6.1.4	310	840	17168	Motor Thermal Protection	BYTE	1	x0
P6.1.5	311	1012	0	Motor Thermal F0 Current	INTEGER	2	x10
P6.1.6	312	1011	0	Motor Thermal Time	BYTE	1	x0
P6.1.7	313	840	28963	Stall Protection	BYTE	1	x0
P6.1.8	314	1010	0	Stall Current Limit	INTEGER	2	x10
P6.1.9	315	1010	1	Stall Time Limit	INTEGER	2	x10
P6.1.10	316	1010	2	Stall Frequency Limit	INTEGER	2	x100
P6.1.11	317	840	28979	Underload Protection	BYTE	1	x0
P6.1.12	318	1013	0	Underload Fnom Torque	INTEGER	2	x10
P6.1.13	319	1013	1	Underload F0 Torque	INTEGER	2	x10
P6.1.14	320	1011	1	Underload Time Limit	INTEGER	2	x100
P6.1.15	333	840	28978	Thermistor Fault Response	BYTE	1	x0
P6.1.16	337	840	29536	PT100 Fault Response	BYTE	1	x0
P6.1.17	2159	NA	NA	Preheat Mode	BYTE	1	x0
P6.1.18	2160	NA	NA	Preheat Control Source	BYTE	1	x0
P6.1.19	2161	NA	NA	Preheat Enter Temp	INTEGER	2	x10
P6.1.20	2162	NA	NA	Preheat Quit Temp	INTEGER	2	x10
P6.1.21	2163	NA	NA	Preheat Output Volt	BYTE	1	x0
P6.2.1	750	861	0	Line Start Lockout	BYTE	1	x0
P6.2.2	2483	NA	NA	Fault Reset Start	BYTE	1	x0
P6.2.3	306	840	29520	4mA Input Fault	BYTE	1	x0

Appendix A—Parameter ID list

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P6.2.4	331	1	7	4mA Fault Frequency	INTEGER	2	x100
P6.2.5	307	840	36864	External Fault	BYTE	1	x0
P6.2.6	332	840	12592	Input Phase Fault	BYTE	1	x0
P6.2.7	330	840	12576	Uvoltage Fault Response	BYTE	1	x0
P6.2.8	1564	840	16912	Unit Under Temp Prot	BYTE	1	x0
P6.2.9	955	840	35344	RTC Fault	BYTE	1	x0
P6.2.10	1256	840	35345	Replace Battery Fault Response	BYTE	1	x0
P6.2.11	1257	840	28688	Replace Fan Fault Response	BYTE	1	x0
P6.2.12	2126	NA	NA	Cold Weather Mode	BYTE	1	x0
P6.2.13	2127	NA	NA	Cold Weather Volt. Level	BYTE	1	x10
P6.2.14	2128	NA	NA	Cold Weather Time Out	BYTE	1	x0
P6.2.15	2129	NA	NA	Cold Weather Password	INTEGER	2	x0
P6.2.16	2130	NA	NA	Under Temp Fault Override	BYTE	1	x0
P6.2.17	2427	NA	NA	STO Fault Response	BYTE	1	x0
P6.3.1	334	840	29953	Fieldbus Fault Response	BYTE	1	x0
P6.3.2	335	840	35088	OPTCard Fault Response	BYTE	1	x0
P6.3.3	1678	840	30070	IP Address Conflicition Resp	BYTE	1	x0
P6.3.4	2157	NA	NA	Keypad Comm Fault Response	BYTE	1	x0
P6.4.1	321	846	0	AR Wait Time	INTEGER	2	x100
P6.4.2	322	846	1	AR Trail Time	INTEGER	2	x100
P6.4.3	323	847	0	AR Start Function	BYTE	1	x0
P6.4.4	324	845	12832	Undervoltage Attempts	BYTE	1	x0
P6.4.5	325	845	12816	OverVoltage Attempts	BYTE	1	x0
P6.4.6	326	845	8736	OverCurrent Attempts	BYTE	1	x0
P6.4.7	327	845	29520	4mA Fault Attempts	BYTE	1	x0
P6.4.8	329	845	28978	Motor Temp Fault Attempts	BYTE	1	x0
P6.4.9	328	845	36864	External Fault Attempts	BYTE	1	x0
P6.4.10	336	845	28979	Underload Attempts	BYTE	1	x0
P7.1.1	1294	2100	0	PID1 Control Gain	INTEGER	2	x100
P7.1.2	1295	2101	0	PID1 Control ITime	INTEGER	2	x100
P7.1.3	1296	2102	0	PID1 Control DTime	INTEGER	2	x100
P7.1.4	1297	2870	0	PID1 Process Unit	BYTE	1	x0
P7.1.5	1298	2871	0	PID1 Process Unit Min	DOUBLE	4	x100
P7.1.6	1300	2872	0	PID1 Process Unit Max	DOUBLE	4	x100
P7.1.7	1302	2873	0	PID1 Process Unit Decimal	BYTE	1	x0
P7.1.8	1303	2850	0	PID1 Error Inversion	BOOLEAN	1	x0
P7.1.9	1304	2851	0	PID1 Dead Band	DOUBLE	4	x100
P7.1.10	1306	2852	0	PID1 Dead Band Delay	INTEGER	2	x100
P7.1.11	1311	2151	0	PID1 Ramp Time	INTEGER	2	x100
P7.2.1	2542	NA	NA	FB PID1 Set Point 1	DOUBLE	4	x100
P7.2.2	2544	NA	NA	FB PID1 Set Point 2	DOUBLE	4	x100
P7.2.3	2550	NA	NA	FB PID1 Feedback 1	INTEGER	2	x100
P7.2.4	2551	NA	NA	FB PID1 Feedback 2	INTEGER	2	x100
P7.2.5	2554	NA	NA	FB PID1 Feedforward 1	INTEGER	2	x100
P7.2.6	2555	NA	NA	FB PID1 Feedforward 2	INTEGER	2	x100
P7.3.1.1	1307	2170	0	PID1 Keypad Set Point 1	DOUBLE	4	x100
P7.3.1.2	1309	2179	0	PID1 Keypad Set Point 2	DOUBLE	4	x100
P7.3.1.3	2466	NA	NA	PID1 Wake Up Action	BYTE	1	x0
P7.3.2.1	1312	2110	0	PID1 Set Point 1 Source	BYTE	1	x0
P7.3.2.2	1313	2168	0	PID1 Set Point 1 Min	INTEGER	2	x100
P7.3.2.3	1314	2169	0	PID1 Set Point 1 Max	INTEGER	2	x100

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P7.3.2.4	1315	2136	0	PID1 Set Point 1 Sleep Enable	BOOLEAN	1	x0
P7.3.2.5	2396	NA	NA	PID1 Set Point 1 Sleep Unit Sel	BYTE	1	x0
P7.3.2.6	2450	2137	0	PID1 Set Point 1 Sleep Level	DOUBLE	4	x100
P7.3.2.7	1317	2138	0	PID1 Set Point 1 Sleep Delay	INTEGER	2	x0
P7.3.2.8	1318	2139	0	PID1 Set Point 1 Wake Up Level	DOUBLE	4	x100
P7.3.2.9	1320	2154	0	PID1 Set Point 1 Boost	BYTE	1	x10
P7.3.2.10	1352	2830	0	PID1 Set Point 1 Comp Enable	BOOLEAN	1	x0
P7.3.2.11	1353	2831	0	PID1 Set Point 1 Comp Max	INTEGER	2	x100
P7.3.3.1	1321	2116	0	PID1 Set Point 2 Source	BYTE	1	x0
P7.3.3.2	1322	2177	0	PID1 Set Point 2 Min	INTEGER	2	x100
P7.3.3.3	1323	2178	0	PID1 Set Point 2 Max	INTEGER	2	x100
P7.3.3.4	1324	2140	0	PID1 Set Point 2 Sleep Enable	BOOLEAN	1	x0
P7.3.3.5	2397	NA	NA	PID1 Set Point 2 Sleep Unit Sel	BYTE	1	x0
P7.3.3.6	2452	2141	0	PID1 Set Point 2 Sleep Level	DOUBLE	4	x100
P7.3.3.7	1326	2142	0	PID1 Set Point 2 Sleep Delay	INTEGER	2	x0
P7.3.3.8	1327	2143	0	PID1 Set Point 2 Wake Up Level	DOUBLE	4	x100
P7.3.3.9	1329	2157	0	PID1 Set Point 2 Boost	BYTE	1	x10
P7.3.3.10	1354	2835	0	PID1 Set Point 2 Comp Enable	BOOLEAN	1	x0
P7.3.3.11	1355	2836	0	PID1 Set Point 2 Comp Max	INTEGER	2	x100
P7.4.1.1	1330	2171	0	PID1 Feedback Function	BYTE	1	x0
P7.4.1.2	1331	2153	0	PID1 Feedback Gain	INTEGER	2	x10
P7.4.2.1	1332	2112	0	PID1 Feedback 1 Source	BYTE	1	x0
P7.4.2.2	1333	2172	0	PID1 Feedback 1 Min	INTEGER	2	x100
P7.4.2.3	1334	2173	0	PID1 Feedback 1 Max	INTEGER	2	x100
P7.4.3.1	1335	2117	0	PID1 Feedback 2 Source	BYTE	1	x0
P7.4.3.2	1336	2181	0	PID1 Feedback 2 Min	INTEGER	2	x100
P7.4.3.3	1337	2182	0	PID1 Feedback 2 Max	INTEGER	2	x100
P7.5.1.1	1338	2800	0	PID1 Feedforward Func	BYTE	1	x0
P7.5.1.2	1339	2801	0	PID1 Feedforward Gain	INTEGER	2	x10
P7.5.2.1	1340	2810	0	PID1 Feedforward 1 Source	BYTE	1	x0
P7.5.2.2	1341	2811	0	PID1 Feedforward 1 Min	INTEGER	2	x100
P7.5.2.3	1342	2812	0	PID1 Feedforward 1 Max	INTEGER	2	x100
P7.5.3.1	1343	2815	0	PID1 Feedforward 2 Source	BYTE	1	x0
P7.5.3.2	1344	2816	0	PID1 Feedforward 2 Min	INTEGER	2	x100
P7.5.3.3	1345	2817	0	PID1 Feedforward 2 Max	INTEGER	2	x100
P8.1.1	1356	2100	1	PID2 Control Gain	INTEGER	2	x100
P8.1.2	1357	2101	1	PID2 Control I Time	INTEGER	2	x100
P8.1.3	1358	2102	1	PID2 Control D Time	INTEGER	2	x100
P8.1.4	1359	2870	1	PID2 Process Unit	BYTE	1	x0
P8.1.5	1360	2871	1	PID2 Process Unit Min	DOUBLE	4	x100
P8.1.6	1362	2872	1	PID2 Process Unit Max	DOUBLE	4	x100
P8.1.7	1364	2873	1	PID2 Process Unit Decimal	BYTE	1	x0
P8.1.8	1365	2850	1	PID2 Error Inversion	BOOLEAN	1	x0
P8.1.9	1366	2851	1	PID2 Dead Band	DOUBLE	4	x100
P8.1.10	1368	2852	1	PID2 Dead Band Delay	INTEGER	2	x100
P8.1.11	1373	2151	1	PID2 Ramp Time	INTEGER	2	x100
P8.2.1	2467	NA	NA	PID2 Wake Up Action	BYTE	1	x0
P8.2.2	2546	NA	NA	FB PID2 Set Point 1	DOUBLE	4	x100
P8.2.3	2548	NA	NA	FB PID2 Set Point 2	DOUBLE	4	x100
P8.2.4	2552	NA	NA	FB PID2 Feedback 1	INTEGER	2	x100
P8.2.5	2553	NA	NA	FB PID2 Feedback 2	INTEGER	2	x100

Appendix A—Parameter ID list

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P8.2.6	2556	NA	NA	FB PID2 Feedforward 1	INTEGER	2	x100
P8.2.7	2557	NA	NA	FB PID2 Feedforward 2	INTEGER	2	x100
P8.3.1.1	1369	2170	1	PID2 Keypad Set Point 1	DOUBLE	4	x100
P8.3.1.2	1371	2179	1	PID2 Keypad Set Point 2	DOUBLE	4	x100
P8.3.1.3	2467	NA	NA	PID2 Wake Up Action	BYTE	1	x0
P8.3.2.1	1374	2110	1	PID2 Set Point 1 Source	BYTE	1	x0
P8.3.2.2	1375	2168	1	PID2 Set Point 1 Min	INTEGER	2	x100
P8.3.2.3	1376	2169	1	PID2 Set Point 1 Max	INTEGER	2	x100
P8.3.2.4	1377	2136	1	PID2 Set Point 1 Sleep Enable	BOOLEAN	1	x0
P8.3.2.5	2398	NA	NA	PID2 Set Point 1 Sleep Unit Sel	BYTE	1	x0
P8.3.2.6	2454	2137	1	PID2 Set Point 1 Sleep Level	DOUBLE	4	x100
P8.3.2.7	1379	2138	1	PID2 Set Point 1 Sleep Delay	INTEGER	2	x0
P8.3.2.8	1380	2139	1	PID2 Set Point 1 WakeUp Level	DOUBLE	4	x100
P8.3.2.9	1382	2154	1	PID2 Set Point 1 Boost	BYTE	1	x10
P8.3.2.10	1414	2830	1	PID2 Set Point1 Comp Enable	BOOLEAN	1	x0
P8.3.2.11	1415	2831	1	PID2 Set Point1 Comp Max	INTEGER	2	x100
P8.3.2.12	2546	NA	NA	FB PID2 Set Point 1	DOUBLE	4	x100
P8.3.3.1	1383	2116	1	PID2 Set Point 2 Source	BYTE	1	x0
P8.3.3.2	1384	2177	1	PID2 Set Point 2 Min	INTEGER	2	x100
P8.3.3.3	1385	2178	1	PID2 Set Point 2 Max	INTEGER	2	x100
P8.3.3.4	1386	2140	1	PID2 Set Point 2 Sleep Enable	BOOLEAN	1	x0
P8.3.3.5	2399	NA	NA	PID2 Set Point 2 Sleep Unit Sel	BYTE	1	x0
P8.3.3.6	2456	2141	1	PID2 Set Point 2 Sleep Level	DOUBLE	4	x100
P8.3.3.7	1388	2142	1	PID2 Set Point 2 Sleep Delay	INTEGER	2	x0
P8.3.3.8	1389	2143	1	PID2 Set Point 2 WakeUp Level	DOUBLE	4	x100
P8.3.3.9	1391	2157	1	PID2 Set Point 2 Boost	BYTE	1	x10
P8.3.3.10	1416	2835	1	PID2 Set Point 2 Comp Enable	BOOLEAN	1	x0
P8.3.3.11	1417	2836	1	PID2 Set Point 2 Comp Max	INTEGER	2	x100
P8.3.3.12	2548	NA	NA	FB PID2 Set Point 2	DOUBLE	4	x100
P8.4.1.1	1392	2171	1	PID2 Feedback Func	BYTE	1	x0
P8.4.1.2	1393	2153	1	PID2 Feedback Gain	INTEGER	2	x10
P8.4.2.1	1394	2112	1	PID2 Feedback 1 Source	BYTE	1	x0
P8.4.2.2	1395	2172	1	PID2 Feedback 1 Min	INTEGER	2	x100
P8.4.2.3	1396	2173	1	PID2 Feedback 1 Max	INTEGER	2	x100
P8.4.2.4	2552	NA	NA	FB PID2 Feedback 1	INTEGER	2	x100
P8.4.3.1	1397	2117	1	PID2 Feedback 2 Source	BYTE	1	x0
P8.4.3.2	1398	2181	1	PID2 Feedback 2 Min	INTEGER	2	x100
P8.4.3.3	1399	2182	1	PID2 Feedback 2 Max	INTEGER	2	x100
P8.4.3.4	2553	NA	NA	FB PID2 Feedback 2	INTEGER	2	x100
P8.5.1.1	1400	2800	1	PID2 Feedforward Func	BYTE	1	x0
P8.5.1.2	1401	2801	1	PID2 Feedforward Gain	INTEGER	2	x10
P8.5.2.1	1402	2810	1	PID2 Feedforward 1 Source	BYTE	1	x0
P8.5.2.2	1403	2811	1	PID2 Feedforward 1 Min	INTEGER	2	x100
P8.5.2.3	1404	2812	1	PID2 Feedforward 1 Max	INTEGER	2	x100
P8.5.2.4	2556	NA	NA	FB PID2 Feedforward 1	INTEGER	2	x100
P8.5.3.1	1405	2815	1	PID2 Feedforward 2 Source	BYTE	1	x0
P8.5.3.2	1406	2816	1	PID2 Feedforward 2 Min	INTEGER	2	x100
P8.5.3.3	1407	2817	1	PID2 Feedforward 2 Max	INTEGER	2	x100
P8.5.3.4	2557	NA	NA	FB PID2 Feedforward 2	INTEGER	2	x100
P9.1	535	640	0	Fire Mode Function	BOOLEAN	1	x0
P9.2	536	438	0	Fire Mode Ref Select Function	BYTE	1	x0

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P9.3	537	28	2	Fire Mode Min Frequency	INTEGER	2	x100
P9.4	565	1	5	Fire Mode Freq Ref 1	INTEGER	2	x10
P9.5	564	1	6	Fire Mode Freq Ref 2	INTEGER	2	x10
P9.6	2443	NA	NA	Fire Mode Test Enable	BOOLEAN	1	x0
P9.7	554	1	11	Smoke Purge Frequency	INTEGER	2	x10
P10.1.1	1418	1801	0	Bypass Enable	BOOLEAN	1	x0
P10.1.2	544	1802	0	Bypass Start Delay	INTEGER	2	x0
P10.1.3	542	1800	1	Auto Bypass	BOOLEAN	1	x0
P10.1.4	543	1802	1	Auto Bypass Delay	INTEGER	2	x0
P10.1.5	547	1803	0	OverCurrent Bypass Enable	BOOLEAN	1	x0
P10.1.6	546	1803	1	IGBT Fault Bypass Enable	BOOLEAN	1	x0
P10.1.7	548	1803	2	4mA Fault Bypass Enable	BOOLEAN	1	x0
P10.1.8	545	1803	3	UnderVoltage Bypass Enable	BOOLEAN	1	x0
P10.1.9	549	1803	4	OverVoltage Bypass Enable	BOOLEAN	1	x0
P10.1.10	1698	NA	NA	Motor OverTemp Bypass Enable	BYTE	1	x0
P10.1.11	1699	NA	NA	UnderLoad Bypass Enable	BYTE	1	x0
P10.1.12	1700	NA	NA	External Bypass Enable	BYTE	1	x0
P10.1.13	1701	NA	NA	Charge Switch Fault Bypass Enable	BYTE	1	x0
P10.1.14	1702	NA	NA	Saturation Trip Fault Bypass Enable	BYTE	1	x0
P10.1.15	1703	NA	NA	Under Temp Fault Bypass Enable	BYTE	1	x0
P10.1.16	1704	NA	NA	EEPROM Fault Bypass Enable	BYTE	1	x0
P10.1.17	1705	NA	NA	FRAM Fault Bypass Enable	BYTE	1	x0
P10.1.18	1706	NA	NA	Watchdog Fault Bypass Enable	BYTE	1	x0
P10.1.19	1707	NA	NA	Fan Cooling Fault Bypass Enable	BYTE	1	x0
P10.1.20	1708	NA	NA	Keypad Com Fault Bypass Enable	BYTE	1	x0
P10.1.21	1709	NA	NA	Option Card Fault Bypass Enable	BYTE	1	x0
P10.1.22	1710	NA	NA	RTC Clock Fault Bypass Enable	BYTE	1	x0
P10.1.23	1711	NA	NA	Ctrl Board OverTemp Fault Bypass Enable	BYTE	1	x0
P10.1.24	1712	NA	NA	Speed Search Start Fault Bypass Enable	BYTE	1	x0
P10.1.25	1713	NA	NA	Fieldbus Fault Bypass Enable	BYTE	1	x0
P10.2.1	2476	NA	NA	Redundant Drive Enable	BYTE	1	x0
P10.2.2	2278	NA	NA	Drive ID	BYTE	1	x0
P10.2.3	2477	NA	NA	Redundant Run Time Enable	BYTE	1	x0
P10.2.4	2478	NA	NA	Redundant Run Time Reset	BYTE	1	x0
P10.2.5	2479	NA	NA	Redundant RunTime Limit	DOUBLE	4	x10
P11.1.1	2487	NA	NA	Interval 1 Setting	BYTE	1	x0
P11.1.2	491	NA	NA	Interval 1 On Time	BYTE	3	x0
P11.1.3	493	NA	NA	Interval 1 Off Time	BYTE	3	x0
P11.1.4	517	3122	0	Interval 1 From Day	BYTE	1	x0
P11.1.5	518	3123	0	Interval 1 To Day	BYTE	1	x0
P11.1.6	519	3124	0	Interval 1 Channel	BYTE	1	x0
P11.2.1	2488	NA	NA	Interval 2 Setting	BYTE	1	x0
P11.2.2	495	NA	NA	Interval 2 On Time	BYTE	3	x0
P11.2.3	497	NA	NA	Interval 2 Off Time	BYTE	3	x0
P11.2.4	520	3122	1	Interval 2 From Day	BYTE	1	x0
P11.2.5	521	3123	1	Interval 2 To Day	BYTE	1	x0
P11.2.6	522	3124	1	Interval 2 Channel	BYTE	1	x0
P11.3.1	2489	NA	NA	Interval 3 Setting	BYTE	1	x0
P11.3.2	499	NA	NA	Interval 3 On Time	BYTE	3	x0
P11.3.3	501	NA	NA	Interval 3 Off Time	BYTE	3	x0
P11.3.4	523	3122	2	Interval 3 From Day	BYTE	1	x0

Appendix A—Parameter ID list

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P11.3.5	524	3123	2	Interval 3 To Day	BYTE	1	x0
P11.3.6	525	3124	2	Interval 3 Channel	BYTE	1	x0
P11.4.1	2490	NA	NA	Interval 4 Setting	BYTE	1	x0
P11.4.2	503	NA	NA	Interval 4 On Time	BYTE	3	x0
P11.4.3	505	NA	NA	Interval 4 Off Time	BYTE	3	x0
P11.4.4	526	3122	3	Interval 4 From Day	BYTE	1	x0
P11.4.5	527	3123	3	Interval 4 To Day	BYTE	1	x0
P11.4.6	528	3124	3	Interval 4 Channel	BYTE	1	x0
P11.5.1	2491	NA	NA	Interval 5 Setting	BYTE	1	x0
P11.5.2	507	NA	NA	Interval 5 On Time	BYTE	3	x0
P11.5.3	509	NA	NA	Interval 5 Off Time	BYTE	3	x0
P11.5.4	529	3122	4	Interval 5 From Day	BYTE	1	x0
P11.5.5	530	3123	4	Interval 5 To Day	BYTE	1	x0
P11.5.6	531	3124	4	Interval 5 Channel	BYTE	1	x0
P11.6.1	511	3100	0	Timer 1 Duration	DOUBLE	4	x0
P11.6.2	532	3102	0	Timer 1 Channel	BYTE	1	x0
P11.6.3	513	3100	1	Timer 2 Duration	DOUBLE	4	x0
P11.6.4	533	3102	1	Timer 2 Channel	BYTE	1	x0
P11.6.5	515	3100	2	Timer 3 Duration	DOUBLE	4	x0
P11.6.6	534	3102	2	Timer 3 Channel	BYTE	1	x0
P12.1.1	2533	NA	NA	FB Process Data Input 1 Sel	INTEGER	2	x0
P12.1.2	2534	NA	NA	FB Process Data Input 2 Sel	INTEGER	2	x0
P12.1.3	2535	NA	NA	FB Process Data Input 3 Sel	INTEGER	2	x0
P12.1.4	2536	NA	NA	FB Process Data Input 4 Sel	INTEGER	2	x0
P12.1.5	2537	NA	NA	FB Process Data Input 5 Sel	INTEGER	2	x0
P12.1.6	2538	NA	NA	FB Process Data Input 6 Sel	INTEGER	2	x0
P12.1.7	2539	NA	NA	FB Process Data Input 7 Sel	INTEGER	2	x0
P12.1.8	2540	NA	NA	FB Process Data Input 8 Sel	INTEGER	2	x0
P12.2.1	1556	442	0	FB Process Data Output 1 Sel	INTEGER	2	x0
P12.2.2	1557	442	1	FB Process Data Output 2 Sel	INTEGER	2	x0
P12.2.3	1558	442	2	FB Process Data Output 3 Sel	INTEGER	2	x0
P12.2.4	1559	442	3	FB Process Data Output 4 Sel	INTEGER	2	x0
P12.2.5	1560	442	4	FB Process Data Output 5 Sel	INTEGER	2	x0
P12.2.6	1561	442	5	FB Process Data Output 6 Sel	INTEGER	2	x0
P12.2.7	1562	442	6	FB Process Data Output 7 Sel	INTEGER	2	x0
P12.2.8	1563	442	7	FB Process Data Output 8 Sel	INTEGER	2	x0
P12.2.9	2415	NA	NA	Standard Status Word Bit0 Function Select	BYTE	1	x0
P12.2.10	2416	NA	NA	Standard Status Word Bit1 Function Select	BYTE	1	x0
P12.2.11	2417	NA	NA	Standard Status Word Bit2 Function Select	BYTE	1	x0
P12.2.12	2418	NA	NA	Standard Status Word Bit3 Function Select	BYTE	1	x0
P12.2.13	2419	NA	NA	Standard Status Word Bit4 Function Select	BYTE	1	x0
P12.2.14	2420	NA	NA	Standard Status Word Bit5 Function Select	BYTE	1	x0
P12.2.15	2421	NA	NA	Standard Status Word Bit6 Function Select	BYTE	1	x0
P12.2.16	2422	NA	NA	Standard Status Word Bit7 Function Select	BYTE	1	x0
P12.3.1.1	586	3220	0	RS485 Comm Set	BYTE	1	x0
P12.3.2.1	587	3221	0	Subordinate Address	BYTE	1	x0
P12.3.2.2	584	3222	0	Baud Rate	BYTE	1	x0
P12.3.2.3	585	3224	0	Parity Type	BYTE	1	x0
P12.3.2.4	588	3225	0	Modbus RTU Protocol Status	BYTE	1	x0
P12.3.2.5	593	3290	0	Comm Timeout Modbus RTU	INTEGER	2	x0
P12.3.2.6	2516	NA	NA	Modbus RTU Fault Response	BYTE	1	x0

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P12.3.3.1	594	NA	NA	MSTP Baud Rate	BYTE	1	x0
P12.3.3.2	595	NA	NA	MSTP Device Address	BYTE	1	x0
P12.3.3.3	596	NA	NA	MSTP Instance Number	DOUBLE	4	x0
P12.3.3.4	598	NA	NA	MSTP Comm Timeout	INTEGER	2	x0
P12.3.3.5	599	NA	NA	MSTP Protocol Status	BYTE	1	x0
P12.3.3.6	600	NA	NA	MSTP Fault Code	BYTE	1	x0
P12.3.3.7	2526	NA	NA	MSTP Fault Response	BYTE	1	x0
P12.3.3.8	1537	NA	NA	MSTP Max Master	BYTE	1	x0
P12.4.1.1	1500	3249	0	IP Address Mode	BOOLEAN	1	x0
P12.4.1.2	1507	NA	NA	Active IP Address	BYTE	4	x0
P12.4.1.3	1509	NA	NA	Active Subnet Mask	BYTE	4	x0
P12.4.1.4	1511	NA	NA	Active Default Gateway	BYTE	4	x0
P12.4.1.5	1513	NA	NA	MAC Address	BYTE	6	x0
P12.4.1.6	1501	NA	NA	Static IP Address	BYTE	4	x0
P12.4.1.7	1503	NA	NA	Static Subnet Mask	BYTE	4	x0
P12.4.1.8	1505	NA	NA	Static Default Gateway	BYTE	4	x0
P12.4.1.9	1725	NA	NA	Enable BACnetIP	BYTE	1	X0
P12.4.2.1	609	NA	NA	Connection Limit	BYTE	1	x0
P12.4.2.2	610	NA	NA	Modbus TCP Unit ID	BYTE	1	x0
P12.4.2.3	611	NA	NA	Comm Timeout Modbus TCP	INTEGER	2	x0
P12.4.2.4	612	3235	0	Modbus TCP Protocol Status	BYTE	1	x0
P12.4.2.5	2517	NA	NA	Modbus TCP Fault Response	BYTE	1	x0
P12.4.3.1	1733	NA	NA	BACnet IP UDP port number	INTEGER	2	x0
P12.4.3.2	1734	NA	NA	BACnet IP Foreign Device	BYTE	1	x0
P12.4.3.3	1735	NA	NA	BACnet IP BBMD IP	BYTE	4	x0
P12.4.3.4	1737	NA	NA	BACnet IP BBMD Port	INTEGER	2	x0
P12.4.3.5	1738	NA	NA	BACnet IP Registration Interval	INTEGER	2	x0
P12.4.3.6	1739	NA	NA	BACnet IP Comm Timeout	INTEGER	2	x0
P12.4.3.7	1740	NA	NA	BACnet IP Protocol Status	BYTE	1	x0
P12.4.3.8	1741	NA	NA	BACnet IP Fault Behavior	BYTE	1	x0
P12.4.3.9	1742	NA	NA	BACnetIP Instance Number	DOUBLE	4	x0
P13.1.1	340	323	0	Language	BYTE	1	x0
P13.1.2	142	256	0	Application	BYTE	1	x0
P13.1.3	619	970	0	Parameter Sets	BYTE	1	x0
P13.1.4	620	302	0	Up To Keypad	BOOLEAN	1	x0
P13.1.5	621	302	1	Down From Keypad	BYTE	1	x0
P13.1.6	623	305	0	Parameter Comparison	BYTE	1	x0
P13.1.7	624	320	0	Password	INTEGER	2	x0
P13.1.8	625	625	0	Parameter Lock	BOOLEAN	1	x0
P13.1.9	627	328	0	Multimonitor Set	BOOLEAN	1	x0
P13.1.10	628	326	0	Default Page	BYTE	1	x0
P13.1.11	629	330	0	Timeout Time	INTEGER	2	x0
P13.1.12	630	324	0	Contrast Adjust	BYTE	1	x0
P13.1.13	631	330	1	Backlight Time	INTEGER	2	x0
P13.1.14	632	627	0	Fan Control	BYTE	1	x0
P13.1.15	633	362	0	Keypad ACK Timeout	INTEGER	2	x0
P13.1.16	634	3291	0	Keypad Retry Number	BYTE	1	x0
P13.1.17	626	NA	NA	Startup Wizard	BOOLEAN	1	x0
P13.1.18	2412	NA	NA	Jog Softkey Hidden	BYTE	1	x0
P13.1.19	2413	NA	NA	Reverse Softkey Hidden	BYTE	1	x0
P13.1.20	2424	NA	NA	Output Display Unit	BYTE	1	x0

Appendix A—Parameter ID list

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
P13.1.21	2460	NA	NA	Output Display Unit Min	DOUBLE	4	x100
P13.1.22	2425	NA	NA	Output Display Unit Max	DOUBLE	4	x100
P13.2.1	640	207	2	Keypad Software Version	INTEGER	4	x0
P13.2.2	642	206	0	Motor Control Software Version	INTEGER	4	x0
P13.2.3	644	207	1	Application Software Version	INTEGER	4	x0
P13.2.4	1714	NA	NA	Software Bundle Version		20	x0
P13.3.1	646	2206	0	Brake Chopper	BOOLEAN	1	x0
P13.3.2	647	2200	0	Brake Resistor Status	BOOLEAN	1	x0
P13.3.3	648	NA	NA	Serial Number	DOUBLE	4	x0
P13.4.1	566	3000	0	Real Time Clock	BYTE	6	x0
P13.4.2	582	3001	0	Daylight Saving	BYTE	1	x0
P13.4.3	601	520	2	Total MWh Count	DOUBLE	4	x10000
P13.4.4	603	522	0	Total Power Day Count	INTEGER	2	x0
P13.4.5	606	821	1	Total Power Hr Count	DOUBLE	4	x0
P13.4.6	604	806	0	Trip MWh Count	DOUBLE	4	x10000
P13.4.7	635	322	3	Clear Trip MWh Count	BOOLEAN	1	x0
P13.4.8	636	870	0	Trip Power Day Count	INTEGER	2	x0
P13.4.9	637	871	0	Trip Power Hr Count	DOUBLE	4	x0
P13.4.10	639	322	4	Clear Trip Power Count	BOOLEAN	1	x0
B2.1.1	883	710	1	Board Status	BYTE	1	x0
B2.1.2	1064	NA	NA	Firmware Version	INTEGER	4	x0
B2.1.3	889	760	3	DI1, DI2, DI3	BYTE	1	x0
B2.1.4	888	761	3	DO1, DO2, DO3	BYTE	1	x0
B2.1.5	891	593	100	Thermistor Resistor	DOUBLE	4	x0
B2.1.6	887	753	100	Thermistor State	BYTE	1	x0
B2.2.1	241	461	100	DO1 Function	BYTE	1	x0
B2.2.2	242	461	101	DO2 Function	BYTE	1	x0
B2.2.3	243	461	102	DO3 Function	BYTE	1	x0
B2.2.4	890	343	100	Thermistor Config	BOOLEAN	1	x0
B3.1.1	883	710	1	Board Status	BYTE	1	x0
B3.1.2	1064	NA	NA	Firmware Version	INTEGER	4	x0
B3.1.3	894	560	100	A11 Value	INTEGER	2	x1000
B3.1.4	897	570	100	A01 Value	INTEGER	2	x1000
B3.1.5	899	570	101	A02 Value	INTEGER	2	x1000
B3.2.1	893	263	100	A11 Mode	BYTE	1	x0
B3.2.2	124	260	100	A11 Signal Range	BYTE	1	x0
B3.2.3	125	264	100	A11 Custom Min	INTEGER	2	x100
B3.2.4	126	265	100	A11 Custom Max	INTEGER	2	x100
B3.2.5	123	266	100	A11 Filter Time	INTEGER	2	x100
B3.2.6	127	267	100	A11 Signal Invert	BOOLEAN	1	x0
B3.2.7	896	276	100	A01 Mode	BYTE	1	x0
B3.2.8	235	460	100	A01 Function	BYTE	1	x0
B3.2.9	238	279	100	A01 Minimum	BYTE	1	x0
B3.2.10	236	277	100	A01 Filter Time	INTEGER	2	x100
B3.2.11	239	274	100	A01 Scale	INTEGER	2	x0
B3.2.12	237	278	100	A01 Inversion	BOOLEAN	1	x0
B3.2.13	240	275	100	A01 Offset	INTEGER	2	x100
B3.2.14	898	276	101	A02 Mode	BYTE	1	x0
B3.2.15	269	460	101	A02 Function	BYTE	1	x0
B3.2.16	270	279	101	A02 Minimum	BYTE	1	x0
B3.2.17	271	277	101	A02 Filter Time	INTEGER	2	x100

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
B3.2.18	272	274	101	A02 Scale	INTEGER	2	x0
B3.2.19	273	278	101	A02 Inversion	BOOLEAN	1	x0
B3.2.20	274	275	101	A02 Offset	INTEGER	2	x100
B4.1.1	883	710	1	Board Status	BYTE	1	x0
B4.1.2	1064	NA	NA	Firmware Version	INTEGER	4	x0
B4.1.3	900	455	100	RO1, RO2, RO3	BYTE	1	x0
B4.2.1	540	451	100	RO1 Function	BYTE	1	x0
B4.2.2	541	451	101	RO2 Function	BYTE	1	x0
B4.2.3	551	451	102	RO3 Function	BYTE	1	x0
B5.1.1	883	710	1	Board Status	BYTE	1	x0
B5.1.2	1064	NA	NA	Firmware Version	INTEGER	4	x0
B5.1.3	905	756	100	PT100 State	INTEGER	6	x0
B5.1.4	902	NA	NA	PT100 Values	INTEGER	6	x10
B5.2.1	901	342	100	PT100-3,2,1	BYTE	1	x0
B5.2.2	338	581	100	PT100 Warning Limit	INTEGER	2	x10
B5.2.3	339	582	100	PT100 Fault Limit	INTEGER	2	x10
B6.1.1	883	710	1	Board Status	BYTE	1	x0
B6.1.2	1064	NA	NA	Firmware Version	INTEGER	4	x0
B6.1.3	908	760	3	AC1, AC2, AC3	BYTE	1	x0
B6.1.4	1696	760	7	AC4, AC5, AC6	BYTE	1	x0
B7.1.1.1	883	710	1	Board Status	BYTE	1	x0
B7.1.1.2	1064	NA	NA	Firmware Version	INTEGER	4	x0
B7.1.1.3	2131	NA	NA	Protocol Status	BYTE	1	x0
B7.1.1.4	NA	NA	NA	PDP-Telegram Selection	INTEGER	2	x0
B7.1.1.5	NA	NA	NA	Fault Counter PDP	INTEGER	2	x0
B7.1.1.6	NA	NA	NA	Fault Situations Max	INTEGER	4	x0
B7.1.1.7	NA	NA	NA	PDP-Profil Number	INTEGER	2	x0
B7.1.1.8	NA	NA	NA	PDP-Control Word	INTEGER	2	x0
B7.1.1.9	NA	NA	NA	PDP-Status Word	INTEGER	2	x0
B7.1.2.1	2621	NA	NA	PDP-MaxBlockLength	BYTE	1	x0
B7.1.2.2	2622	NA	NA	PDP-NoOfMultiparameter	BYTE	1	x0
B7.1.2.3	2623	NA	NA	PDP-MaxLatency	BYTE	1	x0
B7.1.3.1	2624	NA	NA	PDP-DO Manufacturer	INTEGER	2	x0
B7.1.3.2	1451	NA	NA	PDP-DO Device Type	INTEGER	2	x0
B7.1.3.3	NA	NA	NA	PDP-DO FW-Interface	INTEGER	2	x0
B7.1.3.4	NA	NA	NA	PDP-DO FW-Year	INTEGER	2	x0
B7.1.3.5	NA	NA	NA	PDP-DO FW-DayMonth	INTEGER	2	x0
B7.1.3.6	2628	NA	NA	PDP-DO NoOfDOs	BYTE	1	x0
B7.1.3.7	2629	NA	NA	PDP-DO Subclass	BYTE	1	x0
B7.2.1	1242	3201	100	Subordinate Address	BYTE	1	x0
B7.2.2	1243	3202	100	Baud Rate	BYTE	1	x0
B7.2.3	1245	3200	100	Operate Mode	BYTE	1	x0
B7.2.4	NA	NA	NA	Parameter Access	INTEGER	2	x0
B7.2.5	NA	NA	NA	Process Data Access	INTEGER	2	x0
B7.2.6	NA	NA	NA	Fault Situation Counter	INTEGER	2	x0
B7.2.7	619	970	0	Parameter Sets	BYTE	1	x0
B8.1.1	883	710	1	Board Status	BYTE	1	x0
B8.1.2	1064	NA	NA	Firmware Version	INTEGER	4	x0
B8.1.3	2132	NA	NA	Protocol Status	BYTE	1	x0
B8.2.1	2133	NA	NA	Node ID	BYTE	1	x0
B8.2.2	2134	NA	NA	Baud Rate	BYTE	1	x0

Appendix A—Parameter ID list

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
B8.2.3	2135	NA	NA	Operate Mode	BYTE	1	x0
B8.2.4	2519	NA	NA	Comm Card FB Fault Response	BYTE	1	x0
B9.1.1	883	710	1	Board Status	BYTE	1	x0
B9.1.2	1064	NA	NA	Firmware Version	INTEGER	4	x0
B9.1.3	2136	NA	NA	Protocol Status	BYTE	1	x0
B9.2.1	2137	NA	NA	MAC ID	BYTE	1	x0
B9.2.2	2138	NA	NA	Baud Rate	BYTE	1	x0
B9.2.3	2187	NA	NA	IO Poll Type	BYTE	1	x0
B9.2.4	2212	NA	NA	Dnet Comm Timeout	INTEGER	2	x0
B9.2.5	2519	NA	NA	Comm Card FB Fault Response	BYTE	1	x0
B11.1.1	910	710	2	Board Status	BYTE	1	x0
B11.1.2	1067	NA	NA	Firmware Version	INTEGER	4	x0
B11.1.3	915	550	200	DI1, DI2, DI3	BYTE	1	x0
B11.1.4	914	761	2	DO1, DO2, DO3	BYTE	1	x0
B11.1.5	917	593	200	Thermistor Resistor	DOUBLE	4	x0
B11.1.6	913	753	200	Thermistor State	BYTE	1	x0
B11.2.1	244	461	200	DO1 Function	BYTE	1	x0
B11.2.2	245	461	201	DO2 Function	BYTE	1	x0
B11.2.3	246	461	202	DO3 Function	BYTE	1	x0
B11.2.4	916	343	200	Thermistor Config	BYTE	1	x0
B12.1.1	910	710	2	Board Status	BYTE	1	x0
B12.1.2	1067	NA	NA	Firmware Version	INTEGER	4	x0
B12.1.3	920	560	200	A11 Value	INTEGER	2	x1000
B12.1.4	923	570	200	A01 Value	INTEGER	2	x1000
B12.1.5	925	570	201	A02 Value	INTEGER	2	x1000
B12.2.1	919	NA	NA	A11 Mode	BYTE	1	x0
B12.2.2	129	260	200	A11 Signal Range	BYTE	1	x0
B12.2.3	130	264	200	A11 Custom Min	INTEGER	2	x100
B12.2.4	131	265	200	A11 Custom Max	INTEGER	2	x100
B12.2.5	128	266	200	A11 Filter Time	INTEGER	2	x100
B12.2.6	132	267	200	A11 Signal Invert	BOOLEAN	1	x0
B12.2.7	922	276	200	A01 Mode	BYTE	1	x0
B12.2.8	275	460	200	A01 Function	BYTE	1	x0
B12.2.9	276	279	200	A01 Minimum	BYTE	1	x0
B12.2.10	277	277	200	A01 Filter Time	INTEGER	2	x100
B12.2.11	278	274	200	A01 Scale	INTEGER	2	x0
B12.2.12	279	278	200	A01 Inversion	BOOLEAN	1	x0
B12.2.13	280	275	200	A01 Offset	INTEGER	2	x100
B12.2.14	924	276	201	A02 Mode	BYTE	1	x0
B12.2.15	281	460	201	A02 Function	BYTE	1	x0
B12.2.16	282	279	201	A02 Minimum	BYTE	1	x0
B12.2.17	283	277	201	A02 Filter Time	INTEGER	2	x100
B12.2.18	284	274	201	A02 Scale	INTEGER	2	x0
B12.2.19	285	278	201	A02 Inversion	BOOLEAN	1	x0
B12.2.20	286	275	201	A02 Offset	INTEGER	2	x100
B13.1.1	910	710	2	Board Status	BYTE	1	x0
B13.1.2	1067	NA	NA	Firmware Version	INTEGER	4	x0
B13.1.3	926	762	2	RO1, RO2, RO3	BYTE	1	x0
B13.2.1	552	451	200	RO1 Function	BYTE	1	x0
B13.2.2	555	451	201	RO2 Function	BYTE	1	x0
B13.2.3	556	451	202	RO3 Function	BYTE	1	x0

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
B14.1.1	910	710	2	Board Status	BYTE	1	x0
B14.1.2	1067	NA	NA	Firmware Version	INTEGER	4	x0
B14.1.3	931	757	2	PT100 State	INTEGER	6	x0
B14.1.4	928	NA	NA	PT100 Values	INTEGER	6	x10
B14.2.1	927	342	200	PT100-3,2,1	BYTE	1	x0
B14.2.2	937	581	200	PT100 Warning Limit	INTEGER	2	x10
B14.2.3	938	582	200	PT100 Fault Limit	INTEGER	2	x10
B15.1.1	910	710	2	Board Status	BYTE	1	x0
B15.1.2	1067	NA	NA	Firmware Version	INTEGER	4	x0
B15.1.3	934	760	4	AC1, AC2, AC3	BYTE	1	x0
B15.1.4	1697	760	8	AC4, AC5, AC6	BYTE	1	x0
B16.1.1.1	910	710	2	Board Status	BYTE	1	x0
B16.1.1.2	1067	NA	NA	Firmware Version	INTEGER	4	x0
B16.1.1.3	2142	NA	NA	Protocol Status	BYTE	1	x0
B16.1.1.4	NA	NA	NA	PDP-Telegram Selection	INTEGER	2	x0
B16.1.1.5	NA	NA	NA	Fault Counter PDP	INTEGER	2	x0
B16.1.1.6	NA	NA	NA	Fault Situations Max	INTEGER	4	x0
B16.1.1.7	NA	NA	NA	PDP-Profil Number	INTEGER	2	x0
B16.1.1.8	NA	NA	NA	PDP-Control Word	INTEGER	2	x0
B16.1.1.9	NA	NA	NA	PDP-Status Word	INTEGER	2	x0
B16.1.2.1	2621	NA	NA	PDP-MaxBlockLength	BYTE	1	x0
B16.1.2.2	2622	NA	NA	PDP-NoOfMultiparameter	BYTE	1	x0
B16.1.2.3	2623	NA	NA	PDP-MaxLatency	BYTE	1	x0
B16.1.3.1	2624	NA	NA	PDP-DO Manufacturer	INTEGER	2	x0
B16.1.3.2	1451	NA	NA	PDP-DO Device Type	INTEGER	2	x0
B16.1.3.3	2625	NA	NA	PDP-DO FW-Interface	INTEGER	2	x0
B16.1.3.4	NA	NA	NA	PDP-DO FW-Year	INTEGER	2	x0
B16.1.3.5	NA	NA	NA	PDP-DO FW-DayMonth	INTEGER	2	x0
B16.1.3.6	2628	NA	NA	PDP-DO NoOfDOs	BYTE	1	x0
B16.1.3.7	2629	NA	NA	PDP-DO Subclass	BYTE	1	x0
B16.2.1	1250	3201	200	Subordinate Address	BYTE	1	x0
B16.2.2	1251	3202	200	Baud Rate	BYTE	1	x0
B16.2.3	1253	3200	200	Operate Mode	BYTE	1	x0
B16.2.4	NA	NA	NA	Parameter Access	INTEGER	2	x0
B16.2.5	NA	NA	NA	Process Data Access	INTEGER	2	x0
B16.2.6	NA	NA	NA	Fault Situation Counter	INTEGER	2	x0
B16.2.7	619	970	0	Parameter Sets	BYTE	1	x0
B17.1.1	910	710	2	Board Status	BYTE	1	x0
B17.1.2	1067	NA	NA	Firmware Version	INTEGER	4	x0
B17.1.3	2143	NA	NA	Protocol Status	BYTE	1	x0
B17.2.1	2144	NA	NA	Node ID	BYTE	1	x0
B17.2.2	2145	NA	NA	Baud Rate	BYTE	1	x0
B17.2.3	2146	NA	NA	Operate Mode	BYTE	1	x0
B17.2.4	2520	NA	NA	Comm Card FB Fault Response	BYTE	1	x0
B18.1.1	910	710	2	Board Status	BYTE	1	x0
B18.1.2	1067	NA	NA	Firmware Version	INTEGER	4	x0
B18.1.3	2147	NA	NA	Protocol Status	BYTE	1	x0
B18.2.1	2148	NA	NA	MAC ID	BYTE	1	x0
B18.2.2	2149	NA	NA	Baud Rate	BYTE	1	x0
B18.2.3	2188	NA	NA	IO Poll Type	BYTE	1	x0
B18.2.4	2212	NA	NA	Dnet Comm Timeout	INTEGER	2	x0

Appendix A—Parameter ID list

Table 97. VS3 Parameter ID list, continued

Menu Item No.	Modbus Register	PROFIBUS		Parameter Description	Data Type	Length (in Bytes)	Display Format
		PNU	PNU SubIndex				
B18.2.5	2520	NA	NA	Comm Card FB Fault Response	BYTE	1	x0
O1	1	502	0	Output Frequency	INTEGER	2	x100
O2	24	1	0	Freq Reference	INTEGER	2	x100
O3	2	503	0	Motor Speed	INTEGER	2	x0
O4	3	504	0	Motor Current	INTEGER	2	x10
O5	4	507	0	Motor Torque	INTEGER	2	x10
O6	5	513	1	Motor Power	INTEGER	2	x10
O7	6	501	0	Motor Voltage	INTEGER	2	x10
O8	7	501	1	DC-link Voltage	INTEGER	2	x0
O9	8	822	6	Unit Temperature	INTEGER	2	x10
O10	9	822	4	Motor Temperature	INTEGER	2	x10
R11	141	1	8	Keypad Reference	INTEGER	2	x100
R12	1307	2170	0	PID1 Keypad Set Point 1	DOUBLE	4	x100
R13	1309	2179	0	PID1 Keypad Set Point 2	DOUBLE	4	x100
	142	256	0	Application	BYTE	1	x0
	340	323	0	Language	BYTE	1	x0
	566	3000	0	Real Time Clock	BYTE	6	x0
	582	3001	0	Daylight Saving	BYTE	1	x0
	101	20	0	Min Frequency	INTEGER	2	x100
	102	20	1	Max Frequency	INTEGER	2	x100
	486	210	0	Motor Nom Current	INTEGER	2	x10
	107	281	0	Current Limit	INTEGER	2	x10
	489	217	0	Motor Nom Speed	INTEGER	2	x0
	490	215	0	Motor PF	INTEGER	2	x100
	487	211	0	Motor Nom Voltage	INTEGER	2	x0
	488	216	0	Motor Nom Frequency	INTEGER	2	x100
	103	130	0	Accel Time 1	INTEGER	2	x10
	104	134	0	Decel Time 1	INTEGER	2	x10
	1695	NA	NA	Hand Control Place	BYTE	1	x0
	136	436	0	Hand Reference	BYTE	1	x0
	135	408	0	Auto 1 Control Place	BYTE	1	x0
	137	437	0	Auto 1 Reference	BYTE	1	x0
	1297	2870	0	PID1 Process Unit	BYTE	1	x0
	1298	2871	0	PID1 Process Unit Min	DOUBLE	4	x100
	1300	2872	0	PID1 Process Unit Max	DOUBLE	4	x100
	1312	2110	0	PID1 Set Point 1 Source	BYTE	1	x0
	1307	2170	0	PID1 Keypad Set Point 1	DOUBLE	4	x100
	1332	2112	0	PID1 Feedback 1 Source	BYTE	1	x0
	1333	2172	0	PID1 Feedback 1 Min	INTEGER	2	x100
	1334	2173	0	PID1 Feedback 1 Max	INTEGER	2	x100
	1297	2870	0	PID1 Process Unit	BYTE	1	x0
	1298	2871	0	PID1 Process Unit Min	DOUBLE	4	x100
	1300	2872	0	PID1 Process Unit Max	DOUBLE	4	x100
	1312	2110	0	PID1 Set Point 1 Source	BYTE	1	x0
	1307	2170	0	PID1 Keypad Set Point 1	DOUBLE	4	x100
	1332	2112	0	PID1 Feedback 1 Source	BYTE	1	x0
	1333	2172	0	PID1 Feedback 1 Min	INTEGER	2	x100
	1334	2173	0	PID1 Feedback 1 Max	INTEGER	2	x100

Appendix B—Process Data Values

Process data OUT (subordinate→master)

The fieldbus master can read the frequency converter's actual values using process data variables. All software applications use process data as follows:

Table 98. Process data OUT (subordinate → master)

Data	Value	Unit	Scale	Default, Min., Max.
Process data out 1	Output frequency	Hz	0.01 Hz	
Process data out 2	Motor speed	rpm	1 rpm	
Process data out 3	Motor current	A	0.1 A	
Process data out 4	Motor torque	%	0.10%	
Process data out 5	Motor power	%	0.10%	
Process data out 6	Motor voltage	V	0.1 V	
Process data out 7	DC link voltage	V	1 V	
Process data out 8	Latest fault code			

Note: The communication parameter group in any application has a selector parameter for every process data. The monitoring values and drive parameters can be selected using the ID number. Default selections are shown in the table above. Reference **Appendix A** for Modbus IDs that can be set via the keypad FB Process Data Out group.

Process data IN (master → subordinate)

Control word, Reference and Process Data are used with All-in-One applications as follows:

Table 99. Process data IN (master → subordinate) for all applications

Data	Value	Unit	Scale	Default
Process Data in 1	FB Torque Reference	%	0.01	0
Process Data in 2	FB Setpoint 1	varies	varies	0
Process Data in 3	FB Feedback 1	varies	varies	0
Process Data in 4	Accel Time 1	s	0.1	varies
Process Data in 5	Decel Time 1	s	0.1	varies
Process Data in 6	Current Limit	A	0.1	varies
Process Data in 7	Not Assigned	—	—	—
Process Data in 8	Not Assigned	—	—	—

Note: The communication parameter group in any application has a selector parameter for every process data. The monitoring values and drive parameters can be selected using the ID number. Default selections are shown in the table above. Reference **Appendix A** for Modbus IDs that can be set via the keypad FB Process Data Out group.

Appendix B—Process Data Values

When configuring the Process Data parameters for the drive, there are many parameters which can be monitored over the fieldbus and selected using the communications settings group menu items.

Menu Item	Parameter	Parameter Number	Default Monitored Parameter
P20.1.1	FB Data Out 1 Sel	1	Output Frequency
P20.1.2	FB Data Out 2 Sel	2	Motor Speed
P20.1.3	FB Data Out 3 Sel	3	Motor Current
P20.1.4	FB Data Out 4 Sel	4	Motor Torque
P20.1.5	FB Data Out 5 Sel	5	Motor Power
P20.1.6	FB Data Out 6 Sel	6	Motor Voltage
P20.1.7	FB Data Out 7 Sel	7	DC-link Voltage
P20.1.8	FB Data Out 8 Sel	8	Unit Temperature

However, since these Menu Items are read write items, these monitored parameters can be modified to any parameter in the drive by simply changing the value for the menu item. For example, if in **FB Data Out 8** one wanted to monitor the state of the Digital Inputs DI1 to DI3 they would change **Process Data Out 8** from an 8 to a 12. For a complete list of parameters please refer to Communication Application Guide which can be found on the drives web site.

Typically the parameters which are monitored over fieldbus are the same types of parameters monitored on the Monitoring menu of the drive, a list of those parameters and IDs are provided below.

Parameter ID	Description	Parameter ID	Description
1	Output Frequency	16	PID1 Set Point
2	Motor Speed	18	PID1 Feedback
3	Motor Current	20	PID1 Error Value
4	Motor Torque	22	PID1 Output
5	Motor Power	23	PID1 Status
6	Motor Voltage	24	Freq Reference
7	DC-link Voltage	25	Analog Output 1
8	Unit Temperature	26	Running Motors
9	Motor Temperature	27	PT100 Temperature
10	Analog Input 1	28	Last Active Fault
11	Analog Input 2	30	Multi-Monitoring
12	DI1, DI2, DI3	32	PID2 Set Point
13	DI4, DI5, DI6	34	PID2 Feedback
14	DO1	36	PID2 Error Value
15	Torque Reference	38	PID2 Output
		39	PID2 Status

Appendix C—Fault codes

Fault codes

Table 100. Fault code list

Fault Code	Fault Name	Fault type	Default	Realization	CIP Fault code	PROFIdrive fault code
1	Over current	Fault		DSP	0x2310h	8976
2	Over voltage	Fault		DSP	0x3210h	12816
3	Earth vault	Configurable	Fault	DSP	0x2330h	9008
5	Charging switch	Fault		DSP	0xA000h	12849
6	Emergency stop	Fault		MCU	0xA001h	21121
7	Saturation trip	Fault		DSP	0xA002h	29040
9	UnderVoltage	Configurable	Fault	DSP/MCU	0x3220h	12576
10	Input Phase Spv	Configurable	Fault	DSP	0xA004h	8528
11	Output Phase Spv	Configurable	Fault	DSP	0xA005h	9040
12	BrakeChopperSpv	Fault		DSP	0x7110h	28944
13	Drive underTemp	Configurable	Warning	DSP	0x4320h	16928
14	Drive overTemp	Fault		DSP	0x4310h	16912
15	Motor stalled	Configurable	No Action	DSP	0x7121h	28963
16	Motor overTemp	Configurable	No Action	DSP	0x4210h	17168
17	Motor underLoad	Configurable	No Action	DSP	29d	28979
18	IP address conflict	Configurable	Warning	MCU	0xA006h	30070
19	Power board EEPROM fault	Fault		MCU	0xA007h	21795
20	FRAM fault	Fault		MCU	0xA008h	21777
21	Serial flash fault	warning		MCU	0xA009h	21796
25	MCU WatchDog fault	Fault		MCU	0x6010h	24848
26	Start-up prevent	Fault		MCU	0xA00Ah	35585
29	Thermistor fault	Configurable	Fault	MCU	0x7300h	28978
32	Fan cooling	Fault		DSP	0xA00Bh	28689
36	Compatibility fault	Fault		MCU	0x5200h	24849
37	Device change	Warning		MCU	0xA00Ch	35360
38	Device added	Warning		MCU	0xA00Dh	35361
39	Device removed	Fault		MCU	0xA00Eh	35362
40	Device Unknown	Fault		MCU	0xA00Fh	35363
41	IGBT temperature	Fault		DSP	66d	16913
50	AIN<4mA(4to20mA)	Configurable	No Action	MCU	0xA011h	29520
51	External fault	Configurable	Fault	MCU	0x9000h	36864
52	Keypad communication fault	Configurable	Fault	MCU	0xA012h	21264
54	OPT card fault	Configurable	Fault	MCU	0xA013h	35073
55	Real time clock fault	Configurable	Warning	MCU	0xA015h	35344
56	PT100 fault	Configurable	Fault	MCU	0xA016h	29536
57	Motor ID fault	Fault		DSP	0xA017h	29072
59	Possible power wiring error detected	Fault		DSP	0x5400h	37121
58	Current measure fault	Fault		DSP	0x2100h	9217
60	Control board overtemp	Fault		DSP	0x4300h	16914
61	Internal-ctrl supply	Fault		MCU	0x5112h	20737
62	Too many speed search restarts	Fault		DSP	0xA018h	33809
63	Current unbalance	Fault		DSP	26d	9056
64	Replace battery	Configurable	Warning	MCU	0xA019h	35345
65	Replace fan	Configurable	Warning	MCU	0xA01Ah	28688
66	Safety torque off	Fault		DSP	0xA01Bh	21665

Appendix C—Fault codes

Table 100. Fault code list, continued

Fault Code	Fault Name	Fault type	Default	Realization	CIP Fault code	PROFIdrive fault code
67	Current limit control	Warning		DSP	0x2200h	8977
68	Over voltage control	Warning		DSP	0x3310h	12817
69	System Fault - Thermistor SPI	Fault		MCU	0xA01Ch	21009
70	System Fault - DSP Parameter	Fault		MCU	0xA01Dh	22018
71	System Fault - Intercom	Fault		MCU	0xA01Eh	22019
72	Power board EEPROM fault	Fault		MCU	0xA01Fh	22305
73	Internal FRAM	Fault		MCU	0xA020h	22033
74	FRAM data error	Fault		MCU	0xA021h	21809
75	Internal power board EEPROM fault	Fault		MCU	0xA022h	22035
76	EEPROM Data error	Fault		MCU	0xA023h	21808
77	Internal serial flash	Fault		MCU	0xA024h	22051
82	Bypass overload	Fault		MCU	0xA025h	28980
83	FieldBus fault	Configurable	Fault	MCU	0xA026h	30064
84	FieldBus fault	Configurable	Fault	MCU	0xA027h	30065
85	FieldBus fault	Configurable	Fault	MCU	0xA028h	30066
86	FieldBus fault	Configurable	Fault	MCU	0x8100h	30067
87	FieldBus fault	Configurable	Fault	MCU	0xA029h	30068
88	FieldBus fault	Configurable	Fault	MCU	0xA02Ah	30069
89	Under voltage	Fault		DSP	0xA02Bh	30070
90	Drive UnderTemp	Warning/Fault		DSP	0x3221h	30071
91	Option card fault	Fault		MCU	0xA02Ch	30072
92	External fault 2	Configurable	Fault	MCU	0xA02Dh	NA
93	External fault 3	Configurable	Fault	MCU	0xA02Eh	NA
94	Pump lost	Warning		MCU	0xA02Fh	58881
95	Need alternation	Warning		MCU	0xA030	58882
96	Parameter error	Warning		MCU	0x6320	33072
97	Prime loss	Configurable	No Action	MCU	0xA031	35587
98	PID1 feedback AI loss	Configurable	No Action	MCU	0xA032	33283
99	PID2 feedback AI loss	Configurable	No Action	MCU	0xA033	33284
100	FieldBus SMDT Fault	Configurable	Fault	MCU	0xA034	30002
101	SMDT card fault	Configurable		MCU	0xA035	35120
102	External Fault from SWD	Configurable	Fault	MCU	0xA036	36871
103	Drive OverTemp Warning	Warning		DSP	0xA037	16912
104	Compatibility Fault	Warning		MCU	0xA038	22529
105	Compatibility Fault	Warning		MCU	0xA039	22532
106	Compatibility Fault	Warning		MCU	0xA03A	22785
107	Compatibility Fault	Warning		MCU	0xA03B	22786
108	Compatibility Fault	Warning		MCU	0xA03C	22784
109	Compatibility Fault	Warning		MCU	0xA03D	22787
110	Compatibility Fault	Warning		MCU	0xA03E	22788
111	Compatibility Fault	Warning		MCU	0xA03F	22792
112	Compatibility Fault	Warning		MCU	0xA040	22806
113	Compatibility Fault	Warning		MCU	0xA041	22789
114	Compatibility Fault	Warning		MCU	0xA042	22791

Note: Configurable—Faults that are specified as “Configurable” have “Fault configuration parameter” associated with them. This configuration parameter can be configured as using keypad (menu Protections) or using vendor specific object.

Appendix D—Variable Speed Drive Series III Recommended Secure Hardening Guidelines

Introduction

This section “secure configuration” or “hardening” guidelines provide information to the users to securely deploy and maintain this product to adequately minimize the cybersecurity risks to their system. Johnson Controls is committed to minimizing the Cybersecurity risk in its products and deploys cybersecurity best practices and latest cybersecurity technologies in its products and solutions; making them more secure, reliable and competitive for our customers. Johnson Controls also offers Cybersecurity Best Practices whitepapers to its customers that can be referenced at www.JohnsonControls.com/cybersecurity

Table 101. Variable Speed Drive Series III—secure configuration guidelines

Category	Description
Asset identification and inventory	Keeping track of all the devices in the system is a pre-requisite for effective management of Cybersecurity of a system. Ensure you maintain an inventory of all the components in your system in a manner in which you uniquely identify each component. To facilitate this, Variable Speed Drive Series III supports the following identifying information - manufacturer, type, serial number, f/w version number, and location. Customers/users can read following information from product label • Model Number • Serial Number • Device Name Information specific to communication protocols is available from parameter menu as below • IP Address Mode • Active IP Address • MAC Address See application manual for these parameter locations.
Restrict physical access	Industrial Control Protocols don't offer cryptographic protections at protocol level leaving them exposed to Cybersecurity risk. Physical security is an important layer of defense in such cases. Variable Speed Drive Series III is designed with the consideration that it would be deployed and operated in a physically secure location. • Johnson Controls suggests that physical access to cabinets and/or enclosures containing Variable Speed Drive Series III and the associated system should be restricted, monitored and logged at all times. • Physical access to the communication lines should be restricted to prevent any attempts of wiretapping, sabotage. It's a best practice to use metal conduits for the communication lines running between one cabinet to another cabinet. • Attacker with unauthorized physical access to the device could cause serious disruption of the device functionality. A combination of physical access controls to the location should be used, such as locks, card readers, and/or guards etc. • Variable Speed Drive Series III supports the following physical access ports, • RJ45 connector for removable keypad as well as Modbus RTU communications • RJ45 for EtherNet IP/Modbus TCP communications • Terminal block for Modbus RTU and other Digital IOs Johnson Controls suggests access to above physical ports need to be restricted.

Appendix D—Variable Speed Drive Series III Recommended Secure Hardening Guidelines

Table 101. Variable Speed Drive Series III—secure configuration guidelines, continued

Category	Description
Restrict logical access to Variable Speed Drive Series III	It is extremely important to securely configure the logical access mechanisms provided in Variable Speed Drive Series III VFD to safeguard the device from unauthorized access. Variable Speed Drive Series III VFD provides various types of administrative, operational, configuration privilege levels. Johnson Controls recommends that the available access control mechanisms be used properly to ensure that access to the system is restricted to legitimate users only. And, such users are restricted to only the privilege levels necessary to complete their job roles/functions. Johnson Controls recommends below best practices to be followed to ensure adequate cybersecurity of the setup/system • Default credentials are changed upon first login. Variable Speed Drive Series III VFD should not be commissioned for production with Default credentials, it's a serious Cybersecurity flaw as the default credentials are published in the manuals. Restrict administrative privileges - Threat actors are increasingly focused on gaining control of legitimate credentials, especially those associated with highly privileged accounts. Limit privileges to only those needed for a user's duties. Make sure that the password used in the device is only available to authorized users like Configuring Engineers and not shared among all operational users. • Perform periodic account maintenance to make sure that password is changed whenever there is personnel change. • Change passwords and other system access credentials as appropriate • Variable Speed Drive Series III VFD is provided with data/access protection mechanism on keypad, follow below steps to utilize it Variable Speed Drive Series III VFD provides four levels of data protection for users to ensure the security: 1. Lock parameters on keypad. User can lock the parameters through DI or disable change, in which way all the parameters cannot be edited. 2. Lock parameters while motor running. Motor control parameters can only be modified when motor is in stop mode. In which way to enhance the motor security. The parameters are listed in the application manual. 3. Through Power Xpert inControl tool, facility to hide parameters on keypad is available. User can hide the parameters he/she thinks are significant for himself/herself. Such as IP address and so on. 4. Password on keypad. • 0000 means no password, which is the default. • Password range is 0001 ~ 9999. • With password, user can monitor parameters value but need enter password if he/she wants to edit parameters. • User needs to re-enter the password if there is no key operation in 1 min after enter the password. • User needs to enter the old password if he/she wants to change to a new one.
Restrict network access	Variable Speed Drive Series III VFD provides network access to facilitate communication with other devices in the systems and configuration. But this capability could open up a big security hole if it's not configured securely. Johnson Controls recommends segmentation of networks into logical enclaves and restrict the communication to host-to-host paths. This helps protect sensitive information and critical services and limits damage from network perimeter breaches. At a minimum, a utility Industrial Control Systems network should be segmented into a three-tiered architecture (as recommended by NIST SP800-82[R3]) for better security control. Deploy adequate network protection devices like Firewalls, Intrusion Detection / Protection devices. Below are the protocols and their port details available on Variable Speed Drive Series III VFD. Use below information for configuring the firewalls. Variable Speed Drive Series III VFD provides below communication protocols – • EtherNet IP protocols on RJ45 connector – enabled by default on port 44818 and 2222 • Modbus TCP protocol on RJ45 connector – enabled by default on port 502 • Modbus RTU on RS485 physical layer – enabled by default • BACnet MS/TP on RS485 physical layer – disabled by default, when this is enabled, Modbus RTU is disabled. All the protocols have dedicated menu structure, and details are described in User's Manual for how to activate or configure them. • Johnson Controls has published detailed information about various Network level protection strategies in Johnson Controls Cybersecurity Considerations for Electrical Distribution Systems [R1].

Table 101. Variable Speed Drive Series III—secure configuration guidelines, continued

Category	Description
Logging and event management	Best practices - Variable Speed Drive Series III VFD provides parameters change log and fault log functions for user, to help diagnose the drive 1. Parameters change log: - Variable Speed Drive Series III VFD will log the parameter information in FRAM when the parameter changes. The max number of 66 items can be logged. New log will rewrite the old one. User cannot clear this fault information. 2. Fault log: - Variable Speed Drive Series III VFD will log the drive information in FRAM when fault occurs. The max number of 10 items can be logged. New log will rewrite the old one. User can clear the history fault by pressing OK key more than 5 Sec. - Variable Speed Drive Series III VFD will log the fault information in FRAM when fault occurs. The max number of 50 items can be logged. New log will rewrite the old one. User cannot clear this fault information.
Secure maintenance	Best practices Apply Firmware updates and patches regularly Due to rapidly increasing Cyber Threats in Industrial Control Systems, Johnson Controls implements a comprehensive patch and update process for its products. Users are encouraged to maintain a consistent process to promptly monitor for fresh firmware updates and apply the update whenever required. - The latest firmware can be acquired from the www.johnsoncontrols.com website. There will be separate link for Variable Speed Drive Series III VFD FR0 to FR6. - Users can also sign up on our website to get emails when new material is released to the site if desired. - Using the PC Tool or verifying on the keypad the current version of firmware can be verified. - For additional information or technical support on Johnson Controls's Variable frequency drive products contact local sales representative. Johnson Controls also has a robust vulnerability response process. In the event of any security vulnerability getting discovered in its products, Johnson Controls patches the vulnerability and releases information bulletin through its cybersecurity website - http://www.johnsoncontrols.com/cybersecurity and patches through www.johnsoncontrols.com.



© 2018 Johnson Controls
All Rights Reserved
Printed in USA
Publication No. LIT-12013000 / Z21251
September 2018

Johnson Controls is a registered
trademark.

All trademarks are property
of their respective owners.